

RS232 to Ethernet TCP/IP module (USR-TCP232- 2)

Hard version: V1.0

File version: V1.0

2011-11-12



Notice: USR-TCP232-2 is a base version of USR-TCP232-24, the difference from USR-TCP232-24 is no RS485 interface, their usage is the same, so please reference to USR-TCP232-24 data sheet.

The interface near RJ45 is for Power Input, can also be changed to USB B Port.

1.USR-TCP232-2 jumper

Connect Pin1 and Pin2 is for CFG, Pin3 and Pin4 for UPD, Pin1 and Pin3 is GND, be default the jump is connect them, not any function, just put a jump here.



2. Contact Us

Company: Jinan USR IOT Technology Co., Ltd

Address: 1-523, Huizhan Guoji Cheng, Gaoxin Qu, Jinan, Shandong, China

Tel: 86-531-55507297 86-531-88826739-803

Web: www.tcp232.net