

WARNING

THE FOLLOWING SERVICING INSTRUCTIONS ARE FOR USE BY QUALIFIED PERSONNEL ONLY. TO AVOID PERSONAL INJURY, DO NOT PERFORMANY SERVICING OTHER THAN THAT CONTAINED IN OPERATING INSTRUCTIONS UNLESS YOU ARE QUALIFIED TO DO SO.

PLEASE CHECK FOR CHANGE INFORMATION AT THE REAR OF THIS MANUAL.

7S11 SAMPLING UNIT

INSTRUCTION MANUAL

Tektronix, Inc. P.O. Box 500 Beaverton, Oregon 97077

Serial Number:

070-0985-00 Product Group 42 First Printing FEB 1970 Revised FEB 1989

Scans by ARTEK MEDLA =>

DIGITALY REMASTERED OUT OF PRINT- MANUAL SCANS

By Artek Media

18265 200th St. Welch, MN 55089

www.artekmedia.com

"High resolution scans of obsolete technical manuals"

If your looking for a quality scanned technical manual in PDF format please visit our WEB site at <u>www.artekmedia.com</u> or drop us an email at <u>manuals@artekmedia.com</u> and we will be happy to email you a current list of the manuals we have available.

If you don't see the manual you need on the list drop us a line anyway we may still be able to point you to other sources. If you have an existing manual you would like scanned please write for details. This can often be done very reasonably in consideration for adding your manual to our library.

Typically the scans in our manuals are done as follows;

- 1) Typed text pages are typically scanned in black and white at 300 dpi.
- 2) Photo pages are typically scanned in gray scale mode at 600 dpi
- 3) Schematic diagram pages are typically scanned in black and white at 600 dpi unless the original manual had colored high lighting (as is the case for some 70's vintage Tektronix manuals).
- 4) Most manuals are text searchable
- 5) All manuals are fully bookmarked

All data is guaranteed for life (yours or mine ... which ever is shorter). If for ANY REASON your file becomes corrupted, deleted or lost, Artek Media will replace the file for the price of shipping, or free via FTP download.

Thanks

Dave & Lynn Henderson Artek Media Copyright e 1970 Tektronix, Inc. All rights reserved. Contents of this publication may not be reproduced in any form without the written permission of Tektronix, Inc.

Products of Tektronix, Inc. and its subsidiaries are covered by U.S. and foreign patents and/or pending patents.

TEKTRONIX, TEK, SCOPE-MOBILE, and are registered trademarks of Tektronix, Inc. TELEQUIPMENT is a registered trademark of Tektronix U.K. Limited.

Printed in U.S.A. Specification and price change privileges are reserved.

INSTRUMENT SERIAL NUMBERS

Each instrument has a serial number on a pañel insert, tag, or stamped on the chassis. The first number or letter designates the country of manufacture. The last five digits of the serial number are assigned sequentially and are unique to each instrument. Those manufactured in the United States have six unique digits. The country of manufacture is identified as follows:

B000000	Tektronix, Inc., Beaverton, Oregon, USA
100000	Tektronix Guernsey, Ltd., Channel Islands
200000	Tektronix United Kingdom, Ltd., London
300000	Sony/Tektronix, Japan
700000	Tektronix Holland, NV, Heerenveen, The Netherlands

Scans by ARTEK MEDIA =>

TABLE OF CONTENTS

SECTION 1	SPECIFICATION	Page
	General Information	1-1
	Electrical	1-1
	Environmental Characteristics	1-2
	Physical Characteristics	1-2
SECTION 2	OPERATING INSTRUCTIONS	
	General Information	2-1
	Installation	2-1
	Mating	2-1
	First-Time Operation	2-2
	Equivalent-Time Sampling Operation	2-2
	Controls and Connectors	2-2
	Basic Operating Information	2-2
	Basic Applications	2-9

WARNING

THE FOLLOWING SERVICE INSTRUCTIONS ARE FOR USE BY QUALIFIED PERSONNEL ONLY. TO AVOID PERSONAL INJURY, DO NOT PERFORM ANY SERVICING OTHER THAN THAT CONTAINED IN OPERATING INSTRUCTIONS UNLESS YOU ARE QUALI-FIED TO DO SO.

SECTION 3 BASIC SAMPLING PRINCIPLES

Introduction	3-1
Basic Sampling Techniques	3-1
Effective Sampling Time	3-4
Traveling Wave Sampling Gate	3-5
Dot Response (Loop Gain)	3-5
Smoothing	3-5
Smoothing of Random Noise	3-6
Tangential Noise	3-6
Display Sensitivity-Deflection Factor	3-7
DC Offset	3-7
Real-Time Sampling	3-8
Sweep Rates	3-8

TABLE OF CONTENTS (cont)

SECTION 4	CIRCUIT DESCRIPTION	Page
	Introduction	4-1
	Block Diagram	4-1
	Feedback Loop and Pulse Amplifier Chain	4-1
	Vertical Output Amplifier	4-1
	Sweep Unit Drive	4-1
	Readout Logic	4-3
	Circuit Description	4-3
	Trigger Logic	4-3
	Post Amplifier and Attenuators	4-3
	Memory	4-5
	Output Amplifier	4-8
	Real Time Oscillator	4-8
	Gate Generator	4-9
	Readout Logic	4-11
	Power Distribution and Decoupling	4-11
	· · · · · · · · · · · · · · · · · · ·	
SECTION 5	MAINTENANCE	
	Introduction	5-1
	Preventive Maintenance	5-1
	General	5-1
	Cleaning	5-1
	Lubrication	5-1
	Visual Inspection	5-1
	Calibration	5-1
	Parts Identification	5-1
	Parts Replacement	5-2
	Troubleshooting	5-4
	Introduction	5-4
	Troubleshooting Aids	5-4
	Troubleshooting Techniques	5-5
	Transistor Checks	5-5
	Diode Checks	5-5
	Field Effect Transistors (FET)	5-6
	Repackaging for Shipment	5-7
SECTION 6	PERFORMANCE CHECK/CALIBRATION	
	Introduction	6-1
	Test Equipment Required	6-1
	Short Form Procedure	6-2
	Preliminary Procedure	6-3
	Check - 12.2-Volt Power Supply	6-5
	Check Interdot Blanking	6-6
	Check Dot Response and Smooting	6-7
	Adjust Memory Gate Width (R460) and	•••
	Memory Gain (C275) With Normalizer Head	6-7
	Adjust Memory Gate Width (R460) and	•••
	Memory Gain (C275) With Sampling Head	6-8

TABLE OF CONTENTS (cont)

		Page
	Adjust Variable Balance (R305) and	
	Smooting Balance (R245)	6-9
	Check Deflection Factor Accuracies,	
	Variable Control Range and Adjust GAIN	6-10
	Check Memory Overdrive Recovery	6-11
	Check Vertical Signal Out	6-11
	Check Vertical Gain Change in SMOOTH	6-11
	Check Memory Slash	6-11
	Check Delay	6-12
	Check/Adjust Real Time Sampling (R415)	6-12
	Check DC Offset and Adjust Position (R325)	6-12
	Check Real-Time Trigger Amplifier Output	6-14
SECTION 7	ELECTRICAL PARTS LIST	
	Abbreviations and Symbols	
	Parts Ordering Information	
	Index of Electrical Parts List	
	Electrical Parts List	
SECTION 8	DIAGRAMS AND MECHANICAL PARTS ILLUSTRATIONS	
	Diagrams	
	Mechanical Parts Illustrations	
	Repackaging Instructions	
SECTION 9	MECHANICAL PARTS LIST	
	Mechanical Parts List Information	
	Index of Mechanical Parts Illustrations	
	Mechanical Parts List	
	Accessories	

CHANGE INFORMATION

Abbreviations and symbols used in this manual are based on or taken directly from IEEE Standard 260 "Standard Symbols for Units", MIL-STD-12B and other standards of the electronics industry. Change information, if any, is located at the rear of this manual.

SAFETY SUMMARY

The general safety information contained in this summary is for servicing personnel. Specific warnings and cautions will be found throughout the manual where they apply, but may not appear in this summary.

TERMS

IN THIS MANUAL

CAUTION statements identify conditions or practices that could result in damage to the equipment or other property.

WARNING statements identify conditions or practices that could result in personal injury or loss of life.

AS MARKED ON EQUIPMENT

CAUTION indicates a personal injury hazard not immediately accessible as one reads the marking, or a hazard to property including the equipment itself.

DANGER indicates a personal injury hazard immediately accessible as one reads the marking.

SYMBOLS

IN THIS MANUAL



Static-Sensitive Devices



This symbol indicates where applicable cautionary or other information is to be found.

AS MARKED ON EQUIPMENT



DANGER—High voltage.



Protective ground (earth) terminal.



ATTENTION—refer to manual.

WARNINGS

POWER SOURCE

This product is intended to operate from a power source that will not apply mare than 250 volts rms between the supply conductors or between either supply conductor and ground. A protective ground connection by way of the grounding conductor in the power cord is essential for safe operation.

USE THE PROPER POWER CORD

Use only the power cord and connector specified for your product. Use only a power cord that is in good condition.

GROUNDING THE PRODUCT

This product is grounded through the grounding conductor of the power cord. To avoid electrical shock, plug the power cord into a properly wired receptacle before making connections to the product input or output terminals. A protective ground connection by way of the grounding conductor in the power cord is essential for safe operation.

DANGER ARISING FROM LOSS OF GROUND

Upon loss of the protective-ground connection, all accessible conductive parts (including knobs and controls that may appear to be insulating), can render an electric shock.

USE THE PROPER FUSE

To avoid hazard, use only the fuse specified in the parts list for your product, and which is identical in type, voltage rating, and current rating.

DO NOT OPERATE IN EXPLOSIVE ATMOSPHERES

To avoid explosion, do not operate this product in an atmosphere of explosive gases unless it has been specifically certified for such operation.

DO NOT SERVICE ALONE

Do not perform internal service or adjustment of this product unless another person capable of rendering first aid and resuscitation is present.

USE CARE WHEN SERVICING WITH POWER ON

Dangerous voltages exist at several points in this product. To avoid personal injury, do not touch exposed connections and components while power is on.

Disconnect power before removing protective panels, soldering, or replacing components.

SILICONE GREASE HANDLING

Handle silicone grease with care. Avoid getting the silicone grease in your eyes. Wash hands thoroughly after using silicone grease.

ADD FEB 1984

v

1

Scans by ARTEK MEDIA =>



Fig. 1-1, 7511 Sampling Unit.

SECTION 1 7S11 SPECIFICATION

Change information, if any, affecting this section will be found at the rear of the manual.

General Information

The 7S11 Sampling Unit is a single channel vertical amplifier plug-in unit designed for operation in Tektronix 7000-Series Oscilloscopes. The 7S11 accepts the S-Series Sampling Heads. The Sampling Head determines the input characteristics and the availability of a trigger pickoff.

The S-Series Sampling Head used can be plugged into the 7S11 or used remotely on an optional extender cable unit. The 7S11 provides the power for the sampling head. Interconnections to the sampling head circuits are provided by the connector in the sampling head compartment of the 7S11.

The 7S11 and a 7T11 Sampling Sweep Unit operated in the center plug-in compartments of a 7000-Series oscilloscope provide a single channel sampling system. Two 7S11's and one 7T11 provide dual-trace sampling, using the electronic switching in the oscilloscope vertical amplifier. X-Y operation is provided by two 7S11's operated in the center plug-in compartments of the oscilloscope.

If a trigger pickoff is provided in the sampling head, interconnections between two 7S11's and the 7T11 through the fixed and movable shoes provide a trigger selection circuit to trigger the 7T11. An internally reconstructed signal is provided to trigger a real-time time-base such as the 7B50.

Sampled signals are presented to both the oscilloscope vertical amplifier and to the front panel connectors for external use with auxiliary equipment such as pen recorders.

TABLE 1-1

ELE	СТ	RI	CA	
-----	----	----	----	--

Characteristic	Performance	
Deflection Factor		
Units/Division Range	2 to 200 in seven steps in 1, 2, 5 sequence. The Units/Division are those labeled on the sampling head.	

TABLE 1-1 (cont)

Characteristic	Performance	
Gain Accuracy (Ratio to add to accuracies of source, oscillo- scope, attenu- ators, etc.)	Within 3% when NORMAL/ SMOOTH function is NORMAL, with GAIN adjusted at any Units/ Division switch setting. Within 6% when NORMAL/SMOOTH func- tion is SMOOTH.	
Units/Division Variable Range	Extends deflection factor from 1 unit/division or less to at least 400 units/division.	
GAIN Range	Permits adjustment of deflection factor at any Units/Division switch setting for all 7000-series oscillo- scopes.	
DELAY Range	At least 10 ns.	
Memory Slash	0.1 division or less at 20 Hz for ambient temperature of 0° C to less than 30° C.	
DC OFFSET Range	+1 volt to -1 volt or more. ¹	
OFFSET OUT		
Range	+10 volts to10 volts or more.	
Relation to actual Offset	Actual Offset = (0.1) (Offset Out) within 2%.	
Source resistance (related to actual Offset)	10 kΩ within 1%.	
VERTical SIGnal OUT		
Amplitude in volts	(Signal input in volts) (200 Units/Div within 2%. 2.4 volts peak-to-peak	
(Referenced to input)	maximum.	
Deflection factor (Referenced to CRT)	200 mV/displayed division within 3% in +UP or INVERT.	
Source resistance	10 k Ω within 0.5%.	

¹Unless otherwise stated on sampling head front-panel.

ENVIRONMENTAL CHARACTERISTICS

Storage-altitude up to 50,000 feet or 15,000 meters and -55° C. Operating characteristics are the same as those listed in the 7000-series oscilloscope manual.

PHYSICAL CHARACTERISTICS

Dimensions	
Height	5 inches (12.7 centimeters)
Width	3 inches (7.6 centimeters)
Length	14 1/2 inches (37 centimeters)

Approximate dimensions including knobs and connectors.

Finish	Front panel is anodized aluminum.	
Weight		
Net	About 2 pounds (0.9 kilogram).	
Shipping	About 3 1/4 pounds (1.46 kilo- grams).	

STANDARD ACCESSORIES

Standard accessories supplied with the 7S11 are listed on the last page of the Mechanical Parts List section. For optional accessories available for use with this instrument, see the Tektronix, Inc. catalog.

SECTION 2 OPERATING INSTRUCTIONS

Change information, if any, affecting this section will be found at the rear of the manual.

General Information

This section discusses installation, first time operation, function of front panel controls and connectors, basic operation and applications of the 7S11. If you are unfamiliar with sampling, it may be helpful to read Section 3, Basic Tektronix Sampling Principles, before proceeding with this section.

The 7S11 is a single-channel sampling unit for use in a sampling system consisting of a Tektronix 7704 or 7504 Oscilloscope mainframe, a sampling sweep unit (7T11) or real-time time-base and a 7S11-sampling head combination. The 7S11 accepts an S-series sampling head which determines the input characteristics of the sampling system and (except for the Type S-3 Sampling Head) provides a trigger pickoff.

The 7S11 can be used for real time operation with realtime time-base units such as the 7B71 or 7B70 with the 7704 Oscilloscope, or the 7B51 or 7B50 with the 7504 Oscilloscope. An internal trigger source from the display signal is provided for real time operation. Nevertheless, the maximum useable sweep rate is about .1 ms/div (with a 1 kHz signal), since at higher frequencies the horizontal dot size increases and the number of dots per division becomes less than three.

The vertical deflection factors of 2 to 200 are calibrated to the units labeled on the sampling head. Three-foot and six-foot sampling head extender cables are available to operate the S-series sampling heads remotely. Order the three-foot sampling head extender cable by Tektronix Part No. 012-0124-00. Order the six-foot sampling head extender cable by Tektronix Part No. 012-0125-00. Contact your local Tektronix Field Engineer or Representative for price and availability of these optional accessories.

Installing the 7S11 in the Oscilloscope

Insert the 7S11 into the Right Vertical opening of the oscilloscope and slide the 7S11 completely into the compartment. The 7S11 will lock into place with the spring loaded latch knob. Insert the sampling head into the 7S11 with the latch knob free to move until completely in the 7S11, then push the latch to lock the head in place. To remove, pull the latch knob away from the panel, then pull the unit from the 7S11.

The 7T11 Sampling Sweep Unit, normally used with the 7S11, must be installed in the A Horizontal opening next to the 7S11 to make connections between the two units through side connectors (the movable and fixed shoes).

Mating

The 7S11 Vertical Output Amplifier gain must be matched to the oscilloscope CRT deflection factor for accurate gain measurements. The GAIN control, a screwdriver adjustment on the front panel, adjusts the Vertical Output Amplifier gain of the 7S11. Adjustment of this GAIN control using the Type 284 Pulse Generator as a signal source is shown under Equivalent Time Sampling Operation which follows. For further Gain information, refer to the Gain Adjustment instructions later in this section.



Fig. 2-1. Equivalent time sampling system.

FIRST-TIME OPERATION

Equivalent-Time Sampling Operation

Equivalent time sampling operation as described here is provided by a system consisting of the 7504 Oscilloscope, the 7S11 Sampling Unit, the Type S-1 Sampling Head, and the 7T11 Sampling Sweep Unit. The system is shown in Fig. 2-1. Operation of the oscilloscope, sampling head, and the sampling sweep unit is covered more fully in each instrument's manual. In this description, a Type 284 Pulse Generator is used as a signal source.

Set the Oscilloscope Vertical Mode switch to Right, the A Trigger Source switch at Right Vert, and the Horizontal Mode switch to A. Other oscilloscope controls may be in any desired position.

Set the 7S11 controls as follows:

DELAY	Midrange
+ UP/INVERT	+ UP
DC OFFSET and FINE	Midrange
VARIABLE	Pushed in
Units/Div	200
DOT RESPONSE	Midrange
NORMAL/SMOOTH	NORMAI

Set the 7T11 controls as follows:

Time Position and Fine	Fully clockwise
Slope	+
Trig Level	Midrange
Stability	Fully counterclockwise
Random/Sequential	Sequential
Trig Amp	X10
Variable	Pushed in
Time/Div	.1 μs
Sweep Range	5 μs
Int/Ext	Int
Scan	Midrange
Rep/Man/Ext Input	Rep

Type 284

Square Wave Amplitude	1.0 V
Period	1 μs
Mode	Square Wave Output
Lead Time	75 ns

Connect the Square Wave Output signal of the Type 284 through a 5 ns coaxial cable (Tektronix Part No. 017-0512-00) to the input connector of the Sampling Head installed in the 7S11.

Center the trace on the graticule with the DC OFFSET control and adjust the Trig Level and Stability controls on the 7T11 clockwise for a stable display. The GAIN adjustment is properly set if the amplitude is 5 vertical divisions. If the amplitude is not correct, adjust the GAIN control with a small screwdriver for 5 divisions of vertical deflection.

NOTE

Operating the sampling head without the input connector terminated by a 50 Ω resistor or coaxial cable will cause a few millivolts vertical shift to the zero signal baseline. This occurs because of the strobe kickout signal is reflected from the open input connector. The kickout signal arrives back at the sampling bridge during sampling time, while the bridge is still conducting. To avoid this baseline shift, connect the input circuitry, then set the display zero reference point. Use at least 20 cm of airline between the Type S-1 input and a fast generator (such as a tunnel diode pulse generator) or circuit that is sensitive to the fast Strobe kickout signal.

CONTROLS AND CONNECTORS

A brief description of the function and operation of the controls and connectors of the 7S11 follows. The control setup chart, Fig. 2-2, shows the front panel with an S-series sampling head installed. This figure may be reproduced and used as a test setup record for special applications or procedures, or it may be used as a training aid for familiarization with this instrument.

	DELAY (10 ns RANGE)	Varies the time position of the applied signal in relation to displayed signals from other vertical instruments operating in the same mainframe.
	+UP/INVERT	In the + UP button setting, a posi- tive input signal deflects the CRT beam upward. In the INVERT push button setting, the displayed signal is inverted, a negative signal deflects the CRT beam upward.
284 No. ead	DC OFFSET ±1 V	Applies internal signal offset volt- age of $+1$ to -1 volt to the samp- ling head. The input signal zero reference (related to the CRT) is the DC Offset voltage instead of ground. Permits all portions of a +1-volt input signal to be posi- tioned through the CRT graticule area vertically even at a deflection factor of 2 units per division. Verti-

TYPE 7S11 SAMPLING UNIT SETUP CHART



DATA:

Fig. 2-2. Control Setup Chart.

INT TRIG

OFFSET OUT

X10 10 k Ω

VERT SIG OUT

cal deflection total is 16 mV with a deflection factor of 2 mV/Div. and 1.6 V when the deflection factor is 200 mV/Div. The front panel OFF-SET jack allows accurate slide-back voltage measurements to be made of part or all of a signal at 10X the actual offset voltage applied to the head.

Provides vernier control of the DC FINE Offset function. Concentric with the DC OFFSET ±1 V control.

- Units/Div Selects calibrated deflection factor from 200 units/div to 2 units/div in a 1-2-5 sequence. The units are selected and named on the adjacent S-series sampling head. For example, with a Type S-1 Sampling Head, the Units/Div switch set at 100, each major division of deflection corresponds to 100 millivolts of applied signal at the S-1 input connector when the VARIABLE control is at the (CAL IN) position.
- VARIABLE Provides uncalibrated, variable ver-(CAL IN) tical deflection factor between labeled values of the Units/Div switch. When the VARIABLE control is rotated from the counterclockwise position, displayed amplitude varies from less than 0.5 to more than 2.5 times the calibrated displayed amplitude.
- DOT RESPONSE Permits adjustment of loop gain for optimum dot transient response when the NORMAL/SMOOTH switch is in the NORMAL position.
- Screwdriver adjustment permits cal-GAIN ibration of the vertical output amplifier gain to match the oscilloscope CRT deflection factor.
- NORMAL/SMOOTH Selects unity loop gain at the NOR-MAL push button setting. Reduces the loop gain to 0.3 or less at SMOOTH push button setting. NORMAL provides the correct loop gain required when measuring risetime. SMOOTH reduces the effect of random noise on the display while requiring high sampling dot density for the correct displayed risetime.

Push button selects internal trigger operation between two 7S11's. Internal triggering is canceled when associated time base in the same 7000-series mainframe is switched to external triggering. Lights up when internal triggering is restored.

Unless otherwise specified on the sampling head front-panel, the open circuit voltage at this miniature connector is ten times the internal DC Offset voltage as set by the DC OFFSET control. The output resistance is 10 k Ω .

A facsimile signal (the same Mem-.2 V/DIV 10 kΩ ory output signal that drives the Vertical Amplifier) is available at this miniature connector. The .2 V/DIV label applies only when the VARIABLE control is at its CAL IN position and is limited to about 2.5 V maximum. (The VARIABLE control alters the CRT deflection factor but does not change the signal amplitude fed to the VERT SIG OUT miniature connector.) Output voltage swing is not limited to the magnitude displayed on the CRT. Permits a non-sampling type oscilloscope to monitor the facsimile signal. Output resistance is 10 k Ω .

> Miniature connector provides a convenient front-panel ground point.

BASIC OPERATING INFORMATION

Dual Trace

GND

The dual-trace features of the 7504 Oscilloscope Vertical Mode permits observation of two 7S11 displays simultaneously. This is useful for comparing amplitude, risetime, waveshape, and time relationship of two signals. The sweep can use either 7S11 as the internal trigger source. Be sure to trigger from the 7S11 with the earliest signal event. Use input signal cables with equal delays to preserve the time relationship of the two signals.

The DELAY control adds a variable to the time coincidence of the two signals to accommodate small time difference in cables or sampling heads, so that both signals can be displayed in the correct time relationship.



Fig. 2-3. Dual trace operation.

Dual-trace sampling operation requires two 7S11 Sampling Units, a 7T11 Sampling Sweep Unit, and two S-series sampling heads installed in the 7504 Oscilloscope. As with single-trace operation, the 7T11 must be installed in the A Horiz opening adjacent to the 7S11 for internal triggering connections. The second 7S11 is installed in the Left Vert opening. See Fig. 2-3. Set the controls as follows:

7S11 Sampling Units

DELAY	Midrange
+UP/INVERT	+UP
DC OFFSET and FINE	Midrange
VARIABLE	Pushed in
Units/Div	50
DOT RESPONSE	Unity loop gain
	(Fig. 2-5)
NORMAL/SMOOTH	NORMAL

7T11 Sampling Sweep Unit

Time Position and Fine	Fully clockwise
Slope	+
Trig Level and Stability	For triggered display
Random/Sequential	Random
Trig Amp	X1
Variable	Pushed in
Time/Div	5 µs
Sweep Range	50 µs
Int/Ext	Ext 50 Ω 2 V MAX
Scan	9 o'clock setting
Rep/Man/Ext Input	Rep

Type 284 Pulse Generator

Mode	Pulse Output
Lead Time	75 ns

Set the 7504 Oscilloscope Vertical Mode switch to Chop. Connect the Type 284 Pulse Output signal to the sampling head input connectors through a power divider and two 5 ns coaxial cables. Connect the Type 284 Trigger Output signal to the 7T11 Trig Input connector through a 50 Ω coaxial cable and 3 mm to BNC adapter, supplied with the 7T11.

Adjust the 7T11 Trig Level control for a stable display. Center both traces on the graticule vertically with the DC OFFSET controls. This properly triggered dual-trace display will be similar to Fig. 2-4A.

Time Position. To show DELAY control operation, change the 7T11 Sweep Range switch to 5 μ s and the Time/Div switch 2 ns. Turn the Time Position control counterclockwise to place the rising portion of the pulses on the graticule. Time difference between the two displays should be eliminated by adjusting one or both DELAY controls.

Add

The algebraic addition of two signals can be obtained with the Oscilloscope Vertical Mode switch set in the Add position. The DELAY control can be used to compensate for small time differences between displays before making accurate algebraic addition of the two signals. For accurate algebraic addition, both sampling heads should be same type. Use the same display as described under dual-trace time positioning.

The two signals can be superimposed using the DC OFF-SET and DELAY controls for most accurate time coincidence setting. Set the Oscilloscope Vertical Mode switch to Add. The superimposed signals at dual-trace will be similar to the display of Fig. 2-4B.

Push the INVERT switch on one 7S11. The display shown in Fig. 2-4C is nearly a straight line indicating equal and opposite signal amplitude. Rotate the DELAY control of either 7S11 and notice that any time difference between the two displays will appear as a pulse, either positive or negative depending on the time position relative to the time coincidence.

Dot Response. The loop gain of the sampling unit is changed with adjustment of the DOT RESPONSE control Random process sampling (available with the 7T11) o multiple triggering (with a real-time time-base) are convenient ways to adjust the DOT RESPONSE control to a setting of unity loop gain (each sample responding to the full



Fig. 2-4. Displays of dual-trace (Chop) and Add operation.

signal amplitude). 100 millivolts with the Type 284 Pulse Output signal applied to two inputs through the power divider (keeping the same signal connections as above) would use the Random mode of the 7T11.

Push the +UP switch and the Oscilloscope Vertical Mode switch Left or Right button. Observe the display as the DOT RESPONSE control is rotated clockwise and counterclockwise. A setting of unity loop gain occurs when the random dots do not overshoot or undershoot the display, see Fig. 2-5.



Fig. 2-5. Loop gein adjustment, triple exposure.

Vertical-Horizontal (X-Y)

Two 7S11 Sampling Units operated in the center compartments (Right Vert and A Horiz) of the 7504 Oscilloscope will produce the X-Y display for phase difference calculations. See Fig. 2-6A. Any time-related signals which do not exceed sampling head input specifications may be used at the input connectors.

The 7S11 in the Right Vert compartment controls the vertical deflection and the 7S11 in the A Horiz compartment controls horizontal deflection. Set the Oscilloscope Vertical Mode switch at Right and the Horizontal Mode to A Horiz. To produce a Lissajous figure, apply a sine wave to both input connectors through the power divider and 5 ns coaxial cables. The Type 284 1 ns Sine Wave Output can be used. Set the Units/Div switches at 10 and VARIABLE controls for a 6 division display both vertically and horizontally; the DELAY control of either 7S11 can be used to give a circle display (90° out of phase) or a diagonal straight line (0° or 180° out of phase) for setting the 6 divisions. Set the DELAY control for the diagonal straight line to eliminate phase difference at the 5 ns coaxial cable inputs.

After these adjustments, the system is ready to show accurate phase difference displays over a wide range of frequencies. Connect the signals to the 5 ns coaxial cable in-

puts. Fig. 2-6C shows a method for calculating the phase difference between the two signals.



B. In phase display.



Fig. 2-6. X-Y operation,

Real Time Sampling



Never operate the real-time time-base without the side covers in place because of possible damage to the movable shoe contacts or to parts in the time-base unit.

Real Time Sampling operation uses the three slowest ranges of the 7T11 Sweep Range switch or a real-time timebase unit such as the 7B50, 7B51, 7B70 or 7B71. The 7S11 provides oscillator controlled Strobe Drive pulses to the sampling head, independent of the real-time time-base unit. The repetitive Strobe Drive pulses are turned on when the 7T11 Sweep Range switch is at the 50, 5, and .5 ms ranges or when the time-base unit is a real-time time-base unit. Real time internal triggering is available even when the sampling head does not contain a trigger pickoff circuit. Install the 7S11 and real-time time-base units in the center compartments (or the Left Vert and B Horiz) of the oscilloscope.

The 7504 Oscilloscope Calibrator Output of 1 kHz, Amplitude switch at 0.4 V into 50 Ω may be used as the signal source. Connect the Calibrator Output to the sampling head input connector through a 50 Ω coaxial cable and BNC to GR adapter. Set the Units/Div switch to 100 and the time-base unit Time/Div switch to .5 ms. Obtain a stable display with the Level/Slope control or the Trig Level and Stability controls.

Real time sampling offers DC offset capabilities matched with good overload recovery. Random noise in the display can be reduced through smoothing with the DOT RE-SPONSE control and SMOOTH operation.

NOTE

Type S-5 Sampling Head vertical noise may be reduced for real time sampling by lowering the oscillator frequency by adjusting Rep Rate control (R415), This also will lower the dot density.

Gain Adjustment

The GAIN control (a front-panel screwdriver adjustment) matches the gain of the 7511 vertical output amplifier to the Oscilloscope CRT deflection factor. The gain should be checked and adjusted each time the 7511 is used with a different oscilloscope. A 1% difference is possible between channels.

An accurate voltage source should be used into the input connector of the sampling head. The signal source impedance must be considered when it drives the input of a 50 Ω sampling head.

For 50 Ω input sampling heads, the Tektronix Type 284 (within 0.5% at 10 μ s and 1 μ s), the 50 Ω Amplitude Calibrator within 0.25%, or a precision chopped voltage can be

7S11

DELAY	Midrange
+UP/INVERT	+UP
DC OFFSET and FINE	Midrange
VARIABLE	Pushed in
Units/Div	200
DOT RESPONSE	Midrange
NORMAL/SMOOTH	NORMAL

7T11

Time Position and Fine	Fully clockwise
Slope	+
Trig Level	Triggered display
Stability	Triggered display
Random/Sequential	Sequential
Trig Amp	X1
Variable	Pushed in
Time/Div	.2 μs
Sweep Range	50 μs
Int/Ext	Ext
Scan	9 o'clock position
Rep/Man/Ext Input	Rep

Type 284

Square Wave Amplitude Period	1.0 V 1 μs	Calibrator Volt
Mode	Square Wave Output	
Lead Time	Optional	Rate

used. The Oscilloscope Calibrator output, with an accuracy within 1%, can be used also.

Using the Type 284. Set the controls as follows using the Type 284, accuracy withing 0.5% producing 7S11 deflection factor better than 3.5%, as the signal source to check or adjust the GAIN control of the 7S11 and 50 Ω sampling head:

Connect the Square Wave Output signal from the Type 284 to the sampling head input connector through a coaxial cable. Connect the Trigger Output signal from the Type 284 to the 7T11 Trig Input connector through a coaxial cable and BNC to 3 mm adapter.

Adjust the 7T11 Trig Level control for a stable display. Center the trace on the graticule with the DC OFFSET controls and observe the square wave amplitude. If the amplitude is not 5 vertical divisions, adjust the GAIN control with a small screwdriver for 5 vertical divisions.

Using Oscilloscope Calibrator. Set the controls as follows using the Oscilloscope Calibrator as the signal

7S11

DELAY
+UP/INVERT
DC OFFSET and FINE
VARIÁBLE
Units/Div
DOT RESPONSE
NORMAL/SMOOTH

Midrange +UP Midrange Pushed in 100 Unity loop gain NORMAL

7T11

Time Position and Fine	Fully clockwise
Slope	+
Trig Level	Triggered display
Stability	Triggered display
Random/Sequential	Sequential
Trig Amp	X1
Variable	Pushed in
Time/Div	.5 ms
Sweep Range	50 ms
Int/Ext	Int
Scan	Optional
Rep/Man/Ext Input	Rep

	/504
Calibrator Volts	4 V (0.4 V
	into 50 Ω)
Rate	1 kHz

source to check or adjust the GAIN control of the 7S11 and 50 Ω sampling head. The 1 kHz, 0.4 V output has an accuracy of \pm 1%, producing a 7S11 deflection factor accuracy better than 4%.

Apply the signal from the Oscilloscope Calibrator Volts output connector to the sampling head input connector through a BNC coaxial cable and BNC to GR adapter. Adjust the Trig Level control for a stable display of the square wave. Set the DOT RESPONSE control to unity loop gain (no overshoot or undershoot at the leading front corner).

Center the trace on the graticule with the DC OFFSET controls and observe the amplitude. If the amplitude is not 4 vertical divisions, adjust the GAIN control with a small screwdriver for 4 vertical divisions.

Vertical Signal Output

A composite signal is available at the Vertical Signal Output jack (VERT SIG OUT). This signal is taken after the sampling process and is a proportional representation of the display signal rather than the input signal itself. In real time sampling, the output signal voltage follows the rate of the internal real time oscillator. The open circuit voltage at the jack is 200 millivolts per division of display when the VARIABLE control is pushed in. The output resistance is 10 k Ω . The signal is not affected by the Oscilloscope Vertical Mode switch. The signal is changed by the Units/Div switch, the DC OFFSET controls, and the NORMAL/SMOOTH switches. The INVERT switch does not invert the signal. Output voltage swing is limited to 2.5 volts peak or about 6 divisions above and below the graticule center depending on the actual position. The Units/Div switch is active but the output voltage is always proportional to the CRT display (0.2 V/Div) up to 12 divisions maximum peak to peak. Since the signal at the Vertical Output jack is an equivalent time signal, it is useful for pen recorder applications when the sampling sweep unit external input is driven by the recorder.

The OFFSET OUT monitor jack permits accurate measurement of the DC voltage set by the DC OFFSET controls. The output voltage has a range of +10 to -10 volts. Unless otherwise specified on the sampling head front panel, the monitor jack output voltage is ten times the internal DC offset voltage. The output resistance is 10 k Ω .

BASIC APPLICATIONS

Vertical Deflection Measurements

Vertical displacement of the trace on the CRT is directly proportional to the signal at the sampling head input connector installed in the 7S11. The amount of displacement for a given signal can be selected with the Units/Div switch. To provide sufficient deflection for best resolution, set the Units/Div switch so the display spans a large portion of the graticule. Also, when measuring between points on the display, be sure to measure consistently from either the bottom, middle, or top of the trace. This prevents the width of the trace from affecting the measurements.

To make a vertical deflection difference measurement between two points on the display, proceed as follows:

1. Note the vertical deflection, in graticule divisions, between the two points on the display. Make sure the VARIABLE control is in the CAL position.

NOTE

The vertical deflection factor is determined by the Units/Div switch and the value of the units of measure as stated on the sampling head front panel. The ratio of the input signal to the resultant deflection is called the deflection factor. For example, with the sampling head unit values stated as mV/Div, and the Units/Div switch set to 20, the vertical deflection factor will be 20 mV/division.

2. Multiply the divisions of vertical deflection by the deflection factor, and the external attenuator or probe

attenuation factor (if any). The product is the voltage difference between the two points measured.

For example, suppose you measure 4.4 divisions of deflection between two points on the display and the Units/ Div switch is set for 20 mV/Div. Multiply 20 millivolts/ division by 4.4 divisions, the product is 88 millivolts. This is the voltage difference at the input connector between the two points on the display. Now assume there is a 10X external attenuator (probe) between the input connector and the signal source. To determine the actual signal voltage at the source, multiply 10 (the attenuation factor of the probe) by 88 millivolts; this product (880 millivolts or 0.88 volts) is the actual voltage at the signal source.

It is also possible to measure an instantaneous (or DC) voltage to ground from the display. This measurement is accomplished in the same manner, except that with no signal applied, you must first establish a ground-reference point on the CRT.

NOTE

To establish the ground reference point be sure the input connector is either terminated by a 50 Ω resistor or coaxial cable connected to the input.

To do this, trigger the sampling sweep unit with the signal source and display a trace. Then, position the trace so it is exactly aligned with one of the graticule lines. The actual graticule line you select will be largely determined by the polarity and amplitude of the applied signal. After establishing the ground reference, make no further adjustments with the DC OFFSET control.

Apply the signal and measure the voltage in the manner previously described. Make all measurements from the established ground reference point. Accuracy of this measurement is within $\pm 3\%$.

If the applied signal has a relatively high DC level, the ground-reference point and the actual signal may be so far apart that neither will appear on the CRT. In this case, refer to the following discussion on "Voltage Measurements Using the DC Offset Control."

Voltage Measurements Using the DC OFFSET Control. Unless otherwise stated on the sampling head front panel, the DC offset voltage cancels the effect of an applied DC voltage of up to ± 1 volt at the sampling head input. Also, accurate slideback amplitude measurements of the applied signal can be obtained by positioning the display at various points and measuring the amount of voltage change at the OFFSET OUT monitor jack. Source resistance for the voltage at the OFFSET OUT monitor jack is 10 k Ω ; therefore, meter loading may be a factor if other than an infinite-impedance meter is used. The accuracy of the DC offset voltage measurement depends on the accuracy and the loading effect of the measuring device. The following measuring devices are recommended, in order of preference, for monitoring voltage at the OFFSET jacks.

- (1) Differential, non-loading DC voltmeter accurate within 0.2% or better. This type of device provides absolute offset voltage measurements accurate within 2%. Measurements of small changes in offset voltage can be made more accurately than 2%.
- (2) Vacuum-tube voltmeter with an input impedance of at least 10 megohms. Accuracy of the VTVM should be as high as practical.
- (3) Zero-center ±1 mA milliammeter with as high an accuracy as practical. The milliammeter should be connected directly between the OFFSET OUT monitor jack and ground. When using a milliammeter, 1 milliampere is equivalent to 1 volt of the actual offset voltage. The loading effect is within 2% + the error percentage determined by: 100 (Rmeter/10000).

Slideback Measurement Procedure. To measure the voltage difference between two points on a waveform (such as peak or peak-to-peak volts), proceed as follows:

1. Set the DC OFFSET control to about midrange.

2. Apply the signal to be measured to the sampling head input. Adjust for a stable display with about 7 divisions of vertical deflection between the two points of the signal to be measured.

3. With the DC OFFSET controls, move one of the points to be measured to the center line of the graticule and measure the voltage at the OFFSET OUT monitor jack. Use one of the measuring devices mentioned previously.

4. With the DC OFFSET control, move the display so the other point to be measured is aligned with the centerline of the graticule and again measure the voltage at the OFFSET OUT monitor jack.

5. Find the difference between the voltage measured in step 3 and the voltage measured in step 4, and divide by 10.

The result is the voltage difference, in volts, between the two points on the waveform. This voltage tolerance is $\pm 2\%$ of the input signal plus the tolerance and loading effect of the measuring device.

Use of Smoothing

Random process sampling does not generally permit the use of smoothing. This process requires unity loop gain to construct a coherent display from the samples taken at random. When using random process sampling, operate the 7S11 with the NORMAL switch pushed in, and adjust the DOT RESPONSE control to unity loop gain.

Normal process sampling does permit the use of smoothing. Time and amplitude noise may sometimes be objectionable when operating at minimum deflection factors or maximum sweep rates. For Smoothing operate the 7S11 with the SMOOTH switch pushed in.

This will reduce the random noise by about one half by decreasing the gain of the sampling feedback loop. Fig. 2-7 shows the advantage of using smoothing when observing a low-amplitude signal.

Dot Density. Normally the risetime of the display will not be significantly affected in smoothed operation if the dot density is sufficient. If, however, the display waveform shape is affected when the SMOOTH switch is pushed in, a compromise must be made between smoothing and dot density. Fig. 2-7C illustrates the effect produced when the dot density is low with smoothed operation. This effect can be compared to the high dot density of the same input signal as shown in Fig. 2-7B.

"False" Displays

Because sampling displays only a fraction of any one cycle of a repetitive signal, it is sometimes possible to obtain a false equivalent-time display of the signal. The incorrect equivalent-time display occurs when the sampling rate is an exact multiple of the signal rate. Each sample vertical position represents the correct signal amplitude, but an incorrect number of samples is taken, causing the false equivalent-time display.

False equivalent-time displays can be detected by changing the sampling sweep unit Scan control; i.e., changing the dot density. Occasionally such a false equivalent-time display occurs when the sampling sweep unit triggering circuit is adjusted to free run, and at the same time the triggering signal amplitude synchronizes it falsely. Any time the display equivalent time changes when changing the dot density, alter the Time/Div switch to obtain a display with an equivalent time that does not change with dot density change. Usually the sweep rate should be increased (turn the Time/Div control clockwise), but some false displays can be obtained when the signal repetition rate is slower than can be shown by equivalent-time normal process samp-



Fig. 2-7. Use of NORMAL/SMOOTH switch in sequential process sampling for decreasing display noise when viewing a low amplitude signal.

ling. When that occurs, the display can usually be corrected by changing to real-time sampling. Fig. 2-8 gives an example of a false and a correct display for two sweep rates when the signal is a 500 MHz sine wave.

Time Domain Reflectometry (TDR)

The 7S11 with the Type S-1 Sampling Head can be used for Time Domain Reflectometry displays. TDR using the Type 284 Pulse Generator is described in the Type 284 Instruction Manual. Very fast displays, and special TDR analysis of small reactances is possible with the Type S-4 and the Type S-50. See the Type 1S2 Instruction Manual for information about such fast displays.

Pen Recorder Operation

The signal available at the Vert Sig Out jack provides a convenient source for driving the Y axis of a pen recorder. It is common practice to manually scan the CRT (with the



Fig. 2-8. Typical false and correct displays using a 500 MHz signal input.

Operating Instructions-7S11

Scans by Artekmedia => 2010

sampling sweep plug-in controls) while driving the time axis of the recorder with the sweep output voltage. Another method for pen recording is to couple the scanning voltage of the recorder to the external sweep input connector of the sweep unit. Be sure the sweep voltage from the recorder agrees with the limits of the input to the sampling sweep plug-in. The source resistance of the output jack is 10 k Ω . This impedance must be considered in the calibration of some types of pen recorder amplifiers.

Use of a Sampling Head Extender Cable

Two different sampling head extender cables are available for operating one or both sampling heads outside the 7S11. One is three feet long (Tektronix Part No. 012-0124-00), and the other six feet long (Tektronix Part No. 012-0125-00). Contact your Tektronix Field Engineer or Representative for price and availability information.

Sampling heads can be operated on either length extender cable without compromising system step function response. Loop gain adjustment range may be lost with long extender cables so special calibration of the 7S11 loop gain and memory gate width controls is necessary. See Section 6. Also, the extender cable signal delay must be considered in allowing proper pretrigger leadtime for normal process sampling. As compared to operating the sampling head inside the 7S11 use of a three foot cable adds about 5 ns to the required pretrigger leadtime; use of the six foot extender cable adds about 10 ns. To illustrate the above. assume the following conditions: 7T11 Sequential operation; Type S-1 or S-2 Sampling Head on 3-foot extender cable from the 7S11; and external trigger 50 Ω coupling coaxial cable with 5 ns signal delay. With these conditions, minimum trigger leadtime for a fast step display is 73 ns.

The time coincidence of two 7S11 displays is maintained when one sampling head is installed and the other is on a six foot extender cable by using a DELAY control.

The first time a sampling head is operated on an extender cable, its Bridge Bal control may need adjustment, particularly if DC Offset measurements are to be made accurately referenced to ground. The sampling head instruction manual describes Bridge Bal adjustments. Readjustment of the control may be required when the sampling head is again installed directly into the 7S11.

Input Connectors

The type of sampling head installed in the 7S11 determines the input impedance. Type S-1 and S-2 sampling heads are both 50 Ω input. 50 Ω coaxial cables may be used for applying input signals with minimum signal loss or distortion.

Operating the sampling head without the input connector terminated by the 50 Ω resistor or coaxial cable will cause a vertical shift of the zero signal baseline by a few millivolts. This is because the strobe kickout signal is reflected from the open input connector. It arrives back at the sampling bridge during sampling time, while the bridge is still conducting. Set the display zero reference point with the input circuit connected, not before connecting it. Also use at least a 20 cm airline between the sampling head input and a fast generator or circuit that is sensitive to the fast strobe kickout signal.

When connecting a signal to the input, many factors must be taken into consideration, including loading of the source, losses in coaxial cables, time delay, AC or DC coupling, attenuation of large signals and matching impedances at high frequencies.

Coaxial Cables

Signal cables that connect the vertical signal from the source to a 50 Ω input connector should have a characteristic impedance of 50 ohms. Impedance other than 50 ohms will cause reflections that may make it difficult to interpret the display. High-quality low-loss coaxial cables should be used, especially with high speed sampling heads such as Type S-2 and Type S-4, to ensure that all the information obtained at the source will be delivered to the input. If it is necessary to use cables with characteristic impedance other than 50 ohms, suitable impedance-matching devices will aid in obtaining meaningful displays.

The characteristic impedance, velocity of propagation and nature of signal losses in a coaxial cable are determined by the physical and electrical characteristics of the cable. Common coaxial cables, such as RG-213/U, have losses caused by energy dissipation in the dielectric proportional to the signal frequency. Some small diameter cables (1/8 inch) lose much of the high-frequency information of a fast-rise pulse in a very few feet of cable, while the 3 mm is excellent for low losses.

Losses of high frequency information can be shown with a fast rise pulse generator and sampling system. Using a 5-ns-delay RG-58A/U coaxial cable as a connecting cable, a display similar to Fig. 2-9A can be shown. Adding an additional 10 ns-delay RG-58A/U coaxial cable in the signal path results in a display similar to that of Fig. 2-9B. By using larger diameter, higher quality cable such as RG-213/U (or 3 mm) in the same system, less loss is shown with the same length of connecting cable. Tektronix 7M11 Dual Delay-Line is high quality, low loss cable with dual 50 Ω , 75 ns delay lines.

Attenuating the Input Signal

The maximum signal amplitude that should be applied to the input connector of the sampling head will depend upon the sampling head installed in the 7S11. To attenuate the signals to 50 Ω input sampling heads, use an attenuator probe and/or external coaxial attenuators. The attenuators must have good frequency response beyond the frequency response of the sampling head to avoid reducing system performance. High quality coaxial attenuators are available through your Tektronix Field Office or Representative with attenuation factors such as 10X, 5X and 2X. When the attenuators are stacked, their attenuation factors multiply; i.e., two 10X attenuators produce 100X attenuation. The 50 Ω attenuators must be matched to 50 Ω input and output impedances to provide their stated attenuation factor.



good 50 Ω impedance match, use a power divider such as GR 874 TPD Tektronix Part No. 017-0082-00. The loss between any two of the power divider connectors is 6 dB (half voltage) when each connector has a 50 Ω circuit connected.

To divide a signal into two equal parts, and maintain a

Passive Probes. The Tektronix P6056 10X Probe and the P6057 100X Probe are moderate-resistance passive probes designed for use with 50-ohm systems. They are small in size permitting measurements to be made in minlaturized circuitry. Characteristic data is given in the probe instruction manuals.

The P6056 10X Probe places 500 ohms resistance and less than 0.8 pF capacitance in parallel with the signal source at low frequencies. The probe bandwidth is DC to approximately 3.5 GHz, and risetime is 100 picoseconds or less (10% or 90%). At 1 GHz the input resistance is about 300 ohms and the capacitive reactance is about 400 ohms.

The P6057 100X Probe places $5 \ k\Omega$ resistance and less than 0.7 pF capacitance in parallel with the signal source at low frequencies. Bandwidth of the probe is DC to approximately 1.4 GHz, and risetime is 200 plcoseconds or less (10% to 90%). At 1 GHz the input resistance is about 2 kΩ and the capacitive reactance is about 450 ohms.

Built-in Probes. Another satisfactory method of coupling fractional nanosecond signals from within a circuit is to design the circuit with a built-in 50-ohm output terminal. With this built-in probe, the circuit can be monitored without being disturbed. When the circuit is not being tested, a 50-ohm terminating resistor can be substituted for the test cable. If it is not convenient to build in a permanent 50-ohm test point, an external coupling circuit, which may be considered a probe, can be attached to the circuit.

Several factors must be considered when constructing such a built-in signal probe. A probe is designed to transfer energy from a source to a load, with controlled fidality and attenuation. Both internal and external characteristics affect its operation. It must be able to carry a given energy level, be mechanically adaptable to the measured circuit, and be equally responsive to all frequencies within the limits of the system. The probe must not load the circuit significantly or the display may not present a true representation of the circuit operation. Loading may even disrupt the operation of the circuit. When it is necessary to AC-couple the probe, the capacitor should be placed between the series attenuator resistance and the 50-ohm probe cable to minimize differences between the input

Fig. 2-9. Coaxial cables in a fast-rise system.

8. 15 ns delay cable.



Fig. 2-10. Built-in probes for coupling to a test circuit. (A) Parallel method; (B) series method; (C) reverse-terminated parallel method.

characteristics with and without the capacitor. In a 50-ohm environment, stray capacitance to ground has a shorter and more uniform time constant than if the capacitor were placed at the signal source where the impedance is usually higher and sometimes of unknown value.

Fig. 2-10A shows the parallel method of coupling to a circuit under test. Resistor R_s is connected in series with the 50-ohm input cable to the sampling unit, placing R_s + 50 ohms across the impedance in the circuit. This method usually requires the use of an amplitude correction factor. In order to avoid overloading the circuit, the total resistance of R_s + 50 ohms should not be less than 5 times the impedance of the device (R_L in parallel with Z_0) requiring a 20% correction. The physical position of R_s will affect the fidelity of the coupling.

Fig. 2-10B shows the series method of coupling to a circuit. Resistor $R_{\rm S}$ plus the 50 ohm Sampling Head input resistance replaces the impedance of the circuit under test. If $R_{\rm L}$ is 50 ohms, simply substitute the 50-ohm test cable without $R_{\rm S}$. It is best to locate $R_{\rm S}$ in the original position of $R_{\rm L}$ and to ground the coaxial cable where $R_{\rm L}$ was grounded.

A variation of the parallel method is the reverseterminated network shown in Fig. 2-10C. This system may be used across any impedance up to about 200 ohms. At higher source impedances, circuit loading would require more than 20% correction. The two 100-ohm resistors across the cable input serve to reverse-terminate any small reflections due to connectors, attenuators, etc. The series capacitor, which is optional, blocks any DC component and protects the resistors.

SECTION 3 BASIC SAMPLING PRINCIPLES

Change information, if any, affecting this section will be found at the rear of the manual.

Introduction

This section provides a basic functional description of the vertical channels of sampling oscilloscopes. A discussion of equivalent-time sampling process is included. Operating instructions, including first time operation, are given in Section 2.

BASIC SAMPLING TECHNIQUES

The current state of the electronic art does not permit direct cathode-ray tube display of fractional-nanosecond risetime low-level signals. Risetimes in the order of 0.35 ns can be displayed on a CRT if the signal is at least several volts in amplitude.

An inherent limitation in linear amplifiers is the compromise necessary between bandpass and gain. A high gain amplifier is a low bandpass amplifier; and conversely, wideband amplifiers are necessarily low gain amplifiers. For any particular configuration, gain times bandpass is nearly a constant, so anything done to increase the gain will proportionately reduce the bandpass and vice versa. The gainbandpass product limitation of linear amplifiers restricts the display of millivolt signals on a CRT to the 50 to 200 MHz region.

The sampling technique permits the quantitative display (on a CRT) of a facsimile of fractional-nanosecond rise-time low-level signals. In sampling, many cycles of an input signal are translated into one cycle of low-frequency information. The change takes place at the input of the sampling bridge or traveling wave sampling gate. Since only the sampling bridge is subjected to the input signal high frequencies, and all the amplification takes place at relatively low frequencies, the performance of a sampling system is not dependent on the gain-bandpass limitations of conventional amplifiers.

However, the sampling technique introduces some limitations of its own. The sampling process being described is restricted to repetitive signals of low amplitude (typically 1 or 2 volts peak to peak), from low impedance sources. Fortunately, most fractional-nanosecond risetime signals exist in low impedance environments and are generally low amplitude. Piping the signal from the circuit under test to the input of the sampling oscilloscope vertical channel requires a more sophisticated technique than lower bandpass systems. In spite of its limitations, sampling can measure fast signals that otherwise defy observation.

A sampling system looks at the instantaneous amplitude of a signal during a specific small time period, remembers the amplitude, and displays a single dot on the CRT corresponding to the amplitude. After a dot is displayed for a fixed amount of time, the system again looks at the instantaneous amplitude of a different cycle of the input signal. Each sucessive look, or sample, is at a slightly later time in relation to a fixed point of each signal cycle. Each sample is displayed as a spot on the CRT. Generally, the vertical position of the dot represents the equivalent time when the sample was taken. After many cycles of the input signal, the sampling system has reconstructed and displayed a single facsimile made up of many samples, each sample taken from a different cycle of the input signal.

Fig. 3-1 illustrates the equivalent time reconstruction of a repetitive square wave. The CRT display is a series of dots rather than the conventional oscilloscope continuous presentation. In the illustration, a series of samples is taken of the input signal. After each sample, when memory has been established and stabilized, the CRT is unblanked and a dot appears. A large number of such dots form the display.

The number of dots per horizontal unit of display is called dot density. The dot density of a display is controlled by the operator to provide the best compromise between resolution and repetition rate of the display. Since only one sample is taken from any particular input cycle, the time required to reconstruct a display is a function of the dot density selected and the repetition rate of the signal. The higher the dot density selected (for higher resolution), the longer the time required to construct the equivalent time display. The higher the repetition rate of the signal, the less time required to reconstruct the waveform (limited by a maximum repetition rate of the system).

Sampling requires repetitive input signals, though not necessarily signals with constant repetition rate. The equivalent time between dots is determined by the time delay between the fixed point on the signal at which triggering occurs, and the point at which the sample is taken. Since



Fig. 3-1. Equivalent time display of repetitive real time signal by means of the sampling techniques.

both time reference (triggering-time and sample-time) are taken from the same cycle of the signal, the signal repetitions do not have to be identical in amplitude, time duration, and shape. Any differences in the individual cycles show as noise or jitter in the reconstructed display.

Sampling systems have maximum signal repetition rates at which samples can be taken and accurately displayed. The primary limit is the time required for the preamp and the AC amplifier to stabilize after a sample has been taken.

Signals below 100 kHz may have considerable repetition rate jitter and still the sampling oscilloscope will present a sample of each cycle, without display jitter. For signals with a repetition rate higher than 100 kHz, the timing unit holds off retriggering for a maximum of about 10 μ s. This means that a sample will not be taken from every cycle of a high repetition rate signal. Only those cycles are sampled which occur after the end of the holdoff. If the signal is truly repetitive and each cycle is identical, these "missed" cycles are of little significance.

The circuits in the vertical channel of a Tektronix sampling oscilloscope comprise an error-sampled feedback system with ratchet memory. The memory output is not reset to zero after displaying a dot. The memory output remains at the displayed amplitude of each dot in succession until it is corrected by the next sample. The amplitude difference between the two samples is then the error between the memory output and the new sampled amplitude.



Fig. 3-2. Simplified block diagram of an error-sampled feedback system with a ratchet memory.

Fig. 3-2 shows a simplified block diagram of an errorsampled feedback system with ratchet memory. The output signal from the sampling bridge is the difference, or error, between the instantaneous amplitude of the signal at sample time and the previously memorized amplitude. A change is made to the memory output only when the instantaneous amplitude of the signal at sample time is different from the memory output. The memory output "ratchets" up or down at sample time as a result of the error signal sampled. The transition of memory from one output voltage to another occurs between displayed dots, and is therefore not seen on the CRT.

The error-sampled ratchet-memory technique has the advantage of allowing displayed noise to be "smoothed". Smoothing is discussed later in this section. The errorsampled approach also minimizes signal kickout into the input cable by the sampling bridge interrogate pulse (hereafter called "strobe" pulse). Since the sample is always the difference between the signal and the memory output, the error-signal and kickout are much smaller in amplitude than they would be if the memory output reverted to zero and the entire signal was sampled after each dot.

The output from the sampling bridge at sampling time is about 2% of the difference between the signal voltage and the memory output. The 2% signal is the input to the first amplifier. The output of the amplifier is AC-coupled to a memory gate. The memory gate couples the signal to the memory amplifier during the time it is gated on. The memory amplifier changes the memory feedback voltage to equal the signal voltage at the instant of sampling. These changes in memory output occur while the CRT is blanked, and do not show up in the display. The memory output does not revert to zero, but remains at a fixed voltage until corrected by the next error signal. (The signal to the amplifier of a typical sampling system is only about 2% of the error signal sampled by the bridge. The percentage of response, or attenuation through the sampling bridge, is the sampling efficiency).



Fig. 3-3. Simplified representation of an error-sampled ratchet-memory waveform.



Fig. 3-4. Simplified diagram, showing how the strobe pulse causes the sampling bridge to conduct.

At each sample time, the difference between the memory feedback and the 2% signal value is amplified and applied to the memory circuit via the memory gate, to cause the memory output to follow a rising signal in a series of steps as shown in Fig. 3-3. This figure shows the input signal and memory feedback voltages for six samples along the rise of a step waveform.

At the time of sample 1, the input signal and the feedback voltage are equal. There is no error voltage, so the memory output is not changed. The CRT is blanked until the circuit stabilizes after the memory gate pulse ends.

At the time of sample 2, the input signal is (for example) 0.1 volt. The memory output is 0. Assuming a sampling efficiency of 10%, the input of the amplifier receives 10% of the error signal, or 0.01 volt. The 0.01 volt, times the gain of the amplifier (X10), corrects the memory output and feedback to equal the 0.1 volt signal at sample time. Again, the CRT is blanked during this change until the circuit is stabilized.

At the time of sample 3, the difference between the input signal and the feedback is 0.35 volt. The amplifier input responds to 10% of 0.035 volt. The gain of the amplifier and memory changes the feedback 0.35 volt to the new value of 0.45 volt (equal to the signal at number three sampling time). The CRT is again blanked during this change until the circuit is stabilized.

Effective Sampling Time

The minimum risetime a sampling system can display is controlled by the time interval during which the strobe pulse applies forward bias to the sampling bridge diodes. The duration of the bridge forward bias is controlled by the time the strobe pulse exceeds a fixed reverse bias. Special circuitry is used to make the strobe duration as short as possible consistent with noise and diode recovery time. The strobe pulse is generated by a snap-off diode and a short section of shorted transmission line called a clipping line. The effective bridge conduction time is adjusted primarily by controlling the amplitude and duration of the strobe pulse, thus controlling the time during which the strobe



Fig. 3-5. Error-signal source and path to Preamp shown by dotted lines. DIEL denotes dielectric other than air.

pulse exceeds the reverse bias. Adjusting the reverse bias is a secondary means of controlling the sampling bridge conduction time. Fig. 3-4 shows how the strobe pulse breaks through the reverse bias on the sampling bridge. The reverse bias is shown by dashed lines through the strobe pulses.

Traveling Wave Sampling Gate

The sampling system may use a traveling wave gate instead of the sampling bridge as the input stage. Fig. 3-5 shows a simplified schematic of the traveling wave sampling gate. The input signal is connected to the Preamplifier only during the time a sample is taken. The six diodes form the traveling wave gate.

Step response is determined by the travel time of the strobe drive pulse end through part of the sampling gate. In a sampling bridge, the step response is determined by the strobe pulse width.

Part of the input signal is stored temporarily between sampling gate diodes at the strobe pulse end; then it is fed to the Preamplifier at a slower rate than the step response risetime. The environment is controlled in the input and traveling wave sampling gate to minimize reflections of fast pulse signals. The environment of following circuitry passes only moderate rate-of-rise signals.

Dot Response (Loop Gain)

Dot response is the ability of the system to reduce the error voltage to zero after each sample. When the gain of the memory feedback loop is equal to (and compensates for) the attenuation across the sampling bridge, the loop gain is unity or 1. In this case, the memory feedback voltage equals the value of sampling time signal voltage.

If the loop gain is less than unity, the memory output signal and feedback to the first amplifier is less than necessary to reduce the error voltage to zero. The memory output and the feedback will then approach the signal asymptotically after several samples have been taken. The error voltage thus approaches zero (for a steady state signal) after several samples, being reduced by the same factor after each sample. In the case of a loop gain of less than unity, the feedback voltage is effectively a moving average of several preceding samples.

If the loop gain is greater than unity, the feedback voltage will be greater than the error signal after each sample. The displayed dot sequence of a step signal will then alternately overshoot and undershoot for a few samples.

For least displayed waveform distortion, the loop gain must be unity, allowing the system to track the input signal as closely as possible.

Smoothing

A loop gain of less than unity can be useful, if the resulting compromise is understood and the system is operated properly. Random noise in the display is reduced when loop gain is less than unity, since several consecutive samples are averaged. The averaging may also slow down the fastest display risetime capability, depending upon the number of dots contained in the step transition and or the loop gain. By increasing the number of dots in a step transition, the display will follow the actual step transition more closely.

Fig. 3-6 shows the usual effects on a step display when smoothing is used for two different sampling densities (sampling density or dot density is the number of samples or dots per horizontal division). In the 7S11 the operational choice of loop gain is either 1.0 (NORMAL) or 0.3 (SMOOTH). In Fig. 3-6A the actual risetime (between the 10% and 90% points) for unity loop gain displays 4 dots. When operating at 0.3 loop gain, 7 dots are shown. There is a significant difference between the 0.3 loop gain (SMOOTH) and the unity loop gain (NORMAL) displays.

In Fig. 3-6B the sampling density is increased, showing a difference of one sample in the SMOOTH and NORMAL positions between the 10% and 90% points of the step transition.



Fig. 3-6. Equivalent-time display with and without smoothing for two different sampling densities.

When the smoothed mode has a loop gain of 0.3, as in the 7S11, 15 or more samples between the 10% and 90% points of a risetime will result in the smoothed and unsmoothed displays having essentially the same risetime. When the smoothed display contains 12 samples between the 10% and 90% point, the smoothed risetime will be about 6% longer than for the unsmoothed display. As the number of samples contained in the risetime is reduced below 12, the difference between smoothed and unsmoothed display increases rapidly.

Smoothing Of Random Noise

When the loop gain is reduced to 0.3, the displayed dots represent the average of several consecutive samples. Noise of a random nature will be materially reduced in the display at the possible expense of introducing an error in the displayed risetime. Therefore, if random noise is apparent, reducing the loop gain may improve the display. Note that this is only true for random noise. Systematic noise (noise with its repetition rate harmonically related to the signal) is treated as part of the signal.

The 7S11 has a loop gain control labeled NORMAL-SMOOTH. In the SMOOTH mode, loop gain is reduced to 0.3. Always check that there is sufficient sampling density to warrant smoothing. This can be done by changing the dots/division, (or samples/division) control on the timing unit, and observing the effect of sampling density on the displayed risetime.

Smoothing cannot be applied where the full amplitude of each sample is required. When using the random sampling sweep unit like the 7T11, each sample requires unity loop gain. The display dots are not presented in time sequence, and therefore cannot be averaged.

Tangential Noise

Traditionally the amplitude of random noise in an amplifier is gualified by stating the equivalent RMS value of the noise referred to the input of the amplifier. In the case of a CRT sampling display, qualifying the noise amplitude by stating its RMS value is somewhat unsatisfactory. The visible effect of the random noise is more nearly 3 times the RMS value of the noise. Peak-to-peak limits of truly random noise would have to be stated as - infinity to + infinity. Obviously these broad limits would reveal nothing about the amount of significant noise to expect in a display. It has been determined empirically that 90% of the dispersion caused by random noise closely approximates the visible widening of the trace. The noise can be described as existing between two horizontal tangents representing the significant upper and lower limits of the trace width. Hence, the term TANGENTIAL NOISE. Tangential noise is defined as an equivalent peak-to-peak voltage at the input of a sampling system that will cause the same trace widening as 90% of the random noise. 5% of the dots can be expected to fall above the trace width and 5% below it. This method of stating the noise figure of a sampling system is considered to be more meaningful than the RMS value, in that it more closely approximates the actual observed trace widening. Measurement of tangential noise is described in the Sampling Head instruction manual.

Display Sensitivity–Deflection Factor

The two terms "display sensitivity" and "deflection factor" are often mistakenly interchanged. Deflection factor is defined as the ratio of the input signal amplitude to the resultant displacement of the indicating spot. When the oscilloscope vertical gain control is calibrated in volts per division, it is indicating deflection factor. Deflection sensitivity is the reciprocal of deflection factor. Sensitivity is indicated by a vertical gain control calibrated in divisions per volt.

There is always some point within the oscilloscope vertical amplifier after which the signal remains at a fixed deflection factor. The signal out of the vertical memory amplifier of a sampling oscilloscope is usually the first point at which the standard vertical deflection signal exists. Thus, the memory and feedback voltages previously mentioned always deflect the CRT spot vertically with a fixed deflection factor.

Fig. 3-7A shows a simplified block diagram of a sampling bridge and amplifier combination where the gain of the amplifier just compensates for the attenuation of the sampling bridge. In Fig. 3-7B the amplifier has twice as much gain as is necessary to compensate for the low sampling efficiency. By introducing a 2:1 attenuator in the feedback path between the memory output and the bridge output, the dot response is still maintained at unity. Now, only half as much input signal produces the same memory output as in Fig. 3-7A.

Fig. 3-7 shows two fixed attenuators in each example. The usual method of changing amplifier and memory gain in a sampling unit is to attenuate the signal through (or to) it. The attenuator in series with the amplifier and memory is called the forward attenuator, in contrast to the feedback attenuator.

The attenuators in Fig. 3-7 and Fig. 3-8 show that both the "forward gain" and the "feedback attenuator" are altered when changing a sampling system vertical deflection factor.

The system deflection factor can be altered two ways: (1) by changing both the forward and the feedback attenuation and thereby maintaining the same loop gain, and (2) by changing only the feedback attenuation, at the expense of varying the loop gain. If loop gain is not greater than unity, and many samples are included in a signal transition, the memory feedback to the sampling bridge always approaches the signal amplitude regardless of the forward attenuator attenuation ratio.

Since loop gain is determined by the combined forward and feedback attenuation ratios, the dot response can be altered without altering the deflection factor by changing the forward attenuation only. Increasing the forward attenuation ratio (decreasing the amplifier and memory gain) "smooths" the display by making the loop gain less than unity.

DC Offset

Since the sampling bridge can be operated over a range of +2 to -2 volts of input signal, and the system has resolution capability of 2 mV/div, it is advantageous to be able to display a small vertical "window" of the input signal. Fig. 3-8 shows the method of adding a DC offset voltage to the memory feedback. The error signal produced at sampling time is no longer referenced to ground. Instead, it is referenced to the DC offset voltage.

A DC Offset voltage is recognized as a signal by the sampling bridge, which adds it algebraically to the error signal. Therefore, the memory feedback signal in a system with DC Offset includes a DC value to cancel the DC Offset voltage at the output side of the sampling bridge. The deflection factor of a system with DC Offset is centered around the DC Offset voltage instead of ground. This permits portions of the signal (other than ground) to be positioned to the CRT center, without altering the deflection factor.



Fig. 3-7. Method of decreasing the vertical deflection factor while maintaining unity loop gain.

Real-Time Sampling

Real-time sampling is a method of operation in which the samples are taken at a constant rate from relatively low frequency signals (DC to 20 kHz approximately) and displayed at a sweep rate determined by the Time/Div switch on the time-base unit. Thus, the samples are taken continuously along the input signal rather than taking one sample from each cycle of the signal. The displayed series of dots follows the actual shape of the input signal waveform.

In real-time sampling operation, the vertical signal provides the trigger to start the sweep. The display, however, is composed of samples at a fixed repetition rate, not necessarily related to the input frequency.

Sweep Rates

The range of sweep rates available for use in real-time sampling is from the slowest rate provided by the real-time sweep unit to about 0.1 ms/div. At this sweep rate, the usual 50 kHz sampling rate provides about 100 samples/ sweep. At faster sweep rates above 0.1 ms/div, the display dots begin to have significant horizontal dimension due to their duration in real time, and interpretation of the display becomes difficult.

The characteristics of real-time sampling, in addition to slow sweeps at full bandwidth, are reduction of random noise in the display through smoothing, and DC offset capability matched with good overload recovery.



Fig. 3-8. Method of adding a DC Offset voltage to the memory feedback.

SECTION 4 CIRCUIT DESCRIPTION

Change information, if any, affecting this section will be found at the rear of the manual.

Introduction

This section of the manual contains a block diagram description and a circuit description of the 7S11 Sampling Unit. The block diagram description is an expansion of Section 3, Basic Sampling Principles. The circuit description follows the sequence of diagrams at the back of this manual.

BLOCK DIAGRAM

Refer to Fig. 4-1 and the complete block diagram at the back of the manual during the following description. Both Fig. 4-1 and the complete block diagram include a simplified block of a typical sampling head. The 7S11 Sampling Unit functions as part of a sampling system only when a sampling head is installed, so a sampling head block is included.

Feedback Loop and Pulse Amplifier Chain

Fig. 4-1 relates to Fig. 3-4 and Fig. 3-8. The reconstructed signal out of the Memory block (Fig. 4-1) is the first point in the 7S11 at which the amplitude is always a standard value of 0.5 volt per CRT vertical division. There is no signal between the sampling head output and the Memory input when the sampling head input signal is not changing. The Post Amplifier, AC Amplifier and Memory are part of a pulse amplifier chain that amplifies the sampling head output signal just after each sample is taken. Signals through the amplifier chain are greatest in amplitude when the sampled signal is at its full amplitude difference from the last sample. This is called the error signal.

To complete the association of Fig. 4-1 with Section 3, the following describes the operating cycle:

a. The sampling head bridge applies an error signal to the head preamp whenever there is a voltage difference at the bridge input and output terminals at sampling time. The error-signal voltage amplitude is just a few per cent of the difference (sampling efficiency), and the pulse duration out of the bridge is equal to the bridge conduction time. A small storage capacitance at the head Preamp input timestretches the pulse so the pulse chain can amplify the error signal pulses at moderate rates of rise. b. The time-stretched pulse is amplified by the 7S11 Post Amplifier and sent forward into the attenuating network made up the NORMAL/SMOOTH switch, the DOT RESPONSE control and the Forward Attenuator portion of the Units/Div switch.

c. The AC Amplifier again amplifies the pulse and applies it to the Memory circuit during conduction time of the Memory Gate. In effect, the error signal charge applied to the head Preamp is then transferred to the feedback capacitor of the Memory circuit.

d. The Memory circuit applies its error signal corrected output voltage to both the vertical amplifier and the feedback attenuator and sampling head bridge output terminal. Control of the input deflection factor by the Forward and Feedback Attenuators is described near the end of Section 3. The DOT RESPONSE control is also described in Section 3.

Vertical Output Amplifier

The INVERT/+UP switch and the Vertical Output Amplifier drive the oscilloscope vertical amplifier stage.

Sweep Unit Drive

Drive from the timing unit is applied to the sampling head avalanche and snap-off and the Memory Gate Driver. The timing unit controls the free running oscillator used in the 7S11.

Sampling Operation. The 7S11 is a single-channel sampling unit when used with a 7T11 or other sampling sweep unit in a 7000-series oscilloscope.

For dual-channel operation, another 7S11 must be installed in the adjacent vertical compartment of the oscilloscope. Interconnection between the two 7S11's and the sampling sweep unit are made by connecting-shoes on the plug-ins. These interconnections combine the Trigger Logic circuits of the two 7S11's into a bistable multivibrator, and complete the other connections necessary to provide amplification of internally-generated triggers. For external trigger operation, the sampling sweep Internal



Circuit Description-7S11

Fig. 4-1. The 7S11 and sampling head feedback loop block diagram

Scans by ArtekMedia => 2010

4-2

۲
Mode trigger amplifiers and the bistable multivibrator are disabled.

Non-Sampling Operation. When the 7S11 is used for dual-channel real time operation in company with a nonsampling time base unit, no sampling drive pulse is available, nor is a ground provided for the Real Time Oscillator and Trigger Logic multivibrator. The Real Time Oscillator will oscillate at the specified frequency and drive the Memory Gate Driver and the CRT blanking circuit. Internal trigger is obtained from the Real Time Trigger block. The operational differences between the two types of time bases are explained in the Operating Instructions, Section 2.

Readout Logic

The Readout logic in the 7S11 provides the necessary time-slot current to operate the Scale Factor readout on the indicator oscilloscope. Currents supplied from the 7S11 control the display of decimal magnitude, Normal/Invert, Normal/Uncal, 1-2-5 Scaling and the symbols m, μ , V and I. The indicator oscilloscope manual includes the details of Scale Factor Readout operation.

CIRCUIT DESCRIPTION

The following circuit description follows the sequence of the diagrams in Section 9.

Trigger Logic

The Trigger Logic circuit (see Post Amplifier and Attenuators circuit diagram) consists of Q108, Q113, Q116 and associated components. The circuit sets the level for forward bias of the timing unit trigger amplifier so that the trigger is passed from the sampling head to the timing unit (see Fig. 4-2A). The Internal setting of the timing unit trigger switch grounds the base of Q113 through R109, and the collector of Q108 through R108-R109. Q108 is reverse biased by current through R102 and CR108 to clamp the base at +15.6 volts. CR113 is off and Q113 is forward biased by the current through R111 and R109. Conduction causes Q113 collector to be more positive than the cathode of CR116 so that both CR116 and CR115 are off. Q116 supplies current to the lamp, DS116, indicating that this 7S11 is supplying the internal trigger to the timing unit. R115 sets the base current for Q116.

Setting the trigger switch in the timing unit to EXT removes the ground from R109, which turns on CR113 and clamps Q113 base at +5.6 volts, a reverse bias. Q108 remains at reverse bias as with Internal trigger operation. CR115 clamps Q116 base at -0.6 volt so Q116 is off and the INT TRIG lamp is off. CR116 is on, reverse biasing the timing unit transistor, so no trigger signal from the sampling head can trigger the timing unit.

Two 7S11 units operated together will complete the bistable multivibrator shown in Fig. 4-2B. Selection of the desired 7S11 as the Internal trigger source is done through the turning off of Q108 in that unit. The Internal setting of the trigger switch in the timing unit provides ground to both halves of the bistable multivibrator. Pushing the INT TRIG switch momentarily places a positive trigger on Q108 (in the desired 7S11), puts reverse bias between base and emitter, and turns on CR108, which clamps Q108 base at +15.6 volts. The positive trigger is applied to Q108 collector in the second 7S11, which turns that Q108 on, adding current through R109 to the current through R111 and R109 to clamp Q113 base at +5.6 volts through CR113. Operation of the Off 7S11 is the same as discussed for External trigger operation with a single 7S11. The On 7S11 operates similar to a single 7S11 in Internal trigger operation.

Switching the timing unit trigger switch to one of the EXT positions removes the ground from the R109 common point. The R109 common point rises to +5.6 volts, the clamped voltage at the bases of the Q113's, so the multivibrator remains in the state in which it was set. The multivibrator remains in the state in which it was set when the timing unit trigger mode is again placed at Internal unless the other 7S11 INT TRIG button is pushed.

Post Amplifier and Attenuators

The Post Amplifier and Attenuators diagram includes the Post Amplifier, Forward and Feedback attenuators, DC Offset, and the Trigger Logic.

The Post Amplifier is a two-stage non-inverting operational amplifier with AC coupled complementary emitter followers between the second stage and the output. The input impedance is 90.9 Ω , which properly terminates the coaxial cable feed from the sampling head. Output impedance is very low to provide signal current to the 500 Ω Forward Attenuator. Total AC gain is approximately 12, producing a 2.4 volt output signal for a 0.2 volt input signal. DC gain is essentially unity and feedback keeps the amplifier within its proper dynamic range.

Q123 and Q128 are the amplifier transistors, and Q133 and Q136 are the output emitter followers. Q133 ensures low output impedance for positive output signals, and Q136 ensures low output impedance for negative output signals. Each emitter follower has a resistor in the collector for parasitic oscillation suppression. C134 permits the output emitters to be at different DC voltages and ensures that the emitter of the non-driving transistor follows the output voltage.

Output of the Post Amplifier is AC coupled to the NORMAL/SMOOTH switch, DOT RESPONSE control and the Forward Attenuator (part of the Units/Div switch).

Circuit Description-7S11





The Forward Attenuation Network consists of the NORMAL/SMOOTH switch, the DOT RESPONSE control, and the Forward Attenuator portion of the Units/Div switch.

Pushing the SMOOTH switch introduces R141 in series with the Post Amplifier output signal, reducing the loop gain to 0.3 or less compared to loop gain in the NORMAL setting. R142 maintains a constant 500 Ω load on the output stage for time constant and amplitude considerations.

The Forward Attenuator, made up of resistors R145A through R145G, presents a constant 500 Ω load to the driving side. The input resistance to the AC Amplifier is changed by the forward attenuator from 1 k Ω to 100 k Ω in seven steps. Six of the seven resistors are always in parallel connection to ground, with the seventh in series with the signal to the AC Amplifier input. Signal pulse amplitude across the forward attenuator input resistance (500 Ω to ground) does not change when the Units/Div switch position is changed. Attenuation occurs because of a changing current drive into the low impedance of the operational AC



Fig. 4-3. Forward Attenuation network, showing that the output resistor of the Units/Div Forward Attenuator is actually the AC Amplifier input resistor.

Amplifier. Fig. 4-3 shows the full forward attenuator network and identifies the AC Amplifier input terminal.

The AC Amplifier gain is controlled by the ratio of feedback resistor R209 to the value of the series element of R145. The gain changes from 15 at 2 units/div to 0.15 at 200 units/div.

The Forward Attenuator portion of the Units/Div switch is ganged with the Feedback Attenuator portion. The result is that changing the Units/Div switch does not change the dot response (or loop gain). Changing either the NORMAL/SMOOTH switch or the DOT RESPONSE control changes the forward signal, and thus changes the loop gain.

The Feedback Attenuator and the DC Offset are connected together within the sampling head where they are combined and applied to the Sampling Bridge output terminals. The Feedback Attenuator receives the Memory circuit output signal from a very low impedance. The attenuator places one of seven resistors in series with the Memory output signal, and the other six resistors are paralleled to ground as slightly more than 2000 Ω . Maximum attenuation (at 2 Units/Div) allows 0.42% of the Memory signal to pass to the Sampling Bridge circuit. Minimum attenuation (at 200 Units/Div) allows 42% of the Memory signal to pass to the Sampling Bridge Circuit. The attenuation of 0.42% and 42% is corrected to exactly 0.40% and 40% by the parallel value of R147, R149 and the 53 k Ω to ground inside the sampling head. (The Forward Attenuator ratio or AC Amplifier gain ratio of 100:1, and the feedback attenuator ratio of 1:100 ensure that the loop gain is not altered throughout the Units/Div switch range).

The DC Offset Circuit is a single transistor emitter follower that converts the fairly high resistance of the DC OFFSET control to a fairly low resistance at the emitter. Q163 emitter voltage follows the voltage of the arm of the DC OFFSET control, offset by -0.6 volt. Q163 drives a 22.4 k Ω resistive load, consisting of Q163 output resistance, R165 (19.1 k Ω) and 2000 Ω of the Feedback Attenuator. Thus the DC OFFSET voltage at Q163 emitter develops a fixed voltage across the Feedback Attenuator 2000 Ω regardless of the Units/Div switch setting.

Memory

The memory diagram includes the AC Amplifier, the Memory Gate, and the Memory Amplifier.

The AC Amplifier (whose gain is described above with the Forward Attenuation Network) is an inverting operational amplifier with AC coupled complementary emitter followers at the output. Q204 is the voltage amplifier, Q208 emitter follower adds current gain to Q204 collector signal, and Q212-Q214 provide the very low output resistance.

The amplifier input is AC coupled by C201 to permit the amplifier DC operating voltages to be independent of the changes made in input resistance by the Units/Div switch. Q204 base is the summing input terminal of the operational amplifier. As a signal arrives and changes the



Fig. 4-4. Basic Memory Gate circuit between AC Amplifier and Memory Amplifier. (Detailed block of Memory diagram.)

base voltage, the collector voltage changes in the opposite direction and Q208 emitter drives current of the opposite polarity through R209 back to the Q204 base. The input and feedback signal currents are nearly equal, keeping the base voltage almost constant. The output signal is coupled to the Memory Gate by Q212, Q214 and R219-C219. R219 limits the signal output current, ensuring that C219 does not receive a significant charge for output signals of high pulse amplitude.

CR201 and CR206 provide protection when transistors are removed from their sockets. CR201 conducts if Q208 is removed, and CR206 conducts if Q204 is removed. Parasitic suppressing resistors include R206, R207, R211, R213 and R214.

The Memory Gate is a special pulse-driven diode gate that ensures a very high input resistance to the Memory except for about 0.15 to 0.20 μ s at the time of each sample. During the conduction time, the Memory Gate is a low impedance that allows the AC amplifier to introduce a charge into the Memory.

Fig. 4-4 is a detailed block diagram of the circuits on the Memory diagram. The Memory Gate is represented by a resistor, a coil and a relay switch. The resistor is the parallel value of the four biasing resistors which ensure that the four gating diodes are normally not conducting. This equivalent circuit shows that the Memory input is zero volts when there is no error signal at sample time.

Looking from the Memory Gate output toward its input, the four gating diodes are normally reverse biased by the

voltage of Zener diode VR221. (Two of the four diodes provide very high reverse biased leakage resistance, although they don't turn off very fast. The other two turn off fast at the end of the gating pulse, although they don't provide high resistance when reverse biased). VR221 voltage is balanced to ground by R224 and R226 so CR236 cathode rests at +2.5 volts and CR238 anode rests at -2.5 volts. C221 ensures that the AC Amplifier output signal drives both sides of the memory gate diodes.

The gate diodes are forward biased into conduction by T230 at the time of each sample due to the drive pulse from the Memory Gate Driver. T230 is a toroidal transformer specially wound to balance capacitive and inductive coupling to the two secondary windings. The winding with only one end connected provides the capacitive balance. The magnetic toroid core provides the inductive balance. Thus, the drive pulse is converted to identical drive signals to ensure that the output junction of the four diodes accurately divides the 5 volts of VR221-C221. This places the junction of CR237-CR239 at ground when no error signal is applied from the AC Amplifier. The functions of the two limiting diodes CR224-CR226 and the Memory Gate are discussed in the Memory description next. R229, R231 and CR232 are shunt, damping loads to T230 which minimize self-inductance ringing when the memory gate drive pulse ends.

The Memory amplifier is an integrating operational amplifier with special low leakage (high DC resistance) input circuit. The input and feedback components are capacitors, making the AC input impedance very low. The internal high gain ensures a very low output resistance; so that as long as there is no change at the input, the output DC voltage remains stable. The input low leakage circuit has no DC connection to ground except during the time the Memory Gate conducts.

The Memory amplifier is specially decoupled from the power supplies because the output stage (Q262 and Q266) can require a current pulse as great as 30 mA for a 20 volt output change at sample time. The decoupling networks are R261-C261 and R267-C267. L268 in the VERT SIG OUT and feedback lead presents a high impedance to the Memory output for high frequency (fast change) signals. The inductor ensures that the output amplifier does not have to provide high current to the output load. L268 slows the output signal response, but at a time when the CRT is blanked.

A dual junction FET (Q242) is the input stage. It is biased for essentially no leakage at the input gate, and the stage has high voltage gain at the in-phase output drain lead. Any voltage change at the left Q242 gate lead is amplified and applied to the inverting amplifier Q256. Q256 collector circuit applies proper bias to both bases of the output complementary emitter follower pair, Q262-Q266 and restores the DC level negatively so a zero input signal (at the left side of Q242) is also a zero output signal. Q256 collector and Q262-Q266 output lead operate linearly through the range of +10 to -10 volts.

Because of the high open-loop gain, the Memory Amplifier does not have the fast risetime that the prior amplifiers have. The AC Amplifier output pulse duration is shorter than the Memory Amplifier risetime. C239 at O242 input gate lead accepts some of the charge from the AC Amplifier, stores it until the Memory amplifier can respond, and then loses the charge again due to feedback current.

A cycle of operation at sample time takes the following sequence:

a. The Memory Gate drive pulse arrives at essentially the same time the Sampling Bridge is strobed into conduction. The CRT is blanked during this same time. Propagation delay through the three AC coupled amplifiers is quite short. (The fact that the Memory amplifier input is always at zero volts, and the Memory Gate is balanced around zero volts, prevents any false changes in C275-C276 charge. Therefore, there is nc change in the Memory amplifier output voltage during the time the Memory Gate conducts ahead of the arrival of the AC Amplifier output signal).

b. The AC Amplifier applies a pulse signal through R219-C219 and the Memory Gate to the Memory amplifier input. C239 accepts some of the charge until the amplifier begins to respond, driving an equal and opposite current back to the input through the feedback capacitors.

c. Since the AC Amplifier output signal is applied to the Memory Amplifier "virtual signal ground" input, C219 receives about 10% of the total error signal charge before the Memory Gate stops conducting. Thus, as the AC Amplifier output returns to its quiescent voltage, the output side of C219 overshoots. The 743 Ω of the Memory Gate discharges C219 well in advance of the next error signal.

If the 7S11 is displaying a single transition step over the full graticule with the display starting at the lower left and ending at the upper right, the error signal is very large during retrace. Such large error signals (even during random process sampling) apply a significant charge to C219. In this case, the overshoot at the end of the error signal pulse is large enough to cause one side of the Memory Gate to conduct and remove some of the intended charge in the feedback capacitors. Two normally non-conducting clamp diodes prevent such undesired removal of memory charge. CR224 and CR226 help to discharge C219 if it receives too great a charge during the Memory Gate conduction time, thus preventing false amplitude displays. These two diodes do not conduct at any other time.

d. As the Memory Gate drive pulse ends, C239 charge is removed by the Memory amplifier feedback. This causes the Memory output voltage to continue changing toward proper amplitude for a short period of time after the Memory Gate stops conducting. As soon as C239 is returned to normal, the output voltage remains fixed until the next sample.

The actual resting voltage at the left Q242 gate may not be precisely zero, but it is within a few millivolts of zero. Any deviation from zero can be due to several things: slight differences in conduction of the Memory Gating diodes; slight differences in resistance of the four Memory Gate biasing resistors; some small error signal being generated at each sample time even when the sampling head input signal is zero. Q242 right gate voltage is adjusted over a small range to allow the above-normal variations. Adjustment of the right Q242 gate voltage is called the Smoothing Balance adjustment, because it is set so there is no change in Memory amplifier output when the forward attenuation is changed. The forward attenuation is changed by pushing either the NORMAL or SMOOTH switch. Whatever small zero-input error signal may exist in the system, it always has an average value that will not alter the memory stored charge. Changing the forward attenuation changes the peak amplitude of the residual error signal, but not its average voltage zero value. Therefore, Q242 gate voltage is adjusted to equal the average voltage zero value of the residual error signal, and the trace does not move when the NORMAL or SMOOTH switch is pushed.

Memory output voltage limits of about +10 and -10 are set by two diodes in parallel with the feedback capacitors.

The diodes, CR272 and CR274, are reverse biased by 9 volts each. If the output tries to go more positive than about +10 volts, CR274 conducts (9 + 0.6 = 9.6 volts) reducing the amplifier gain to much less than 1. If the output tries to go more negative than about -10 volts, CR272 conducts, reducing the amplifier gain to much less than 1. The clamping diodes prevent the amplifier transistors from saturating at the time of an overdrive signal, and thus ensure fast transition away from the clamped voltage at the next sample.

CR242 conducts only when Q242 is removed from the socket while the power is on, thus keeping -50 volts off the source leads when Q242 is plugged in. Temperature compensation of the amplifier is accomplished effectively by the source-coupled FET input amplifier and CR257 and CR259. Q252 is an active load for Q242. This active load causes the signal current to the base of Q256 to be about twice the signal current out of the drain of Q242 right. Q252 also serves to speed up the circuit response time. The two identical halves of Q242 compensate each other so their total current does not change with temperature change. CR257 and CR259 have junction-drop temperature coefficients similar to Q262 and Q266 base-emitter junctions, and thus stabilize the output circuit.

The Memory amplifier drives the front panel vertical output jack through a resistive attenuator that delivers 40% of the memory signal through 10 k Ω . The jack is labeled VERT SIG OUT, 0.2 V/DIV, 10 k Ω . The memory output signal is the standard deflection signal mentioned in Section 3, and is 0.5 volt/CRT division. The Memory drives the Vertical Output through the Invert switch.

NOTE

The Memory output limits of ± 10 volts at 0.5 V/div equals 40 CRT divisions of display area, required when operating at high sensitivity and many divisions of DC OFFSET. The whole pulse amplifier chain is designed for full response and fast recovery so that on-screen displays have accurate deflection factors and DC offset reference. Such operation provides accurate signals at the front panel Vert Output jack, even though much of the signal is not displayed on the CRT.

Output Amplifier

The Output Amplifier diagram includes the Vertical Output and the Real Time Trigger.

The Vertical Output amplifier follows the Invert switch, INVERT/+UP which sets the signal path from the Memory circuit. The Vertical Output amplifier consists of a twostage push-pull balanced circuit. The first stage includes the VARIABLE gain control and the Position adjustment in the common emitter circuit of Q314 and Q334. The Position adjustment changes the current through each side of the push-pull circuit for a center-screen output voltage. Gain of the stage is controlled by the VARIABLE control. Maximum gain occurs with minimum resistance between the two emitters. The Variable Balance adjustment sets the level on the base of Q334 so that no current flows between emitters under no-signal conditions. This ensures that there is no ground reference shift of the trace when the VARIABLE control is turned.

The second stage of the Vertical Output amplifier includes the GAIN adjustment, which varies the emitter degeneration of Q344 and Q354. The push-pull outputs are applied to the oscilloscope vertical amplifier as a current source.

The Real Time Trigger amplifier (Q362 and Q366) is a balanced circuit with push-pull input from the first stage of the Vertical Output amplifier. Positive and negative trigger signals are applied to the timing unit through the oscillo-scope interface.

Gate Generator

The Gate Generator diagram includes the Real Time Oscillator and Memory Gate Driver. The sampling drive pulse from the sampling sweep unit is slewed in time from the initial sweep trigger event and further delayed in the Delay circuit. The Memory Gate Driver circuit provides the proper time-positioning of the Memory Gate pulse so that the error signals are gated at the correct time. The Real Time Oscillator oscillates at about 47.5 kHz to start the sampling process when driven by a non-sampling sweep unit.

The Memory Gate Driver is preceded by a blocking oscillator (Q430 and associated components) which standardizes the risetime and amplitude of the sampling pulse from the sampling sweep. Until the positive sampling drive pulse occurs, Q430 is cut off and its collector is at +15 volts. The arriving pulse causes the transistor to start conduction as a normal amplifier, but the regenerative feedback from T430 via CR430 quickly drives Q430 into saturation. As the current through T430 reaches a steady value, the counter-EMF generated in the secondary of T430 is stopped by the reverse-biasing of CR430. Q430 remains in saturation until cut off when the sampling drive pulse ends.

The Memory Gate Driver circuit consists of a lowcurrent amplifier (Q452) and a monostable multivibrator (Q456-Q464). At quiescence, the base voltage of Q452 (determined by the DELAY control setting) is between +11 and +15 volts. The current through Q542 is about 1 mA, which is insufficient to forward-bias Q456. Diode CR455 holds the base of Q456 at -15.6 volts to ensure that the Memory Gate Driver output does not change as the DELAY control is changed. Q464 is reverse-biased by the current through R461, R460 (Memory Gate Width adjustment), CR462 and R462, and its base voltage is clamped at +0.6 volts by CR464. The collector voltage of Q464 rests at -14.5 volts.

When the blocking oscillator fires, the negative-going transition at Q430 collector is integrated into a fast negative-going ramp by R434 and C434. The ramp voltage drops to a level (determined by the DELAY control setting) sufficient to forward-bias CR434 and shortly thereafter, Q452 is driven to conduct harder. The additional current required by the emitter of Q452 is furnished by C451, and the collector of Q452 rises far enough to forward-bias Q456. When Q456 conducts its collector voltage drops, the negative change is coupled by C460 to reverse-bias CR462, which turns on Q464. R464 applies a steady 50 mA current to the Memory Gate transformer primary (T230) for about 180 nanoseconds. The positive-going change at the collector of Q456 in conduction.

The negative-going transition at the collector of Q456 is also coupled via C457 and C447 to the base of Q452, holding that transistor in hard conduction. The Strobe for the sampling head is taken from the junction of C457 and C447.

The regeneration from C447 to Q452 does not last as long as that holding Q456 in conduction, but since the base voltage of Q456 cannot go more positive than about -14.4volts, Q452's collector voltage does not change. The position of the Memory Gate Width control adjusts the charge rate of C460 and therefore the conduction time of Q464. The conduction time and gate duration vary directly with the resistance of R460.

As C460 charges toward +15 volts, CR462 again conducts and turns Q464 off, ending the Memory Gate pulse and the drive to the base of Q456. However, Q456 was in saturation, so it does not stop conducting immediately. The collector voltage of Q456 rises positive about 350 ns after the transistor was turned on. This RC rise is slow and does not couple much energy through either C457 or C460.

Real Time Oscillator

The Real Time Oscillator consists of two blocking oscillator circuits. One, a low frequency blocking oscillator, is composed of transistor Q404 and associated circuitry. The second, a high frequency blocking oscillator, is composed of transistors Q408, Q410 and associated circuitry. The Real Time Oscillator circuit is controlled by the oscillator control line from the sampling sweep unit. When the oscillator control line is at the high state, neither of the two oscillators can operate since their source of current is shunted by diodes CR413 and CR414 (see Gate Generator diagram 4). When the oscillator control line is at the low state, both diodes are back biased and the oscillators can operate.

The low frequency blocking oscillator uses transformer coupling from emitter to base to perform the oscillator action. During equivalent time sampling operation, the anode of CR413 is held at about +.6 volt. Most of the current from R404 travels through CR413, and Q404 remains reverse biased. When the sampling sweep unit TIME/DIV switch is rotated to a real time position, the oscillator control line drops to a point slightly below ground potential and the cathode of CR413 drops to about -.6 volt. As the cathode of CR413 drops below ground potential, Q404 begins to conduct. Current through T400 couples positive feedback via CR401 to the base of Q404, driving it further into conduction. The current for the rapid saturation of Q404 is furnished first by C406; then as the emitter of Q404 rises positive, CR402 begins to conduct and clamps the emitter of Q404 at about +.6 volt. The field around T400 begins to collapse, rapidly driving Q404 into cutoff. The result at the base of Q408 is a single positive pulse used to drive the high frequency blocking oscillator.

When the oscillator control line is at the high state, the anode of CR414 is at approximately ground potential, which is sufficient for the diode to conduct. Since there is no difference in potential from the cathode of CR413 to the cathode of CR414, both Q408 and Q410 are reverse biased when the oscillator control line is at the high state. When the sampling sweep unit is switched to a real time TIME/DIV setting, the oscillator control line drops to approximately -0.6 volt. The cathode potential of CR414 drops to approximately -1.2 volts at which point Q410, CR411 and Q408 begin conduction (the base of Q408 is pulled positive by the conduction of Q404). The change in the collector of Q410 through the primary of T410 starts positive feedback to the base of Q410. Q410 is driven rapidly into saturation. When Q410 saturates, the collapsing field across T410 then drives Q410 into cutoff. The result is a sharp negative pulse, which is coupled across C418 to the base of Q422. Although the repetition rate of the high frequency oscillator depends primarily on the output rate of the low frequency oscillator, the high frequency oscillator output frequency can be varied by the repetition rate adjustment, R415.

Transistor Q422 inverts the negative pulse from the high frequency oscillator and drives the base of Q430 when the sampling sweep unit is in real time operation.



Fig. 4-5. Simplified Readout Logic Coding.

۵

Readout Logic

The Readout Logic diagram shows the circuitry used to generate different current levels for analog coding. The transistors and diode are used to simplify the switching. Fig. 4-5 shows a simplified diagram of the switches and resistances used for encoding.

In some sampling heads there is no probe coding. Probe coding is performed via a ring around the BNC connector and Q506 and Q516 which convert the resistance value in the probe into analog current pulses during timeslot 1, B33. Trace identification is implemented by grounding the probe coding ring around the BNC connector.

Power Distribution and Decoupling

The Power Distribution & Decoupling diagram contains the power supply decoupling networks and internal power supply for the S-series sampling head. Power from the indicator oscilloscope enters through the center circuit board at the rear. The -12.2 Volt Supply consists of the comparator Q624 and the series regulator Q626. The output voltage is compared with the reference divider voltage of R621-R622.

The voltage reference divider, R621 and R622, applies approximately -12.2 volts to the base input of Q624. This reference is coupled to the emitter-base junction of the output side of Q624 through common emitter resistor R624.

A positive-going change in voltage decreases the current through the output collector of Q624 which places a more negative voltage on the base of Q626. As the current through Q626 increases, the output voltage decreases to its proper value.

 $\Omega624$ is protected from reverse bias by diodes CR624 and CR625.

SECTION 5 MAINTENANCE

Change information, if any, affecting this section will be found at the rear of the manual.

Introduction

This section of the manual contains maintenance information for use in preventive maintenance, corrective maintenance or troubleshooting of the 7S11.

PREVENTIVE MAINTENANCE

General

Preventive maintenance consists of cleaning, visual inspection, lubrication, etc. Preventive maintenance performed on a regular basis will help prevent instrument failure. The severity of the environment to which the 7S11 is subjected will determine the frequency of maintenance.

Cleaning

The 7S11 should be cleaned as often as operating conditions require. Accumulation of dirt in the instrument can cause overheating and component breakdown. Dirt on components acts as an insulating blanket and prevents efficient heat dissipation. It also provides an electrical conduction path.

The top and bottom covers of the instruments in which the 7S11 operates provide protection against dust in the interior of the instrument. Operating without the covers in place will require more frequent cleaning.



Avoid the use of chemical cleaning agents which might damage the plastic used in this instrument. Some chemicals to avoid are benzene, toluene, xylene, acetone or similar solvents.

External. Loose dust accumulated on the outside of the 7S11 can be removed with a soft cloth or small paint brush. The paint brush is particularly useful for dislodging dirt on and around the front-panel controls. Dirt which remains can be removed with a soft cloth dampened in a mild solution of water and detergent. Abrasive cleaners should not be used.

Interior. Dust in the interior of the instrument should be removed occasionally due to its electrical conductivity under high-humidity conditions. The best way to clean the interior is to blow off the accumulated dust with dry, low-velocity air. Remove any dirt which remains with a soft paint brush or a cloth dampened with a mild detergent and water solution.

Lubrication

The reliability of Potentiometers, rotary switches and other moving parts can be increased if they are kept properly lubricated. Use a cleaning-type lubricant on switch contacts. Lubricate switch detents with a heavier grease (such as Tektronix Part No. 006-0219-00). Potentiometers should be lubricated with a lubricant which will not affect electrical characteristics (such as Tektronix Part No. 006-2574-00). Do not over-lubricate. A lubrication kit containing the necessary lubricants and instructions is available from Tektronix. Order Tektronix Part No. 003-0342-01). The VARIABLE on/off slide switch uses Beacon #325 grease.

Visual Inspection

The 7S11 should be inspected occasionally for such defects as broken connections, improperly seated transistors, damaged circuit boards and heat-damaged parts.

The remedy for most visible defects is obvious; however, care must be taken if heat-damaged parts are located. Overheating is usually only a sympton of trouble. For this reason, it is essential to determine the actual cause of overheating before the heat-damaged parts are replaced; otherwise, the damage may be repeated.

Calibration

To ensure accurate measurements, check the calibration of this instrument after each 500 hours of operation or once every six months.

Parts Identification

Identification of Switch Wafers. Wafers of switches shown on the circuit diagram are numbered from the first

Maintenance-7S11

wafer located behind the detent section of the switch to the last wafer. The letters F and R indicate whether the front or the rear of the wafer is used to perform the particular switching function. For example, the designation 2R printed by a switch section on a schematic identifies the switch section as being on the rear side of the second wafer when counting back from the front panel.

Wiring Color Code. The wiring in the 7S11 is color coded to facilitate circuit tracing.

Resistor Coding. The 7S11 uses a number of very stable metal film resistors identified by their gray background color and color coding.

If the resistor has three significant figures with a multiplier, the resistor will be EIA color coded. If it has four significant figures with a multiplier, the value will be printed on the resistor. For example, a 333 k Ω resistor will be color coded, but a 333.5 k Ω resistor will have its value printed on the resistor body.

The color-coding sequence is shown in Fig. 5-1.

Capacitor Marking. The capacitance values of common disc capacitors and small electrolytics are marked in microfarads on the side of the component body. The white ceramic capacitors used in the 7S11 are color coded in picofarads using a modified EIA code (Fig. 5-1).

Diode Color Code. The cathode end of each glassencased diode is indicated by a stripe, a series of stripes or a dot. For most silicon or germanium diodes with a series of stripes, the color-code also indicates the type of diode or identifies the Tektronix Part Number using the resistor color-code system (e.g., a diode color-coded blue or pinkbrown-gray-green indicates Tektronix Part Number 152-0185-00). The cathode and anode end of metal-encased diodes can be identified by the diode symbol marked on the body.

Parts Replacement

All parts used in the 7S11 can be purchased directly through your Tektronix Field Office or Representative.



Fig. 5-1. Resistor and ceramic capacitor color-code.

However, replacements for standard electronic items can generally be obtained locally in less time than is required to obtain them from Tektronix. Replacements for the special parts used in the assembly of the 7S11 should be ordered from Tektronix since these parts are either manufactured or selected by Tektronix to satisfy a particular requirement. Before purchasing or ordering, consult the Electrical Parts List to determine the value, tolerance and rating required.

NOTE

When selecting the replacement parts, it is important to remember that the physical size and shape of a component may affect its performance at high frequencies. Parts orientation and lead dress should duplicate those of the original part since many of the components are mounted in a particular way to reduce or control stray capacitance and inductance. After repair, portions of the instrument may require recalibration.

Pushbutton Switches. The pushbutton switches are not repairable and should be replaced if defective. Components which are mounted on the circuit board associated with the pushbutton switch can be replaced using the normal replacement procedures.

Rotary Switches. Individual wafers or mechanical parts of rotary switches are normally not replaced. The availability of replacement switches, either wired or unwired, is detailed in the Electrical Parts List.

Circuit Boards. Use ordinary 60/40 solder and a 35- to 40-watt pencil type soldering iron on the circuit boards. The tip of the iron should be clean and properly tinned for best heat transfer to the solder joint. A higher wattage soldering iron may separate the etched wiring from the base material.

All of the components mounted on the Vertical and Inter-Channel Control circuit boards can be replaced without removing the boards from the instrument. Observe soldering precautions given under Soldering Techniques in this section.

Replacement of soldered-in diodes. Grasp the diode lead between the body of the diode and the circuit board with a small pair of tweezers. Touch the tip of the soldering iron to the lead where it enters the circuit board. Do not lay the iron tip directly on the circuit board. Gently but firmly pull the diode lead from the hole in the circuit board. If removal of the lead does not leave a clean hole, apply a sharp object such as a toothpick or pointed tool while reheating the solder. Avoid using too much heat.

NOTE

Cleaning of the circuit board hole while the board is mounted in the instrument is not recommended. Solder pushed through the hole toward the back side cannot always be cleared away unless the back side is accessible. Thus, clear the mounting holes only when the board is out of the instrument.

To place the new diode, bend the leads and trim to fit just through the board. Tin each lead while using the tweezers as a heat sink. Place the diode leads in the holes. Apply a small amount of solder, if necessary, to ensure a good bond. Use the tweezers as a heat sink and use only enough heat for a good connection.

Replacement of other soldered-in components. Grip the component lead with long-nose pliers. Touch the soldering iron to the lead at the solder connection. Do not lay the iron directly on the board, as it may damage the board. Refer to Fig. 5-2.

When the solder begins to melt, pull the lead out gently. This should leave a clean hole in the board. If not, the hole can be cleaned by reheating the solder and placing a sharp object such as a toothpick or pointed tool into the hole to clean it out.

Bend the leads of the new component to fit the holes in the board. If the component is replaced while the board is mounted in the instrument, cut the leads so they will just protrude through the board.

Pre-tin the leads of the component by applying the soldering iron and a small amount of solder to each (heatshunted) lead. Insert the leads into the board until the component is firmly seated against the board. If it does not seat properly, heat the solder and gently press the component into place.



Fig. 5-2. Apply the soldering iron to the heat-shunted lead when removing a component from a circuit card.

Maintenance-7S11

Apply the iron and a small amount of solder to the connection to make a firm solder joint. To protect heatsensitive components, hold the lead between the component body and the solder joint with a pair of long-nose pliers or other heat sink.

Clean the area around the soldered connection with a flux-remover solvent to maintain good environmental characteristics. Be careful not to remove information printed on the board.

Incandescent bulbs for lighting the pushbutton switches are soldered to the circuit board on the pushbutton switches. Remove the screws and cover to expose the bulbs.

Metal Terminals. When soldering metal terminals (e.g., switch terminals, potentiometers, etc.), ordinary 60/40 solder can be used. The soldering iron should have a 40- to 75-watt rating with a 1/8 inch wide chisel-shaped tip.

Observe the following precautions when soldering metal terminals:

1. Apply only enough heat to make the solder flow freely.

2. Apply only enough solder to form a solid connection. Excess solder may impair the function of the part.

3. If a wire extends beyond the solder joint, clip off the excess.

4. Clean the flux from the solder joint with a flux-remover solvent.

Circuit Board Replacement. If a circuit board is damaged and cannot be repaired, the entire assembly including all soldered-on components should be replaced. The part number given in the Mechanical Parts List is for a completely wired board.

Replace the Vertical and Inter-Channel Control circuit boards with attention to the screws which are spring mounted to the center circuit board. Be certain that the screws are gradually loosened so the circuit board assembly does not spring up at one end and cause damage. Loosen the screws one turn at a time to equalize stress caused by the springs. Check that the pins are straight before replacement. Replace the circuit board with careful alignment of the holes over the pins with pressure on the area around the screws to overcome spring resistance for the initial screw tightening, then tighten all the screws gradually, (as in the removal) one turn at a time. Tighten all screws finger-tight.

The Interface assembly board can be removed as follows: first, loosen (or remove) the phillips head screws and locking nuts holding the fixed shoe on the left side of the 7S11 and lift the shoe away, then remove the six phillips head screws holding the Interface assembly board to the metal chassis. Remove the four phillips head screws holding the rear plastic connector guide. Loosen the set screw in the shaft coupling holding the VARIABLE control shaft to the control (switch pushed in). The Inter-Channel Control circuit board must be removed for removal of pin connections at pins A, B and ground. Tag the wires with masking tape and mark for identification. Disconnect all pin-and-connector wire connections. Unsolder the leads at the sampling head connector, gently lifting them away from the board. Pull the assembly board from the 7S11 to the rear, watching the wires connected to the movable shoe for possible hang-up on the notches, and placing them so they bend outside the chassis holes.

Interface board replacement involves installation of the board, watching and placing the wires for least interference and final location. Install and tighten the four screws holding the rear plastic connector. Next, install and tighten the six chassis screws. Solder the sampling head connector pins and connect the wires. Install the fixed shoe connector into the slot and install the Inter-Channel Control board. Reassemble the VARIABLE control shaft and coupling and tighten the set screw.

TROUBLESHOOTING

Introduction

The following information is provided to facilitate troubleshooting of the 7S11. Information contained in other sections should be used along with the following information to aid in locating the defective component. An understanding of the circuit operation is very helpful in locating troubles. See the Circuit Description section if the operation of a particular circuit is not clear.

Troubleshooting Aids

Diagrams. Complete circuit diagrams are given on foldout pages in the Diagrams section. The component number and electrical value of each component in this instrument are shown on the diagrams. Each main circuit is assigned a series of component numbers. Table 5-1 lists the main circuits in the 7S11 and the series of component numbers assigned to each. Important voltages and waveforms are also shown on the diagrams. The portions of the circuit mounted on circuit boards are enclosed with a blue line.

TABLE 5-1

Component numbers on diagrams	Diagram number	Circuit
101-149	1	Post Amp & Attenuators
201-299	2	Memory
301-399	3	Output Amplifier
401-499	4	Gate Generator
501-549	5	Readout Logic
601-649	7	Power Distribution
		& Decoupling

Troubleshooting Techniques

This troubleshooting procedure is arranged in an order which checks the simple trouble possibilities before proceeding with extensive troubleshooting. The first few checks ensure proper connection, operation and calibration. If the trouble is not located by these checks, the remaining steps aid in locating the defective component. When the defective component is located, it should be replaced, following the replacement procedures given in this section.

1. Check Control Settings. Incorrect control settings can indicate a trouble that does not exist. For example, incorrect setting of the VARIABLE control appears as incorrect gain, etc. If there is any question about the correct function or operation of any control, see the Operating Instructions section of this manual.

2. Check Associated Equipment. Before proceeding with troubleshooting of the 7S11, check that the equipment used with the 7S11 is operating correctly. Check that the signal is properly connected and that the interconnecting cables are not defective. Also, check the power source.

3. Visual Check. Visually check the portion of the instrument in which the trouble is located. Many troubles can be located by visual indications such as unsoldered connections, broken wires, damaged circuit boards, damaged components, etc.

4. Check Instrument Calibration. Check the calibration of the instrument, or the affected circuit if the trouble exists in one circuit. The indicated trouble may only be a result of misadjustment or may be corrected by calibration. Complete instructions are given in the Calibration section of this manual.

5. Isolate the Trouble to a Circuit. To isolate trouble to a circuit, note the trouble symptom. The symptom often identifies the circuit in which the trouble is located. When trouble symptoms appear in more than one circuit, check affected circuits by taking voltage and waveforms readings.

Transistor Checks

Transistors should not be replaced unless they are actually defective. Transistor defects usually take the form of the transistor opening, shorting, or developing excessive leakage. To check a transistor for these and other defects, use a transistor curve display instrument such as a Tektronix Type 576 or 575. However, if a good transistor checker is not readily available, a defective transistor can be found by signal-tracing, by making in-circuit voltage checks, by measuring the transistor forward-to-back resistance using proper ohmmeter resistance ranges, or by using the substitution method. The location of all transistors is shown in the parts location figures later in this section.

To check transistors using a voltmeter, measure the emitter-to-base and emitter-to-collector voltages and determine if the voltages are consistent with the normal resistances and currents in the circuit (see Fig. 5-3). Note the lead configuration in Fig. 5-4.

When checking transistors by substitution, be sure that the voltages supplied to the transistor are normal before making the substitution. If a transistor is substituted without first checking out the circuit, the new transistor may immediately be damaged by some defect in the circuit.

Diode Checks

A diode can be checked for an open or shorted condition by measuring the resistance between terminals. With an ohmmeter scale having an internal source of about 1.5 volts, the resistance should be very high in one direction and very low when the leads are reversed.



Fig. 5-3. In-circuit voltage checks NPN or PNP transistors.

Do not use an ohmmeter scale that has a high internal current. High currents may damage the diode. Do not measure tunnel diodes with an ohmmeter; use a dynamic tester (such as Tektronix Type 576 or 575 Transistor Curve Tracer).

Field Effect Transistors (FET)

Memory Amplifier field effect transistors in the 7S11 should not be tested with an ohmmeter. Rather, if you suspect the dual FET, pull the unit out of the socket, rotate it 180° and re-insert it. The leads are arranged in a manner to permit the unit to be installed with the guide pin pointing either forward or backward. If there is no change in circuit operation, both sections of the dual FET are probably good.

Actual condition of either half of a dual FET can be checked using a Tektronix Type 576 Transistor Curve Tracer. The Gate corresponds to the Base, Drain to the Collector, and Source to the Emitter of an ordinary transistor at the curve tracer sockets.

Set the Type 576 Curve Tracer controls:

Vertical Current/Div	1 mA
Display Offset	0
Centerline Value	Div
Display Invert	Released
Zero	Released
Cal	Released
Horizontal Volts/Div	1 Collector
Max Peak Volts	15
Watts	0.1
Polarity	+ (NPN)
Mode	Norm
Number of Steps	10
Offset Mult	0.00
Step/Offset Amplitude	.05 V
Offset Zero	Pressed
Steps	Pressed
Step Family Rep	Pressed
Rate Norm	Pressed
Step Mult 1X	Released
Step/Offset Polarity Invert	Pressed
Variable Collector Supply	0
Emitter Grounded	Step Gen

Install the FET Test Fixture in the Type 576 Standard Test Fixture and the FET to be tested in the Test Fixture.

Turn the Variable Collector Supply control clockwise until about 10 volts is displayed horizontally.



Fig. 5-4. Lead configuration for transistors used in the 7S11.

Press the Step Generator Polarity Invert button for the Depletion mode of operation or release the button for the Enhancement mode of operation.

Turn the Amplitude switch counterclockwise until a family of curves is displayed. Set the Peak Power Watts switch for a maximum collector supply power output of less than the maximum power rating of the FET under test.

Increase the collector supply voltage as follows:

- Set the Variable Collector Supply control fully counterclockwise;
- (2) Install the protective box and close the lid;
- (3) Set the Max Peak Volts switch to to the desired voltage range;
- (4) Turn the Variable Collector Supply control clockwise until the desired collector supply voltage is obtained.

Turn the Amplitude switch counterclockwise for a higher drain current.

Small-signal g_m of the FET is equal to the Vertical switch setting divided by the Amplitude switch setting (note the g_m PER DIV READOUT), multiplied by the vertical separation of two curves of the displayed family.

Major Circuit and Parts Location

The remainder of this section includes photographs of sections of the 7S11. Major circuit areas are identified. All components mounted on circuit boards are identified by circuit numbers. All circuit board connections are identified by pin letters.

REPACKAGING FOR SHIPMENT

If the Tektronix instrument is to be shipped to a Tektronix Service Center for service or repair, attach a tag showing: owner (with address) and the name of an individual at your firm that can be contacted, complete instrument serial number and a description of the service required.

Save and re-use the package in which your instrument was shipped. If the original packaging is unfit for use or not available, repackage the instrument as follows:

Surround the instrument with polyethylene sheeting to protect the finish of the instrument. Obtain a carton of corrugated cardboard of the correct carton strength and having inside dimensions of no less than six inches more than the instrument dimensions. Cushion the instrument by tightly packing three inches of dunnage or urethane foam between carton and instrument, on all sides. Seal carton with shipping tape or industrial stapler.

The carton test strength for your instrument is 200 pounds.



*See Parts List for serial number ranges

Fig. 5-5. Vertical circuit board.



Fig. 5-5. Inter-Channel Control circuit board.



Fig. 5-7. Interface circuit board, left side.



Fig. 5-8. Interface circuit board, right side.

SECTION 6 PERFORMANCE CHECK/CALIBRATION

Change information, if any, affecting this section will be found at the rear of the manual.

Introduction

This procedure combines the 7S11 performance check and calibration procedures since a number of the steps are common to both procedures. After the "Preliminary Procedure", which is performed before the 7S11 is installed in the oscilloscope, the Performance Check Procedure (using the test equipment recommended and without access to internal controls or test points) includes all the steps that can be done on the 7S11 once it is installed in the oscilloscope. Notes in the text titled "PERFORMANCE CHECK ONLY" give instructions that pertain to the performance check procedure only and list the next step applicable to the performance check. All these steps herein pertain to the calibration procedure.

As an aid to the calibration of the instrument, a Short-Form Procedure is given prior to the complete procedure. To facilitate instrument calibration for the experienced calibrator, the Short-Form Procedure lists the calibration adjustments necessary for each step and the applicable tolerances. This procedure also includes the step number and title as listed in the complete Performance Check/ Calibration Procedure and the page number where each step begins. Therefore, the Short-Form Procedure can be used as an index to locate a step in the complete procedure. This procedure can be reproduced and used as a permanent record of instrument calibration.

Completion of each step in the complete Performance Check/Calibration Procedure insures that this instrument meets the electrical specifications given in Section 1. Where possible, instrument performance is checked before an adjustment is made. For best overall instrument performance when performing a complete calibration procedure, make each adjustment to the exact setting even if the check is within the allowable tolerance.

NOTE

All waveforms shown in this procedure were taken with a Tektronix Oscilloscope Camera System. Limits, tolerances and waveforms in this procedure are given as calibration guides and should not be interpreted as instrument specifications except as specified in Section 1.

TEST EQUIPMENT REQUIRED

General

The following test equipment and accessories, or its equivalent, is required for complete calibration of the 7S11. Specifications given are the minimum necessary for accurate calibration; therefore, some of the recommended equipment may have specifications that exceed those given. All test equipment is assumed to be correctly calibrated and operating within the given specifications. If equipment is substituted, it must meet or exceed the specifications of the recommended equipment.

Special Tektronix Calibration fixtures are used in this procedure only where they facilitate calibration. These special calibration fixtures are available from Tektronix, Inc. Order by part number through your local Tektronix Field Office or representative.

Test Equipment

1. Oscilloscope, a 7504 or a 7704, in which to operate the 7S11.

2. Type S-1 Sampling Head.

3. 7T11 Sampling Sweep Unit.

4. Test oscilloscope with a differential comparator; minimum deflection factor required is 5 mV/div or less, risetime required is 20 ns or less. A 7A13 Differential Comparator and 7B50 Time Base can be operated in the 7504 (or 7704) Oscilloscope required for the 7S11, or use a separate oscilloscope such as the Type 547 with the Type W Plug-In Unit.

5. 1X Probe, P6101. Tektronix Part No. 010-6101-01.

6. 50 Ω Amplitude Calibrator. Output impedance 50 Ω ; voltage range 0.012 to 1.2 volts square wave; accuracy within ±0.3%. Tektronix Calibration Fixture 067-0508-00.

Performance Check/Calibration-7S11

7. A special Variable Attenuator with GR 874 connectors. It consists of a 100 Ω potentiometer across a 50 Ω line, and does not have a guaranteed response. Tektronix Part No. 067-0511-00.

8. Normalizer Head, optional (recommended if more than one sampling head will be used with the 7S11) for Memory Gain and Memory Gate Width adjustments. Tektronix Calibration Fixture 067-0572-01.

9. DC Resistance Bridge (such as ESI 250 DA) for measuring 10 $k\Omega$, accurate within $\pm 0.5\%$.

NOTE

This test instrument is not required if the Preliminary Procedure is omitted.

10. 10X Probe, P6012. Tektronix Part No. 010-0203-00.

11. 2 1/2 inch ground lead. Tektronix Part No. 175-0249-00.

12. Adapter, BNC (F) to GR 874. Tektronix Part No. 017-0063-00.

13. Adapter, 3 mm (M) to BNC (F). Tektronix Part No. 015-1018-00, supplied with the 7T11.

14. 50 Ω coaxial cable about 4 feet long with BNC connectors, for example, RG58C/U cable, Tektronix Part No. 012-0057-01.

15. 50 Ω coaxial cable with GR 874 connectors, such as 5 ns signal delay RG58C/U cable, Tektronix Part No. 017-0512-00.

16. Screwdriver. Three-inch shaft, 3/32-inch bit for slotted screws. Tektronix Part No. 003-0192-00.

17. Extender, Tektronix Calibration Fixture 067-0589-00.

18. Special cable assembly, RF, about 36 inches in length with mini-coaxial connectors. Tektronix Part No. 012-0203-00.

19. Patch cord with insulated aligator clips.

SHORT-FORM PROCEDURE

7S11, Serial Number _____

Calibration Date _____

Calibrated By _____

1. Check –12.2-Volt Power Supply Page 6-5

-12.2 volts ±0.24 volt; ripple 1 mV P-P or less.

2. Check Interdot Blanking Page 6-6

Blanking Pulse width between 0.75 μ s and 2 μ s at the 50% amplitude, SN B101608 and below. 7 μ s to 9.5 μ s at the 50% amplitude, SN B101609 and up.

3. Check Dot Response and Smoothing, Page 6-7 Adjust Gain

DOT RESPONSE control can set the display to unit loop gain in NORMAL operation; loop gain decreases to 0.3 or less of NORMAL in SMOOTH operation.

4. Adjust Memory Gate Width (R460) and Page 6-7 Memory Gain (C275) With Normalizer Head

Memory Gate Width control to given maximum trace separation and Memory Gain control for 5 division trace separation with the DOT RESPONSE control set at electrical midrange.

5. Adjust Memory Gate Width (R460) and Page 6-8 Memory Gain (C275) with Sampling Head

Memory Gate between 160 ns and 180 ns, 50% amplitude level; Memory Gain set for 5 division trace separation with a 400 mV error signal at test point 121.

6. Adjust Variable Balance (R305) and Page 6-9 Smoothing Balance (R245)

No trace movement with VARIABLE control rotation or when SMOOTH switch is pushed.

7. Check Deflection Factor Accuracies, Page 6-10 Variable Control Range, and Adjust Gain

Units/Div switch setting amplitude correct within 3% with the GAIN set any switch setting, VARIABLE control at CAL; VARIABLE control increases the deflection amplitude 2.5 times or more at fully clockwise setting and decreases the deflection amplitude to 0.5 or less at fully counterclockwise setting.

8. Check Memory Overdrive Recovery Page 6-11

Baseline (unity loop gain indication) shift at 10 mV/div not more than 1 div with about 8 times the normal signal displayed.

9. Check Vertical Signal Out Page 6-11
Output is 200 X Signal Input in volts, Units/Div ±2%.
Output is 200 mV (within 3%) per displayed division in +UP or INVERT.

10. Check Vertical Gain Change in Page 6-11 SMOOTH

Vertical gain change in SMOOTH operation within 3% of NORMAL operation

11. Check Memory Slash Page 6-11

Vertical amplitude of slash at 20 Hz is 0.1 division or less.

12. Check Delay Page 6-12

Displayed range of DELAY control is at least 10 ns.

13. Check/Adjust Real Time Sampling Page 6-12 (R415)

Repetition rate is 47.5 kHz within 10%, frequency modulated; FM rate between 120 Hz and 440 Hz; FM deviation within 8% of the repetition rate.

14. Check DC Offset and Adjust Position Page 6-12 (R325)

Displayed range of DC OFFSET control +1 volt and -1 volt or more; Offset voltage range at OFFSET OUT jack from at least +10 volts to -10 volts. Actual displayed offset = (0.1) (Offset Out) within 2%.

15. Check Real-Time Trigger Amplifier Out- Page 6-14 put

(0.1) (Memory Output)

PERFORMANCE CHECK/ CALIBRATION PROCEDURE

General

The following procedure is arranged so the 7S11 can be calibrated with the least interaction of adjustments and reconnection of equipment. A picture of the test equipment required for each group of steps is given to aid in identification of the necessary equipment. The control settings and test equipment setup throughout this procedure continue from preceding step(s) unless noted otherwise.

NOTE

Control titles which are printed on the front panel of the 7S11 are capitalized in this procedure (e.g., DE-LAY). Internal adjustments are initial capitalized only (e.g., Position).

The following procedure uses the equipment listed under Test Equipment Required. If other equipment is substituted, control settings or calibration setup may need to be altered to meet the requirements of the equipment used. Detailed operating instructions for the test equipment are not given in this procedure. Refer to the instruction manual for the test equipment if more information is required.

NOTE

Many tolerances given in this procedure are guides to correct instrument operation and are not instrument specifications.

Preliminary Procedure

Before installing the 7S11 in the oscilloscope, check the source resistance of the Offset Out and Vert Sig Out jacks.

NOTE

This preliminary Procedure may be omitted if this verification is not required.

The Offset Out jack resistance must be 10 k Ω ±1%, (9.9 k Ω to 10.1 k $\Omega).$

a. Ground test point 163, see Fig. 6-1. Use a DC resistance bridge and measure the DC source resistance at the OFFSET OUT jack.

b. Ground test point 264, see Fig. 6-1. Measure the DC source resistance at the VERT SIG OUT jack with the DC resistance bridge.

The Vert Sig Out jack resistance must be 10 k Ω ±0.5% (9.95 k Ω to 10.05 k Ω).

Performance Check

Install the 7T11 in the A HORIZ compartment of the 7504 Oscilloscope and the 7S11 (with a calibrated sampling head installed) in the RIGHT VERT compartment.

Begin the performance check with step 3.



Fig. 6-1. Vertical circuit board location of grounded test points for output jack resistance measurement.

Calibration Procedure

a. Assemble the extender, the 7511 and 7T11 at the 7504 Oscilloscope. Remove the mini-coaxial connector at the top of the 7T11 (see Fig. 6-2) and insert the special mini-coaxial cable through the chassis (so the 7T11 can be installed in the oscilloscope) and connect it to the connector. Place the disconnected cable within the chassis and tape the connector to avoid contact with components. Remove the mini-coaxial connector on the 7S11 left side (Inter-Channel Control circuit board) and connect the special cable. This completes the oscillator control and strobe drive circuits. The 7S11 INT TRIG lamp will not be on when the 7T11 is at int trigger.

b. Install the 7T11 in the A HORIZ compartment of the oscilloscope. Connect the 7511 to the solid or flexible extender, then install the extender in the RIGHT VERT compartment.

c. Install the Type S-1 Sampling Head in the 7S11.

Both Procedures

a. Install the 7A13 in the Oscilloscope Left Vert compariment and the 7B50 in the B HORIZ compartment.

b. Make all power connections. Turn on the power to all equipment. Allow 20 minutes warmup time before proceeding. Set the controls as listed under Preliminary Control Settings.

Preliminary Control Settings

Set the 7S11 controls as follows:

DELAY	Midrange
+UP	Pushed in
DC OFFSET ±1 V and FINE	Midrange
mVOLTS/DIV	50
VARIABLE	Pushed in
DOT RESPONSE	Midrange
NORMAL	Pushed in

Set the 7T11 controls as follows:

Time Position and Fine	Fully clockwise
Sequential	Pushed in
Sweep Range	5 µs
Time/Div	0.5 µs
Variable	Pushed în
Scan	Fully clockwise
Rep	Pushed in
Slope +	Pushed in
Trig Level	Midrange
Stability	Fully clockwise
Trig Amp X1	Pushed in
Ext 1 MΩ	Pushed in

Set the 7504 Oscilloscope controls as follows:

A Intensity	Midrange
Focus	Adjusted for well defined display
B Intensity	Midrange



Fig. 6-2. Special connections for calibration.



Fig. 6-3. Test equipment required.

Readout Control Ulum	As desired	1. Check –12.2-Volt Power Supply
Grat Illum	As desired	PERFORMANCE CHECK ONLY
Calibrator Rate	4 V (0.4 V into 50 Ω) 1 kHz	Steps 1 and 2 are not applicable to the performant check. Set controls as given under Preliminary Col

Set the 7A13 and 7B50 (test oscilloscope) controls as follows:

Comparison Voltage	-0.000 Volts
+Input	AC
Volts/Div	1 mV
BW	5 MHz
Time/Div	10 ms
Trigger Mode	P-P Auto
Triggering Coupling	AC
Triggering Source	Line
Magnifier	X1

Set the 50 Ω Amplitude Calibrator as follows:

Operate

0.3

Test-Operate	
Volts	

æ trol Settings and begin the performance check with step 3.

a. Test equipment required is shown in Fig. 6-3. Set the 7504 Oscilloscope Vertical Mode switch to Left and Horizontal Mode switch to B.

b. Connect a 1X probe from the + Input to Pin A at the sampling head connector, see Fig. 6-4.

NOTE

The -12.2-Volt power supply voltage and ripple tolerance are typical values provided as guides to correct instrument operation and are not instrument specifications. Actual values may exceed these values without loss of measurement accuracy if the instrument meets the specifications given in Section 1, as tested in this procedure.



Fig. 6-4. Power supply checks.

c. Check that the ripple is not more than $1\,\text{mV}$ peak to peak.

d. Set the 7A13 Volts/Div to 50 mV and the Comparison Voltage to 12.00. Set the + Input to GND and position the trace at graticule center.

e. Set the +Input to DC and the -Input to Vc. Adjust the Comparison Voltage to position trace at graticule center and check that voltage is -1.244 to -1.196.

f. Set +Input and -Input to GND and remove the probe.

2. Check Interdot Blanking

a. Change the 7A13 probe from 1X to 10X and set the controls as follows:

Volts/Div	10 m V
+Input	AC

b. Connect the 10X probe ground clip to a 7S11 Ground test point and the probe tip to pin AC, see Fig. 6-5A.

c. Set the 7504 Oscilloscope Vertical Mode switch to ALT. Set the 7T11 Sweep Range switch to 0.5 ms and the Time/Div switch to 5 μ s. Set the 7T11 Stability control fully clockwise and the Trig Leve) control at midrange (dot straight up).



Fig. 6-5. Interdot blanking checks.

Ô

d. Set the 7B50 Time/Div switch to 1 μ s and adjust the Level/Slope control for a stable display similar to Fig. 6-5B.

e. Check the blanked trace (7S11) for 0.75 μs to 2 μs , SN B101608 and below (7 μs to 9.5 μs , SN B101609 and up) as shown in Fig. 6-5B.

3. Check Dot Response and Smoothing

a. Connect the 50 Ω Amplitude Calibrator Output to the Sampling Head input connector through a 50 Ω coaxial cable and the Trigger Output to the 7T11 Trig Input connector through a 50 Ω coaxial cable and BNC to 3 mm adapter.

b. Set the 7504 Vertical Mode switch to Right, Horizzontal Mode switch to A, and A Trigger source switch to Right.

c. Set the 7T11 Sweep Range switch to 50 μ s and the Time/Div switch to 2 μ s. Push in the Ext 50 Ω 2 V Max switch. Obtain a stable display with the Stability control fully counterclockwise and the Trig Level control as needed. Center the positive level of the square wave on the graticule with the Time Position control.

d. Set the 7S11 GAIN control for exactly 6 divisions of display amplitude.

e. Observe the first dot at the front corner of the positive level as the DOT RESPONSE control is turned fully clockwise and fully counterclockwise, see Fig. 6-6A. Check that the first dot moves more than 1 division above and below the positive level.

f. Set the DOT RESPONSE control at unity loop gain, the first dot is at the same level as the positive level of the square wave.

g. Push the SMODTH switch in and check that the first dot on the rising portion of the waveform is less than 1.8 divisions from the negative level (0.3 of the 6 division display amplitude, i.e., loop gain is reduced to 0.3 of unity loop gain). See Fig. 6-6B.

h. Push in the NORMAL switch. Set the 7T11 Scan control to about 9 o'clock.

4. Adjust Memory Gate Width (R460) and Memory Gain (C275) With Normalizer Head

PERFORMANCE CHECK ONLY

Steps 4, 5 and 6 are not applicable to a performance check. Set controls as given in step 7 and proceed with step 7.

NOTE

Steps 4 and 5 accomplish the same adjustments. If the Normalizer Head is used, time is saved and step 5 can be disregarded.

a. Remove the Type S-1 Sampling Head and install the Normalizer Head, Tektronix Calibration Fixture 067-0572-01.



A. DOT RESPONSE control fully counterclockwise, loop gain less than unity.



Fig. 6-6. Dot response and smoothed operation check.

Performance Check/Calibration-7S11

b. Set the 7S11 Units/Div switch to 100. Set the Normalizer Head Units/Div Multiplier to X1 and the Units switch to Volts.

c. Set the 7T11 Sweep Range switch to 50 ms and the Time/Div switch to 5 ms. Set the Stability control fully clockwise and the Trig Level control for a free-running display.

d. Adjust the Memory Gate Width control, R460, for maximum vertical separation between traces. See Fig. 6-7 for control location.

e. Set the DOT RESPONSE control at electrical midrange; turn the control fully clockwise, note separation, turn control fully counterclockwise and note separation. Average the two noted separations and set the DOT RESPONSE for the average separation. (The knob dot should be at 12 o'clock setting.)

f. Adjust Memory Gain control C275 for 5 divisions of vertical separation between traces.

g. Remove the Normalizer Head. Install the Type S-1 Sampling Head.

5. Adjust Memory Gate Width (R460) and Memory Gain (C275) With Sampling Head

a. Connect the 50 Ω Amplitude Calibrator Output to the Sampling Head input connector through a 50 Ω GR 874 coaxial cable and variable attenuator. Set the Volts switch to 1.2.

b. Set the 7S11 Units/Div switch to 100. Set the 7T11 Sweep Range to 5 ms, the Time/Div switch to 0.5 ms, the Stability control fully clockwise and the Trig Level control for a free-running display.

c. Set the variable attenuator for an applied signal amplitude of 5 divisions. Turning the DOT RESPONSE control appears as extra lines, see Fig. 6-8A. Set the DOT RE-SPONSE control at electrical midrange; turn the control fully clockwise, note separation of the extra lines of dots, turn control fully counterclockwise and note separation. Average the two noted separations and set the extra lines of dots at the average separation with the DOT RESPONSE control. (Either the top or bottom trace can be used alone if the extra lines exceed the graticule area in separation by noting the maximum above and below movement of the extra lines from one trace and setting the lines at the average.)

d. Set the 7A13 Volts/Div switch to 100 mV and the BW switch to Full. Set the 7B50 Time/Div switch 0.1 μ s. Set

the 7504 Vertical Mode switch to Left, the Horizontal Mode switch to B, and the B Trigger Source switch to Left Vert.

e. Connect the 7A13 10X probe to test point 230, the Memory Gate Driver, see Fig. 6-7.

f. Obtain a stable display and center the waveform. Check that the Memory Gate is between 160 ns and 180 ns wide at the 50% level, see Fig. 6-8B.

g. Adjust the Memory Gate Width control R460, Fig. 6-7, for a Memory Gate between 160 ns and 180-ns wide at the 50% amplitude level.

h. Connect the 7A13 10X probe to test point 121, the Post Amplifier Input, see Fig. 6-7, and use a short ground lead (Tektronix Part No. 175-0249-00) to minimize ringing. Set the 7A13 Volts/Div switch to 10 mV.

i. Connect a 1X probe from the 7B50 Ext Trig In connector to test point 230 and push the Ext Triggering Source switch.

j. Remove Q404, see Fig. 6-7, and obtain a stable, double-triggered display in such a manner that there are two, most defined, waveform traces, one positive and one negative, as shown in Fig. 6-8C. If not, change the real-time oscillator frequency by adjusting R415.

k. Set the variable attenuator at the Sampling Head input connector for a display 400 mV peak to peak (200 mV peak to peak if not a Type S-1 Sampling Head), ignore ringing, and use a vertical graticule line to check the amplitude, about 80 ns to 100 ns from the start of ringing. See Fig. 6-8C.

I. Set the 7504 Vertical Mode switch to Right and the Horizontal Mode switch to A. Check that the bright traces are 5 divisions apart.

m. Adjust the Memory Gain control C275, see Fig. 6-7, for 5 divisions separation (2.5 divisions if not a Type S-1), similar to Fig. 6-8A.

n. Remove the probes and install Q404. See Step 13 for R415 adjustment.



Fig. 6-7. Test points and adjustments, steps 4 through 13,

0

Smoothing Ba R245

6. Adjust Variable Balance (R305) and Smoothing Balance (R245)

B. 7S11 right side adjustments.

a. Remove Q262 and Q266, then short test point 264 to ground with a patch cord. See Fig. 6-7.

b. Release the VARIABLE Units/Div control and rotate the control throughout its range. Check that the trace moves no more than 0.2 division vertically. c. Adjust Variable Bal control R305 for minimum trace shift as the VARIABLE control is rotated throughout its range. See Fig. 6-7 for location of control.

d. Return the VARIABLE control to the CAL IN position. Remove the patch cord and install transistors Q262 and Q266.

e. Push the SMOOTH switch in and check for no trace movement.



Fig, 6-8. Memory Gate Width and Memory Gain adjustments with sampling head.

f. Adjust Smoothing Bal control R245 for no trace movement when either the NORMAL or SMOOTH switch is pushed.

g. Push in the NORMAL switch. Disconnect the variable attenuator and cable at the sampling head input connector.

7. Check Deflection Factor Accuracies, Variable Control Range and Adjust GAIN

a. Set the 7S11 Units/Div switch to 100 and apply 0.6 volts from the 50 Ω Amplitude Calibrator to the sampling head input connector through a 50 Ω coaxial cable and connect a coaxial cable from the Amplitude Calibrator Trigger Output connector to the 7T11 Trig Input connector,

b. Push the 7T11 Ext 50 Ω 2 V Max switch, set the Sweep Range switch to 50 μ s and the Time/Div switch to 5 μ s. Obtain a stable display with the Trig Level control.

c. Adjust the front panel GAIN control for a display amplitude of 6 divisions.

Normal range of the GAIN control is from 6.4 divisions, control fully clockwise, to 5.6 divisions, control fully counterclockwise (minimum range).

d. Check all positions of the attenuator switch, as listed in Table 6-1, for a 6 division display amplitude within a tolerance of ± 0.18 division.

Units/Div	50 Ω Amplitude Calibrator
200	1.2 V
100	.6 V
50	.3 V
20	.12 V
10	.06 V
5	.03 V
2	.012 V

NOTE

Record deflections in each case. If one range is above tolerance, GAIN can be reduced to bring all ranges within tolerance without need for checking the Feedback Attenuator resistor values.

e. Set the Units/Div switch to 200 and the 50 Ω Amplitude Calibrator to 0.6 volts. Display amplitude is 3 divisions.

f. Push the VARIABLE control to release it from the CAL IN position. Turn the VARIABLE control fully counterclockwise and check the display amplitude for 1.5 divisions or less.

g. Turn the VARIABLE control fully clockwise and check the display amplitude for 7.5 divisions or more.

h. Return the VARIABLE control to the CAL IN position.

8. Check Memory Overdrive Recovery

a. Set the 50 Ω Amplitude Calibrator Output Volts to 0.03 and the 7S11 Units/Div switch to 10. Set the 7T11 Stability control fully clockwise and adjust the Trig Level control for a free running display.

b. Set the DOT RESPONSE control so the display consists of two continuous lines 3 divisions apart (indication of unity loop gain).

c. Set the 50 Ω Amplitude Calibrator Output Volts to 0.3 and position the bottom of the display on the graticule with the DC OFFSET control.

d. Observe that the continuous line may become two lines, indicating that the loop gain has changed.

e. Check that the separation does not exceed 1 division.

9. Check Vertical Signal Out

a. Set the 7S11 Units/Div switch to 100 and set the 50 Ω Amplitude Calibrator Volts switch to 0.6.

b. Set the 7504 Vertical Mode switch to Left and the Horizontal Mode switch to B. Set the 7B50 Time/Div switch to 5 ms. Set the 7A13 controls as follows:

Comparison Voltage	+
+ Input	DC
Volts/Div	20 m V
—Input	Vc
RIN (internal switch S10)	00

c. Connect the 1X probe from the 7A13 +Input to the 7S11 VERT SIG OUT jack. Position the bottom of the signal at the center of the graticule with the 7S11 DC OFF-SET control.

d. Set the 7A13 Comparison Voltage so the positive portion of the display (top of the square wave) is at the center of the graticule. e. Check that the Comparison Voltage is 1.2 volts $\pm 2\%$ (1.176 to 1.224), which is 200 mV per division of display amplitude.

f. Disconnect the probe. Set the 7A13 –Input switch to GND.

10. Check Vertical Gain Change in SMOOTH

a. Set the 7504 Vertical Mode switch to Right and the Horizontal Mode switch to A.

b. Use the 600 mV from the 50 Ω Amplitude Calibrator at the 100 Units/Div switch setting from the preceding step.

c. Push the SMOOTH switch.

d. Check that the peak amplitude does not decrease more than 3% (0.2 division of the 6 division display). Ignore any rolloff at the leading portion of the display.

If the display amplitude changes more than minus 3%, the Memory amplifier internal gain (open loop gain) is lower than it should be. Check R248 and/or transistors Q242, Q252 and Q256.

e. Reset the NORMAL switch. Disconnect the input signal and trigger signal.

11. Check Memory Slash

a. Set the 7T11 Stability control fully clockwise and the Trigger Level control for a free-running trace.

b. Turn the Trigger Level control counterclockwise to stop triggering. The trace will blank for about 3 seconds, then unblank; observe the dot vertical movement.

c. Check that the dot movement in the vertical direction does not exceed 2 divisions in 1 second (count one thousand and one).

PERFORMANCE CHECK ONLY

The remainder of the procedure requires access to internal test points and controls and is therefore part of the Calibration Procedure only.

12. Check Delay

a. Set the 7504 Vertical Mode switch to Left and the Horizontal Mode switch to B. Connect the 1X probe at the 7B50 Ext Trig In connector.

b. Set the 7A13 +Input to AC and the Volts/Div switch to 0.1 V. Connect the 10X probe at the +Input and the probe tip to test point 230, Memory Gate Driver.

c. Set the 7T11 in a real time mode (SWEEP RANGE switch in .5 ms; 5 ms or 50 ms position). Connect the 1X probe to the collector of Q422 (7S11).

d. Set the 7B50 Time/Div switch to 0.05 μ s and Triggering Source switch to Ext. Obtain a stable display, then push the Magnifier X10 switch. Observe the falling portion of the Memory Gate signal; the horizontal position is affected by the Triggering Level/Slope control.

e. Turn the 7S11 DELAY control fully counterclockwise and check that the falling portion moves to the right at least 10 ns. See Fig. 6-9.

f. Disconnect the probes. Install Q404.

13. Check/Adjust Real Time Sampling (R415)

a. Set the 7A13 Volts/Div switch to 0.2 V, the 7B50 Triggering Source switch to Int, and the Time/Div switch to 10 $\mu s.$

b. Connect the 7A13 10X probe to test point 230, see Fig. 6-7.



Fig. 6-9. Delay control range check.

c. Obtain a stable display and check that the repetition rate is 47.5 kHz \pm 10%, displayed as a period of 19 μ s to 23 μ s, measured between pulse group centers. See Fig. 6-10A.

d. Adjust Rep Rate control R415 for a period between 19 μ s and 23 μ s. See Fig. 6-7 for location. See NOTE in Real Time Sampling on page 2-7 regarding this adjustment for Type S-5 Sampling Head use.

e. Change the 7B50 Time/Div to 2 μ s. Align the second pulse at the center graticule line with the Variable Time/Div control.

f. Check that the FM deviation is within 5% and 15% of the repetition rate, determined by measuring the width of the pulses at graticule center and dividing by 5 divisions. See Fig. 6-10B.

g. Set the 7B50 Variable Time/Div control to Calibrated and set the Time/Div switch to 1 ms.

h. Place the 10X probe tip at the emitter of Q408. Obtain a stable display.

i. Check that the FM rate is between 120 Hz and 440 Hz, displayed as a period between 8.3 ms and 2.3 ms. See Fig. 6-10C.

j. Remove the probe tip.

14. Check DC Offset and Adjust Position (R325)

a. Set the 7504 Vertical Mode switch to Right and the Horizontal Mode switch to A.

b. Set the 7S11 Units/Div switch to 100. Connect the 50 Ω Amplitude Calibrator Output to the sampling head input connector through a 50 Ω coaxial cable. Set the Volts switch to 0.3. Connect the Trigger Output to the 7T11 Trig Input connector through a 50 Ω coaxial cable and BNC to 3 mm adapter.

c. Set the 7T11 Sweep Range switch to 50 μs and the Time/Div switch to 5 μs . Set the Trig Level control for a stable display.

d. Set the 7504 Vertical Mode switch to Chop. Set the 7A13 Comparison Voltage to -0000, Volts/Div switch to 50 mV, +Input switch to DC, -Input to Vc. The R_{IN} is infinite (internal switch S10). Connect the 1X probe to the +Input. Connect the probe tip to the 7S11 OFFSET OUT



Fig. 6-10. Real-time sampling checks.

jack. Set the 7S11 DC OFFSET control for zero volts out; positon the trace at graticule center.

e. Adjust Position control R325, shown in Fig. 6-11, to move the top of the displayed 7S11 signal to the center of the graticule.

f. Set the 7S11 Units/Div switch to 5 and use the Position control to again set the top of the displayed signal to the center of the graticule.

g. Turn the DC OFFSET control clockwise until the bottom of the 7S11 signal is displayed at the center of the graticule.

h. Measure the OFFSET OUT voltage. Set the 7A13 Comparison Voltage Fine control to return the trace to the center of the graticule. OFFSET OUT voltage must be 2.94 to 3.06 volts (3 volts $\pm 2\%$).

i. Set the DC OFFSET control fully clockwise and check that the OFFSET OUT voltage is at least minus 10 volts.

j. Set the 7A13 Comparison Voltage to +, turn the 7S11 DC OFFSET control fully counterclockwise, and check for at least plus 10 volts at the OFFSET OUT jack.

k. Disconnect the square wave signal.

I. Set the 7S11 Units/Div switch to 200 and set the 7T11 Stability control fully clockwise for a free-running trace.



Fig. 6-11. Control and test point locations (7511 right side) for DC OFFSET and real-time trigger checks.

Performance Check/Calibration-7S11

m. Set the DC OFFSET control for zero volts at the OFFSET OUT jack. Set the Positon control, R325, so the trace is 3 divisions below the center graticule line.

n. Turn the DC OFFSET control fully clockwise and check that the trace moves at least 5 divisions upward.

o. Reset the DC OFFSET control for zero volts at the OFFSET OUT jack. Set the Position control, R 325, so the trace is 3 divisions above the center graticule line.

p. Turn the DC OFFSET control fully counterclockwise and check that the trace moves at least 5 divisions downward.

q. Reset the DC OFFSET control for zero volts at the OFFSET OUT jack.

r. Adjust the Position control so the trace is at the center graticule line.

Normal centering range of the Position control is at least +3 divisions to -3 divisions from graticule center.

s. Disconnect the 1X probe tip. Set the 7504 Vertical Mode switch to Right.

15. Check Real-Time Trigger Amplifier Output

a. Connect the 50 Ω Amplitude Calibrator Output to the sampling head input connector through a 50 Ω coaxial cable.

b. Turn the Stability control fully counterclockwise and set the Trig Level control for a stable display.

c. Set the 50 Ω Amplitude Calibrator Volts switch to 0.12 and the 7S11 Units/Div switch to 20.

d. Set the 7504 Vertical Mode switch to Left, the 7A13 –Input to GND, and R_{IN} (S10 internal) to 1 $M\Omega$.

e. Measure the signal amplitude at +Trigger and -Trigger pins with the 1X probe and add the two amplitudes. See Fig. 6-11.

f. Check that the differential amplitude is 300 mV $\pm 10\%$

g. Disconnect the square wave signal and the 1X probe.

REPLACEABLE ELECTRICAL PARTS

PARTS ORDERING INFORMATION

Replacement parts are available from or through your local Tektronix, Inc. Field Office or representative.

Changes to Tektronix instruments are sometimes made to accommodate improved components as they become available, and to give you the benefit of the latest circuit improvements developed in our engineering department. It is therefore important, when ordering parts, to include the following information in your order: Part number, instrument type or number, serial number, and modification number if applicable.

If a part you have ordered has been replaced with a new or improved part, your local Tektronix, Inc. Field Office or representative will contact you concerning any change in part number.

Change information, if any, is located at the rear of this manual.

SPECIAL NOTES AND SYMBOLS

X000	Part first added at this serial number
00X	Part removed after this serial number

ITEM NAME

In the Parts List, an Item Name is separated from the description by a colon (:). Because of space limitations, an Item Name may sometimes appear as incomplete. For further Item Name identification, the U.S. Federal Cataloging Handbook H6-1 can be utilized where possible.

ABBREVIATIONS

ACTR	ACTUATOR	PLSTC	PLASTIC
ASSY	ASSEMBLY	QTZ	QUARTZ
CAP	CAPACITOR	RECP	RECEPTACLE
CER	CERAMIC	RES	RESISTOR
СКТ	CIRCUIT	RF	RADIO FREQUENCY
COMP	COMPOSITION	SEL	SELECTED
CONN	CONNECTOR	SEMICOND	SEMICONDUCTOR
ELCTLT	ELECTROLYTIC	SENS	SENSITIVE
ELEC	ELECTRICAL	VAR	VARIABLE
INCAND	INCANDESCENT	ww	WIREWOUND
LED	LIGHT EMITTING DIODE	XFMR	TRANSFORMER
NONWIR	NON WIREWOUND	XTAL	CRYSTAL

CROSS INDEX - MFR. CODE NUMBER TO MANUFACTURER

Mfr. Code	Manufacturer	Address	City, State, Zip Code			
00853	SANGAMO WESTON INC	Sangamo RD Po Rox 128	PICKENS SC 29671-9716			
01121	ALL EN-BRADI FY CO	1201 S 2ND ST	MTI WALKEE WT 53204-2410			
03508	GENERAL ELECTRIC CO	W GENESEE ST	AURIEN NY 13021			
00000	SEMI-CONDUCTOR PRODUCTS DEPT	W GENESEE ST	ADDORT THE ISOLI			
04222	AVY CERAMICS	19TH AVE SOUTH	MYRTLE REACH SC 29577			
UTLLL		P 0 80Y 867	MINIEL DEADIT SO 2007			
04713		5005 E MCDOWELL RD	PHOENTX A7 85008-4229			
04710	SEMICONDUCTOR PRODUCTS SECTOR	SOUS E PRODUNCEE ND	THERIN AL COUCHERS			
05397	LINTON CARRIDE CORP	11901 MADISON AVE	CIEVELAND OH 44101			
03037	MATERIALS SYSTEMS DIV					
07263	FATECHILD SEMICONDUCTOR CORP	10400 RIDGEVIEW CT	CUPERTING CA 95014			
0,200	NORTH AMERICAN SALES					
	SUB OF SCHLUMBERGER LTD MS 118					
07716	TRW INC	2850 MT PLEASANT AVE	RURIINGTON IA 52601			
0//10	TRW INC FIXED RESISTORS/BURITNGTON		BOREINGION IN GEODI			
12697	CLAROSTAT MEG CO INC	LOWER WASHINGTON ST	DOVER NH 03820			
13556		8821 SCIENCE CENTER DRIVE	MINNEAPOLIS MN 55428-3619			
10000	DIV OF TRW INC	COEL SOLENCE CENTER DATE				
14433	ITT SEMICONDUCTORS DIV		WEST PALM BEACH FL			
19701	MEPCO/CENTRALAB	PO BOX 760	MINERAL WELLS TX 76067-0760			
10/01	A NORTH AMERICAN PHILIPS CO					
	MINERAL WELLS ATROPT					
22229	SOLITEON DEVICES INC	8808 BALBOA AVE	SAN DIEGO CA 92123			
	SEMICONDUCTOR GROUP SAN DIEGO OPERS					
23880	STANFORD APPLIED ENGINEERING INC	340 MARTIN AVE	SANTA CLARA CA 95050-3112			
24546	CORNING GLASS WORKS	550 HIGH ST	BRADFORD PA 16701-3737			
24931	SPECIALTY CONNECTOR CO INC	2100 FARLYWOOD DR	FRANKLIN IN 46131			
24331	SI EGIAETT CONNECTOR CO THE	PO BOX 547				
32997	BOURNS INC	1200 COLLIMBIA AVE	RIVERSIDE CA 92507-2114			
02007	TRIMPOT DIV					
33095	SPECTRUM CONTROL INC	2185 W WEIGHT ST	ERIE PA 16505			
52763	STETCO INC	3344 SCHIERHORN	FRANKLIN PARK IL 60131			
57668	ROHM CORP	8 WHATNEY	IRVINE CA 92713			
		PO BOX 19515				
58854	GTE PRODUCTS CORP	60 BOSTON ST	SALEM MA 01970-2147			
	LIGHTING PRODUCTS GROUP					
59660	TUSONIX INC	7741 N BUSINESS PARK DR	TUCSON AZ 85740-7144			
		PO BOX 37144				
59821	MEPCO/CENTRALAB	7158 MERCHANT AVE	EL PASO TX 79915-1207			
	A NORTH AMERICAN PHILIPS CO					
71590	MEPCO/CENTRALAB INC	HWY 20 W	FORT DODGE IA 50501			
	A NORTH AMERICAN PHILIPS CO	PO BOX 858				
71744	GENERAL INSTRUMENT CORP	4433 N RAVENSWOOD AVE	CHICAGO IL 60640-5802			
	LAMP DIV/WORLD WIDE/					
73138	BECKMAN INDUSTRIAL CORP	4141 PALM ST	FULLERTON CA 92635			
	BECKMAN ELECTRONIC TECHNOLOGIES					
	SUB OF EMERSON ELECTRIC					
76854	OAK SWITCH SYSTEMS INC	100 S MAIN ST	CRYSTAL LAKE IL 60014-6201			
	AN OAK INDUSTRIES INC CO	PO BOX 517				
80009	TEKTRONIX INC	14150 SW KARL BRAUN DR	BEAVERTON OR 97077-0001			
		PO BOX 500				
98291	SEALECTRO CORP	40 LINDEMAN DR	TURNBULL CT 06611-4739			
	BICC ELECTRONICS					
TK0961	NEC ELECTRONICS USA INC	401 ELLIS ST	MOUNTAIN VIEW CA 94039			
	ELECTRON DIV	PO BOX 7241				
TK1345	ZMAN AND ASSOCIATES	7633 S 180TH	KENT WA 98032			
Component No.	Tektronix Part No	Serial/Asse	smbly No.	Num & Decemintian	Mfr. Costo	Mfm Dowt No.
------------------	----------------------------	--------------------	-----------	---	----------------	-----------------------------------
component no.	PAPL NO.	LITECTIVE	DSCOTL		Lode	MIT. PATL NO.
A1 A1	670-1088-00 670-1088-01	B010100 B110000	B109999	CIRCUIT BD ASSY:VERTICAL CIRCUIT BD ASSY:VERTICAL	80009 80009	670-1088-00 670-1088-01
A2	670-1089-00	B010100	B049999	CIRCUIT BD ASSY: INTER CHANNEL CONTROL	80009	670-1089-00
A2	670-1089-01	B050000	B079999	CIRCUIT BD ASSY INTER CHANNEL CONTROL	80009	670-1089-01
A2	670-1089-02	B080000	B0999999	CIRCUIT BD ASSY: INTER CHANNEL CONTROL	80009	670-1089-02
A2	670-1089-03	B100000	B119999	CIRCUIT BD ASSY: INTER CHANNEL CONTROL	80009	670-1089-03
A2	670-1089-04	B120000	B135354	CIRCUIT BD ASSY: INTERCHANNEL CONTROL	80009	670-1089-04
A2	670-1089-05	B135355		CIRCUIT BD ASSY: INTERCHANNEL CONTROL	80009	670-1 089- 05
A3	670-1090-00	B010100	B029999	CIRCUIT BD ASSY: INTERFACE	80009	670-1090-00
A3	670-1090-01	B030000	B039999	CIRCUIT BD ASSY: INTERFACE	80009	670-1 090 -01
A3	670-1090-02	B040000	B079999	CIRCUIT BD ASSY: INTERFACE	80009	670-1090-02
A3	670-1090-03	B080000	B099999	CIRCUIT BD ASSY: INTERFACE	80009	670-1090-03
A3	670-1 090-0 4	B100000		CIRCUIT BD ASSY:INTERFACE	80009	670-1090-04
A4	6 70- 1148-00	B010100	B019999	CIRCUIT BD ASSY:+UP-INVERT SW	80009	670-1148-00
A4	670-1148-01	B020000		CIRCUIT BD ASSY:+UP-INVERT SW	80009	670-1148-01
A5	6 70-1149-0 0	B010100	B019999	CIRCUIT BD ASSY:NORMAL-SMOOTH SW	80009	670-1149-00
A5	670-1149-01	B020000		CIRCUIT BD ASSY:NORMAL-SMOOTH SW	80009	670-1149-01
A6	670-1165-00			CIRCUIT BD ASSY:COMMUTATOR SW MOVING (NO ELECTRICAL PARTS)	80009	670-1165-00
A7	670-1166-00			CIRCUIT BD ASSY:COMMUTATOR SW FIXED (NO ELECTRICAL PARTS)	80009	670-1166-00
A1	670-1088-00 670-1088-01	B010100 B110000	B109999	CIRCUIT BD ASSY:VERTICAL	80009 80009	670-1088-00 670-1088-01
	0/0 1000 01	0110000		CINCOLL DO ADDITATENTIONE	00000	0/0 1000 01
A1C120	283-0059-00			CAP, FXD, CER DI: 1UF, +80-20%, 50V	04222	SR305C105MAA
A1C127	283-0051-00			CAP, FXD, CER DI: 0.0033UF, 5%, 100V	04222	SR301A332JAA
A1C134	283-0059-00			CAP, FXD, CER DI: 1UF, +80-20%, 50V	04222	SR305C105MAA
A1C139	283-0000-00			CAP, FXD, CER DI:0.001UF, +100-0%, 500V	59660	831-610-Y5U0102P
A1C160	283-0026-00			CAP, FXD, CER DI:0.2UF, +80~20%, 25V	04222	SR305C204MAA
A1C161	283-0059-00			CAP, FXD, CER DI:1UF, +80-20%, 50V	04222	SR305C105MAA
A1C166	283-0000-00			CAP, FXD, CER DI:0.001UF, +100-0%, 500V	59660	831-610-Y5U0102P
A1C201	283-0059-00			CAP, FXD, CER DI: 1UF, +80-20%, 50V	04222	SR305C105MAA
A1C216 A1C219	283-0059-00 283-0032-00			CAP, FXD, CER DI: 1UF, +80-20%, 50V CAP, FXD, CER, DI: 470PE, 5%, 500V	04222 59660	SR305C105MAA 831-000-75F0471.1
A1C221	292 0050 00				04000	
A10221	283-0059-00			CAD EVD CED DI.100,400-20%,000	04222	
A1C234	283-0594-00			CAP, FAD, CER DI: 10F, 400-20%, 50V	09222	D151E102E0
A1C245	283-0023-00			CAP FYD CFD DI \cdot 0 11F \pm 80-20% 12V	71590	20046681047
A1C256	281-0579-00			CAP. FXD. CFR. DI: 21 PF. 5%. 500V	52763	2RDPLZ007 21P0JC
A1C261	283-0059-00			CAP, FXD, CER DI: 1UF, +80-20%, 50V	04222	SR305C105MAA
A1C267	283-0059-00			CAP, FXD, CER. DI : 10F, +80-20%, 50V	04222	SR305C105MAA
A1C269	283-0103-00	0010100	D100000	CAP, FXD, CER DI: 180PF, 5%, 500V	59821	ZUUH/3L181J
A10272	283-0026-00	B010100	R109888	CAP, FXD, CER DI: 0.20F, +80-20%, 25V	04222	SKJUSUZUAMAA
A1C272	203-0110-00	B110000	B100000	CAP, FAU, CER DI:U. UUDUF, +80-20%, 150V	04000	000-04/-1-0022
A1C274	283-0110-00	B110000	0103223	CAP, FXD, CER DI:0.005UF, +80-20%, 25V	59660	855-547-E-502Z
A1C275	281-0092-00			CAP, VAR, CER DI : 9-35PF, 200V	33095	53-717-001 D9-35
A1C276	283-0600-00			CAP, FXD, MICA DI: 43PF, 5%, 500V	00853	D105E430J0
A10341	283-0060-00			CAP, FXD, CER D1: 100PF, 5%, 200V	59660	855-535UZJ101J
A10602	283-0004-00			CAP, FXU, CER UI: 0.020F, +80-20%, 150V	59660	000-0002002002
A1C600	290-0134-00			CAR, FAU, ELUILI: 220F, 20%, 10V	0539/	11100220001040
A10004	290-0134-00			UNF, FAU, ELUILI: 22UF, 20%, 13V	0009/	TINCENTING

Campanent No.	Tektronix Part No.	Serial/Assen Effective	bly No. Dscont	Name & Description	Mfr. Code	Mfr. Part No.
A10605	283-0059-00			CAP EXD CED DI 11/E +80-20% 50/	04222	SP3050105MAA
A10005	203-0059-00			CAR EVD CED DI 11/F 190-20% 50V	04222	SP20EC10EMAA
AICOUO	203-0059-00			CAP, FAD, CER DI: 10F, +00-20%, 50V	04222	5K303C103MMA
AIC607	290-0134-00			CAP, FXD, ELCILI: 22UF, 20%, 15V	05397	1110B226M015A5
A1C608	290-0134-00			CAP, FXD, ELCILI: 220F, 20%, 15V	05397	1110B226M015AS
A1C609	283-0059-00			CAP, FXD, CER DI: 1UF, +80-20%, 50V	04222	SR305C105MAA
A1CR128	152-0141-02			SEMICOND DVC, DI:SW, SI, 30V, 150MA, 30V, DO-35	03508	DA2527 (1N4152)
A1CR201	152 -0141-02			SEMICOND DVC, DI:SW, SI, 30V, 150MA, 30V, DO-35	03508	DA2527 (1N4152)
A1CR206	1 52-0141-02			SEMICOND DVC, DI:SW, SI, 30V, 150MA, 30V, DO-35	03508	DA2527 (1N4152)
A1CR224	152 -0141-02			SEMICOND DVC, DI:SW, SI, 30V, 150MA, 30V, DO-35	03508	DA2527 (1N4152)
A1CR226	152-0141-02			SEMICOND DVC, DI:SW, SI, 30V, 150MA, 30V, DO-35	03508	DA2527 (1N4152)
A1CR232	152-0141-02			SEMICOND DVC, DI:SW, SI, 30V, 150MA, 30V, DO-35	03508	DA2527 (1N4152)
A1CR236	152-0141-02			SEMICOND DVC, DI:SW, SI, 30V, 150MA, 30V, DO-35	03508	DA2527 (1N4152)
A1CR237	152-0323-00			SEMICOND DVC.DI:SW.SI.35V.O.1A.DO-7	14433	WG1518
A1CR238	152-0141-02			SEMICOND DVC. DI: SW. SI. 30V. 150MA. 30V. DO-35	03508	DA2527 (1N4152)
A1CR239	152-0323-00			SEMICOND DVC.DI:SW.SI.35V.0.1A.DO-7	14433	WG1518
A1CR242	152-0141-02			SEMICOND DVC. DI:SW. SI. 30V. 150MA. 30V. DO-35	03508	DA2527 (1N4152)
A1CR257	152-0141-02			SEMICOND DVC DI SW SI 30V 150MA 30V DO-35	03508	DA2527 (1N4152)
A1CR259	152-0141-02			SEMICOND DVC, DI:SW, SI, 30V, 150MA, 30V, DO-35	03508	DA2527 (1N4152)
A1CD272	152-0222-00			SEMICOND DVC DI-SU SI 25V O 1A DO-7	14423	UC1518
A1CR272	152-0323-00			SEMICOND DVC, DI.SW, SI, SSV, O.IA, DO-7	14400	WG1510
AICR2/4	152-0323-00			SEMICOND DVC, DI-SW, SI, SSV, U.IA, DU-7	02500	WG1510 DA2527 (1NA152)
ALLROUD	152-0141-02			SEMICUMD DVC, D1:5W, S1, SUV, 150MM, SUV, D0-35	00000	120,0402,00
A1L268	120-0402-00			XFMK, IURUID:	80009	120-0402-00
AIL603	120-0382-00			COIL, RF: 2100H, +28%-43%, 14 TURNS	80009	120-0382-00
A1L604	120-0382-00			COIL, RF:210UH, +28%-43%, 14 TURNS	80009	120-0382-00
A1L607	120-0382-00			COIL, RF: 210UH, +28%-43%, 14 TURNS	80009	120-0382-00
A1L608	120-0382-00			COIL,RF:210UH,+28%-43%,14 TURNS	80009	120-0382-00
A1Q123	151 -0 192-00			TRANSISTOR: NPN, SI, TO-92	0471 3	SPS8801
A1Q128	151-0188-00			TRANSISTOR: PNP, SI, TO-92	80009	151-0188-00
A1Q133	151-0190-00			TRANSISTOR: NPN, SI, TO-92	80009	151-0190-00
A1Q136	151-0188-00			TRANSISTOR: PNP, SI, TO-92	80009	151-0188-00
A1Q163	151-0190-00			TRANSISTOR:NPN,SI,TO-92	80009	151-0190-00
A1Q204	151-0190-00			TRANSISTOR: NPN, SI, TO-92	80009	151-0190-00
A10208	151-0190-00			TRANSISTOR: NPN, SI, TO-92	80009	151-0190-00
A10212	151-0190-00			TRANSISTOR: NPN, SI, TO-92	80009	151-0190-00
A10214	151-0188-00			TRANSISTOR: PNP.SI.TO-92	80009	151-0188-00
A1Q242	151-1037-00			TRANSISTOR: FET, N-CHAN, SI, TO-71	22229	FD1553
A10252	151-0261-00			TRANSISTOR: PNP.SI.TO-77	80009	151-0261-00
A10256	151-0188-00			TRANSISTOR: PNP. SL. TO-92	80009	151-0188-00
A10262	151-0190-00			TRANSISTOR NPN SI TO-92	80009	151-0190-00
A10266	151-0188-00			TRANSISTOR PNP SI TO-92	80009	151-0188-00
A10314	151_0192_00			TPANSISTOR NON SI TO-92	04713	SPS8801
A1Q334	151-0192-00			TRANSISTOR:NPN,SI,TO-92	04713	SPS8801
A10344	151-0216-00			TRANSISTOR PNP SI TO-92	04713	SPS8273
A10254	151-0210-00			TDANSISTOR. FHF, SI, 10-32	04713	51 30003
A10354	151-0216-00			TRANSISTOR: PNP, SI, TO 92	04713	SPS0003
A1Q362	151-0216-00			TRANSISTOR: PNP, SI, TO-92	04/13	5P50003
A10366	151-0216-00			TRANSISTOR: PNP, SI, TO-92	04/13	SPS8803
A1Q502	151-0188-00			TRANSISTOR: PNP, SI, TO-92	80009	151-0188-00
A1Q506	151-0190-00			TRANSISTOR:NPN,SI,TO-92	80009	151-0190-00
A1Q508	151-0188-00			TRANSISTOR: PNP, SI, TO-92	80009	151-0188-00
A1Q512	151-0188-00			TRANSISTOR: PNP, SI, TO-92	80009	151-0188-00
A1Q516	151-0281-00			TRANSISTOR: NPN, SI, 400 MILLIWATTS	80009	151-0281-00
A1Q518	151-0281-00			TRANSISTOR: NPN, SI, 400 MILLIWATTS	80009	151-0281-00
A1R121	321-0093-00			RES. FXD. FILM: 90.9 DHM. 1%.0. 125W. TC=TO	19701	5043ED90R90F
A1R123	315-0183-00			RES, FXD, FILM: 18K OHM, 5%, 0.25W	19701	5043CX18K00J
A1R125	315-0752-00			RES. FXD. FTIM: 7.5K OHM. 5% 0.25W	57668	NTR25J-E07K5
A1R127	321-0154-00			RES. FXD. FILM: 392 OHM, 1%, 0, 125W, TC=T0	07716	CEAD392R0F
A1R129	315-0512-00			RES. FXD. FILM: 5.1K OHM 5% 0.25W	57668	NTR251-E05K1
A1R130	315-0101-00			RES. EXD FILM 100 0HM 5% 0 25₩	57668	NTR251-F 100F
	010 0101-00			1201 101 101 100 0101,0/0,0.20W	3, 000	

.

	Tektronix	Serial/Asser	mbly No.		Mfr.	
Component No	D. Part No.	Effective	Dscont	Name & Description	Code	Mfr. Part No.
A1R133	315-0101-00			RES, FXD, FILM: 100 OHM, 5%, 0.25W	57668	NTR25J-E 10DE
A1R134	315-0153-00			RES, FXD, FILM: 15K 0HM, 5%, 0.25W	19701	5043CX15K00J
A1R135	315-0153-00			RES, FXD, FILM: 15K OHM, 5%, 0.25W	19701	5043CX15K00J
A1R136	315-0101- 0 0			RES, FXD, FILM: 100 OHM, 5%, 0.25W	57668	NTR25J-E 100E
A1R137	315-0101-00			RES, FXD, FILM: 100 OHM, 5%, 0.25W	57668	NTR25J-E 100E
A1R138	321-0263-00			RES, FXD, FILM: 5.36K 0HM, 1%, 0.125W, TC=T0	07716	CEAD53600F
A1R161	315-0101-00			RES. EXD. ETLM: 100.0HM.5%.0.25W	57668	NTR251-E 100F
A1R162	315-0101-00			RES. EXD. FILM: 100 OHM. 5%. 0. 25W	57668	NTR251-E 100F
A1R163	315-0123-00			RES. FXD. FILM: 12K OHM. 5%. 0.25W	57668	NTR25J-E12K0
A1R165	321-0316-00			RES, FXD, FILM: 19.1K OHM, 1%, 0.125W, TC=T0	07716	CEAD19101F
A1R166	321-0289-00			RES, FXD, FILM: 10.0K OHM, 1%, 0.125W, TC=T0	19701	5033ED10K0F
A1R202	321-0391-00			RES, FXD, FILM: 115K OHM, 1%, 0.125W, TC=T0	07716	CEAD11502F
A1R204	315-0183-00			RES EXD ETLM-18K OHM 5% 0 25W	19701	5043CX18K00.1
A1R206	315-0122-00			RES. FXD. FILM: 1.2K OHM. 5%. 0.25W	57668	NTR251-E01K2
A1R207	315-0101-00			RES.FXD.FILM:100 0HM.5%.0.25W	57668	NTR25J-E 100E
A1R208	315-0512-00			RES. FXD, FILM: 5.1K OHM, 5%, 0.25W	57668	NTR25J-E05K1
A1R209	321-0306-00			RES, FXD, FILM: 15.0K OHM, 1%, 0.125W, TC=T0	19701	5033ED15J00F
A1R211	315-0101-00			RES, FXD, FILM: 100 OHM, 5%, 0.25W	57668	NTR25J-E 100E
A1R213	315-0101-00			RES EXD ETLM-100 OHM 5% 0 254	57668	NTR251-F 100F
A1R214	315-0220-00			RES. FXD. FILM: 22. OHM. 5%. 0. 25W	19701	5043CX22R00.1
A1R216	315-0752-00			RES. FXD. FILM: 7.5K OHM. 5%. 0.25W	57668	NTR25J-E07K5
A1R218	315-0752-00			RES, FXD, FILM: 7.5K OHM, 5%, 0.25W	57668	NTR25J-E07K5
A1R219	315-0101-00			RES, FXD, FILM: 100 OHM, 5%, 0.25W	57668	NTR25J-E 100E
A1R221	321 -0245-0 0			RES, FXD, FILM: 3.48K OHM, 1%, 0.125W, TC=T0	19701	5033ED3K48F
A1R222	321-0245-00			RES. FXD. F11M: 3.48K OHM. 1%.0.125W. TC=T0	1 97 01	5033ED3K48F
A1R224	321-0231-00			RES.FXD.FILM:2.49K OHM.1%.0.125W.TC=T0	19701	5033ED2K49F
A1R226	321-0231-00			RES. FXD. FILM: 2.49K OHM. 1%. 0.125W. TC=T0	19701	5033ED2K49F
A1R229	315-0102-00			RES, FXD, FILM: 1K OHM, 5%, 0.25W	57668	NTR25JE01K0
A1R231	315-0102-00			RES, FXD, FILM: 1K OHM, 5%, 0.25W	57668	NTR25JE01K0
A1R234	315-0100-00			RES, FXD, FILM: 10 OHM, 5%, 0.25W	19701	5043CX10RR00J
A1R239	317-0510-00	B110000		RES, FXD, CMPSN:51 OHM, 5%, 0.125W	01121	BB5105
A1R242	321-0328-00			RES, FXD, FILM: 25.5K OHM, 1%, 0.125W, TC=T0	19701	5043ED25K50F
A1R244	315-0432-00			RES, FXD, FILM: 4.3K OHM, 5%, 0.25W	57668	NTR25J-E04K3
A1R245	311-0732-00	B010100	B060969	RES, VAR, NONWA: TRMR, 1K OHM, 0.5W	01121	SV1021
A1R245	311-1263-00	B060970		RES, VAR, NONWW: 1K OHM, 10%, 0.50W	32997	3329P-L58-102
A1R246	315-0432-00			RES, FXD, FILM:4.3K OHM, 5%, 0.25W	57668	NTR25J-E04K3
A1R248	315-0106-00			RES.FXD.FILM:10M OHM.5%.0.25W	01121	CB1065
A1R253	315-0101-00			RES, FXD, FILM: 100 OHM, 5%, 0.25W	57668	NTR25J-E 100E
A1R257	315-0241-00			RES, FXD, FILM: 240 OHM, 5%, 0.25W	19701	5043CX240R0J
A1R258	315-0241-00			RES,FXD,FILM:240 0HM,5%,0.25W	19701	5043CX240R0J
A1R259	315-0243-00			RES, FXD, FILM: 24K OHM, 5%, 0.25W	57668	NTR25J-E24K0
A1R261	315-0101-00			RES,FXD,FILM:100 OHM,5%,0.25W	57668	NTR25J-E 100E
A1R264	315-0101-00			RES, FXD, FILM: 100 OHM, 5%, 0.25W	57668	NTR25J-E 100E
A1R266	315-0101-00			RES, FXD, FILM: 100 OHM, 5%, 0.25W	57668	NTR25J-E 100E
A1R267	315-0101-00			RES, FXD, FILM: 100 OHM, 5%, 0.25W	57668	NTR25J-E 100E
A1R268	321-0745-03			RES, FXD, FILM: 25.05K OHM, 0.125%, 0.125W, TC=T2	19701	5033RC25K05
A1R269	321-1310-03			RES, FXD, FILM:16.7K OHM, 0.25%, 0.125W, TC=T2	19701	5033RC16K72C
A1R271	321-0360-00			RES, FXD, FILM: 54.9K 0HM, 1%, 0.125W, TC=T0	19701	5033ED54K90F
A1R272	321-0283-00			RES, FXD, FILM:8.66K 0HM, 1%, 0.125W, TC=T0	1 97 01	5043ED8K660F
A1R274	321-0283-00			RES, FXD, FILM: 8.66K OHM, 1%, 0.125W, TC=T0	19701	5043ED8K660F
A1R275	321-0360-00			RES, FXD, FILM: 54.9K 0HM, 1%, 0.125W, TC=T0	19701	5033ED54K90F
A1R301	315-0105-00			RES, FXD, FILM: 1M OHM, 5%, 0.25W	19701	5043CX1M000J
A1R302	315-0512-00			RES, FXD, FILM: 5.1K OHM, 5%, 0.25W	57668	NTR25J-E05K1
A1 R303	315-0512-00			RES, FXD, FILM: 5.1K UHM, 5%, 0.25W	5/668	NTR25J-E05K1
A1R304	315-0105-00			RES, FXD, FILM: 1M OHM, 5%, 0.25W	19701	5043CX1M000J
A1R305	311-0831-00			RES, VAR, NONWW: TRMR, 100K OHM, 0.5W	73138	91-104-0
A1R311	321-0207-00			RES, FXD, FILM: 1.40K OHM, 1%, 0.125W, TC=T0	19701	5033ED1K400F
AIR312	321-0234-00			RES, FAU, FILM: 2.6/K UHM, 1%, 0.125W, TC=10	19/01	5033ED2K6/F

	Tektronix	Serial/Asser	ndly No.		Mfr.		-
<u>Component No.</u>	Part No.	_Effective	Dscont	Name & Description	Code	Mfr. Part No.	_
A1R314	321-0194-00			RES. FXD. FTLM: 1.02K_0HM. 1%.0.125W. TC=T0	07716	CEAD10200F	
A1R316	321-0371-00			RES. FXD. FILM: 71.5K 0HM. 1%.0.125W. TC=T0	07716	CEAD71501F	
A1R317	321-0372-00			RES. FXD. FILM: 73.2K 0HM. 1%.0.125W. TC=T0	07716	CEAD73201F	
A1R319	315-0243-00			RES. FXD. FILM: 24K OHM. 5%. 0. 25W	57668	NTR25J-E24K0	
A1R321	321-0251-00			RES. FXD. FILM: 4.02K 0HM. 1%.0.125W. TC=T0	19701	5033ED4K020F	
A1R322	321-0191-00			RES, FXD, FILM:953 OHM, 1%, 0.125W, TC=T0	07716	CEAD953R0F	
A1R325	311-0883-00			RES VAR NONWY TRMR 50K OHM 0 5W	01121	SV5031	
A1R326	321-0191-00			RES. EXD. ETI M-953 OHM. 1% 0. 125W. TC=T0	07716	CEAD953R0F	
A1R332	315-0684-00			RES FXD FILM 680K 0HM 5% 0 25W	01121	CB6845	
A1R334	321-0194-00			RES FXD FILM:1 02K 0HM 1% 0 125W TC=T0	07716	CFAD10200F	
A1R336	321-0371-00			RES EXD FILM:71 5K OHM 1% 0 125W TC=T0	07716	CFAD71501F	
A1R337	321-0372-00			RES, FXD, FILM: 73.2K OHM, 1%, 0.125W, TC=T0	07716	CEAD73201F	
A1R339	315-0243-00			RES EXD ETLM-24K OHM 5% 0 25W	57668	NTR251-F24K0	
A1R343	321-0238-00			RES FYD FILM-2 94K OHM 1% O 125W TC=TO	07716	CEAD29400E	
A1R344	321-0146-00			RES FXD FILM: 324 OHM 1% 0 125W TC=T0	07716	CFAD324R0F	
A1R346	321-0209-00			RES FXD FILM 1 47K OHM 1% 0 125W TC=T0	19701	5033FD1K47F	
A1R353	321-0238-00			PES FYD FILM-2 94K 0HM 1% 0 125W TC=TO	07716	CEAD29400E	
A1R356	321-0209-00			RES, FXD, FILM: 1.47K OHM, 1%, 0.125W, TC=TO	19701	5033ED1K47F	
A1R362	321-0222-00			RES EXD ETIM-2 OOK OHM 1% O 125W TC=TO	19701	5033ED2K00E	
A10363	321-0251-00			DES EVD ETIM A 02K OHM 1% 0 125W TC-TO	10701	5033ED4K020E	
A10365	321-0251-00			DES EVD ETIM-4 02K 0HM 19 0 125W TC+TO	19701	5033ED4K020F	
A1D366	321-0231-00			DES EVD ETIM-2 OOK OHM 1% 0 1254 TO-TO	10701	5033ED2K00E	
A1R300 A1R368	321-0222-00			DES EVD ETLM.257 OLM 19 0 1254 TC-TO	07716	CEAD257DOE	
A10501	315-0693-00			DES EVD ETIMISON OUM 5% A 25U	57669	NTD251_E69K0 -	
AIROOI	515-0005-00			RES, FAD, FILM, OOK ONN, 5%, 0.25W	37000		
A1R502	315-0104-00			RES, FXD, FILM: 100K OHM, 5%, 0.25W	57668	NTR25J-E100K	
A1R503	315 -0474- 00			RES,FXD,FILM:470K 0HM,5%,0.25W	19701	5043CX470K0J92U	
A1R504	317-0105-00			RES, FXD, CMPSN: 1M OHM, 5%, 0.125W	01121	BB1055	
A1R505	315 -015 4-00			RES,FXD,FILM:150K 0HM,5%,0.25W	57668	NTR25J-E150K	
A1R506	321-0399-00			RES, FXD, FILM: 140K OHM, 1%, 0.125W, TC=T0	07716	CEAD14002F	
A1R508	321-0373-00			RES,FXD,FILM:75.0K 0HM,1%,0.125W,TC=T0	19701	5033ED75K00F	
A1R509	315-0105-00			RES, FXD, FILM: 1M OHM, 5%, 0.25W	19701	5043CX1M000J	
A1R515	321-0223-00			RES, FXD, FILM: 2.05K OHM, 1%, 0.125W, TC=T0	19701	5033ED2K05F	
A1R516	321-0299-00			RES,FXD,FILM:12.7K OHM,1%,0.125W,TC=T0	19701	5033ED12K70F	
A1R517	321-0346-00			RES, FXD, FILM: 39.2K OHM, 1%, 0.125W, TC=T0	19701	5043ED39K20F	
A1R518	321-0346-00			RES, FXD, FILM: 39.2K OHM, 1%, 0.125W, TC=T0	19701	5043ED39K20F	
A1R602	315-0101-00			RES, FXD, FILM:100 OHM, 5%, 0.25W	57668	NTR25J-E 100E	
A1R605	315-0101-00			RES, FXD, FILM: 100 OHM, 5%, 0.25W	57668	NTR25J-E 100E	
A1R606	315-0101-00			RES, FXD, FILM: 100 OHM, 5%, 0.25W	57668	NTR25J-E 100E	
A1R609	315-0101-00			RES, FXD, FILM: 100 OHM, 5%, 0.25W	57668	NTR25J-E 100E	
A1T230	120-0547-00			XFMR, TOROID:	TK1345	120-0547-00	
A1VR221	152-0226-00			SEMICOND DVC, DI:ZEN, SI, 5.1V, 5%, 0.4W, DO-7	047 13	SZ12262RL	
A2	670-1089-00	B010100 E	3049999	CIRCUIT BD ASSY: INTER CHANNEL CONTROL	80009	670-1089-00	
A2	670-1089-01	B050000 E	3079999	CIRCUIT BD ASSY: INTER CHANNEL CONTROL	80009	670-1089-01	
A2	670-1089-02	B080000 E	3099999	CIRCUIT BD ASSY: INTER CHANNEL CONTROL	80009	670-1089-02	
A2	670-1089-03	B100000 E	3119999	CIRCUIT BD ASSY: INTER CHANNEL CONTROL	80009	670-1089-03	
A2	670-1089-04	B120000 E	3135354	CIRCUIT BD ASSY: INTERCHANNEL CONTROL	80009	670-1089-04	
A2	670-1089-05	B135355		CIRCUIT BD ASSY: INTERCHANNEL CONTROL	80009	670-1089-05	
A2C159	283-0026-00			CAP, FXD, CER DI:0.2UF, +80-20%, 25V	04222	SR305C204MAA	
A2C406	283-0059-00			CAP, FXD, CER DI: 1UF, +80-20%, 50V	04222	SR305C105MAA	
A2C411	283-0065-00			CAP, FXD, CER DI: 0.001UF, 5%, 50V	59660	0835-591Y5E0102J	
A2C414	283-0081-00			CAP, FXD, CER DI:0.1UF, +80-20%, 25V	59821	2DDU69E104Z	
A2C418	283-0054-00			CAP, FXD, CER DI: 150PF, 5%, 200V	59660	855-535 U2J0151J	
A2C423	283-0060-00			CAP, FXD, CER DI: 100PF, 5%, 200V	59660	855-535U2J101J	
A2C427	283-0060-00			CAP, FXD, CER DI: 100PF, 5%, 200V	59660	855-535U2J101J	
A2C431	283-0032-00			CAP, FXD, CER DI: 470PF, 5%, 500V	59660	831-000-Z5E0471J	
A2C432	283-0175-00	B100 0 00		CAP,FXD,CER DI:10PF,5%,200V	05397	C312C100D2G5CA 8	
A2C434	283-0109-00			CAP,FXD,CER DI:27PF,5%,1000V	59660	858-534C0G0270J	

_

	Tektronix	Serial/Asse	ndbly No.		Mfr.	
<u>Component No.</u>	Part No.	Effective	Dscont	Name & Description	Code	Mfr. Part No.
A2C444	283-0032-00			CAP FYD CFR DI 470PE 5% 500V	59660	831-000-75F0471.1
A2CAA7	283-0115-00			CAD EYD CED DI: 470F 5% 200V	50821	200T60K470.1
	203-0113-00			CAR FYD CED DI.11/F .90 20% EOV	040001	
A20449	203-0059-00			CAP, FAD, CER DI 10F, +00-20%, 50V	50600	3K3U3U1U3MMA
A20451	203-0032-00			CAP, FAD, CER DI 100PF, 5%, 500V	59000	031-000-23E04/1J
A2045/	283-0103-00			CAP, FXD, CER DI: 180PF, 5%, 500V	59821	200H/3L181J
A2C460	283-0109-00			CAP, FXD, CER DI:27PF, 5%, 1000V	59660	858-53400602/00
A2C471	281-0579-00	B010100	B099999	CAP, FXD, CER DI:21PF, 5%, 500V	52763	2RDPLZ007 21POJC
A2C471	281-0605-00	B100000		CAP. FXD. CER DI: 200PF. 10%. 500V	59660	301000Y5D201K
A2C476	283-0060-00	B010100	B099999	CAP. FXD. CER DI: 100PF. 5%. 200V	59660	855-5350201010
A2C479	283-0060-00	B010100	B099999	CAP. FXD. CFR. DI : 100PF . 5% . 200V	59660	855-5350231013
A2C621	283-0059-00		2000000	CAP. FXD. CER. DI 11/E +80-20% 50V	04222	SR305C105MAA
A2C629	290-0134-00			CAP, FXD, ELCTLT: 22UF, 20%, 15V	05397	T110B226M015AS
100605	282-0050-00				04222	
A20000	203-0059-00			CAP, FXD, CER DI 1UF, TOU-20%, DUV	04222	SR303C105MAA
A20030	283-0059-00			CAP, FXD, LER DI: 10F, +80-20%, 50V	04222	SKOUDLIUDMAA
A20637	283-0059-00			CAP, FXD, CER DI: 10F, +80-20%, 50V	04222	SR305C105MAA
A2C638	283-0059-00			CAP, FXD, CER D1: 10F, +80-20%, 50V	04222	SR305C105MAA
A2CR401	152-0141-02			SEMICOND DVC, DI:SW, SI, 30V, 150MA, 30V, DO-35	03508	DA2527 (1N4152)
A2CR402	152-0141-02			SEMICOND DVC, DI:SW, SI, 30V, 150MA, 30V, DO-35	03 50 8	DA2527 (1N4152)
A2CR403	152-0141-02			SEMICOND DVC, DI:SW, SI.30V, 150MA, 30V, DO-35	03508	DA2527 (1N4152)
A2CR410	152-0141-02			SEMICOND DVC.DI:SW.SI.30V.150MA.30V.DO-35	03508	DA2527 (1N4152)
A2CR411	152-0141-02			SEMICOND DVC.DI:SW.SI.30V.150MA.30V.DO-35	03508	DA2527 (1N4152)
A2CR413	152-0141-02			SEMICOND DVC. DI : SW. SI . 30V. 150MA . 30V. DO-35	03508	DA2527 (1N4152)
A2CR414	152-0141-02			SEMICOND DVC DI SW ST 30V 150MA 30V DO-35	03508	DA2527 (1N4152)
A2CR425	152-0141-02			SEMICOND DVC, DI:SW, SI, 30V, 150MA, 30V, DO-35	03508	DA2527 (1N4152)
1200120	152-0141-02			SENTCOND DVC DI-SH ST 20V 150MA 20V DO-25	03508	DA2527 (1N4152)
A20R423	152-0141-02			SEMICOND DVC DI CU CI 201 150MA, 304 DO 25	03500	DA2527 (1N4152) DA2527 (1N4152)
A20R430	152-0141-02			SEMICUMD DVC, DI:SW, SI, SUV, ISUMA, SUV, DO-35	03500	DA2527 (104152)
A2UR434	152-0141-02			SEMILUNU DVC, DI:SW, SI, SUV, ISUMA, SUV, DU-35	03506	DA2527 (1N4152)
A2UR444	152-0141-02			SEMICUND DVC, DI:SW, SI, 30V, 150MA, 30V, DU-35	03508	DA2527 (IN4152)
A2CR455	152-0141-02			SEMICOND DVC, DI:SW, SI, 30V, 150MA, 30V, DO-35	03508	DA2527 (1N4152)
A2CR462	152-0141-02			SEMICOND DVC, DI:SW, SI, 30V, 150MA, 30V, DO-35	03508	DA2527 (1N4152)
A2CR464	152-0141-02			SEMICOND DVC DI-SW SI 30V 150MA 30V DO-35	03508	DA2527 (1N4152)
A2CR471	152-0141-02			SEMICOND DVC, DI-SW, SI, SOV, ISONA, SOV, DO 35	03200	DA2527 (1N4152)
A2CR474	152-0141-02	B100000		SEMICOND DVC DI SW SI 30V 150MA 30V DO-35	03508	DA2527 (1N4152)
A2CD475	152-0141-02	B125255		SEMICOND DVC,DI.SW,SI,SUV,ISUMA,SUV,DU-35	03500	DA2527 (1N4152)
A2CR475	152-0141-02	B133333	P000000	SEMICOND DVC, DI. SW, SI, SUV, ISUMA, SUV, DU-SS	03200	DA2527 (1N4152) DA2527 (1N4152)
A2UR470	152-0141-02	D010100	D099999	SEMICUMD DVC, DI:SW, SI, SUV, ISUMA, SUV, DU-35	03508	DA2527 (1N4152)
AZUR479	152-0141-02			SEMICOND DVC, DI:SW, SI, 30V, ISOMA, 30V, DU-35	03508	DA2527 (IN4152)
A2CR624	152-0141-02			SEMICOND DVC, DI:SW, SI, 30V, 150MA, 30V, DO-35	03508	DA2527 (1N4152)
A2CR625	152-0141-02			SEMICOND DVC, DI:SW, SI, 30V, 150MA, 30V, DO-35	03508	DA2527 (1N4152)
A2Q404	151-0190-00			TRANSISTOR: NPN, SI, TO-92	80009	151-0190-00
A2Q408	151-0190-00			TRANSISTOR: NPN, SI, TO-92	80009	151-0190-00
A2Q410	151-0190-00		~	TRANSISTOR: NPN. SI. TO-92	80009	151-0190-00
A20422	151-0188-00			TRANSISTOR: PNP, SI, TO-92	80009	151-0188-00
A20430	151-0190-00	B010100	B049999	TRANSISTOR NPN SI TO-92	80009	151-0190-00
A20430	151-0260-00	B050000	RAQQQQQ	TDANSISTOD NON SI TO-02	TKOOGI	41632BD
A20430	151-0203-00	B100000	00555555	TRANSISTOR NEW ST TO 70	04712	41032DD
A20452	151-0441-00	010000		TDANCICTOD.DND CT TO 02	04/13	151_0199_00
A20452	151-0100-00			TRANSISTUK: MP, SI, TU-92	80009	151-0108-00
A20400	151-0190-00			TRANSISTUR: NPN, SI, TU-92	80009	151-0190-00
A2Q404	151-0100-00			1KANSISIUK: MP, 51, 10-92	80009	151-0188-00
A2Q474	151-0190-00	B010100	B135354	TRANSISTOR:NPN,SI,TO-92	80009	151-0190-00
A2Q474	151-0223-00	B135355		TRANSISTOR:NPN,SI,625MW,TO-92	80009	151-0223-00
A2Q476	151-0190-00	B100000	B135354	TRANSISTOR:NPN,SI,TO-92	80009	151-0190-00
A20476	151-0223-00	B135355		TRANSISTOR: NPN. SI. 625MW. TO-92	80009	151-0223-00
A20477	151-0301-00	B100000	B135354	TRANSISTOR: PNP. SI. TO-18	80009	151-0301-00
A2Q477	151-0202-00	B135355		TRANSISTOR: PNP, SI, TO-72	04713	SS2025
A20478	151-0190-00			TRANSISTOR NON SI TO-92	80009	151-0190-00
A20624	151-0261-00			TRANSISTOR PNP SI TO-77	80009	151-0261-00
A20626	151-0134-00			TRANSISTOR: PNP. SI TO-39	04713	SM3195
A2R159	315-0101-00			RES EXD ETLM-100 OHM 5% 0 25	57668	NTR251-F 100F
	210 0101 00			A state and a state of the stat	5,500	

o	Tektronix	Serial/Ass	embly No.		Mfr.	
Component No.	Part No.	Effective	Discont	Name & Description	Code	Mfr. Part No.
A2R401	317-0103-00			RES, FXD, CMPSN: 10K OHM, 5%, 0125W	01121	BB1035
A2R402	317-0750-00			RES, FXD, CMPSN: 75 OHM, 5%, 0.125W	01121	BB7505
A2R404	321-0402-00			RES, FXD, FILM: 150K DHM, 1%, 0.125W, TC=T0	19701	5033ED150K0F
A2R410	317-0750-00			RES, FXD, CMPSN: 75 0HM, 5%, 0.125W	01121	BB/505
A2R411	31/-0103-00			RES, FXD, CMPSN: LUK, UHM, 5%, U125W	01121	
AZK414	315-04/3-00			RES, FXD, FILM: 4/K UHM, 5%, U.25W	5/000	NTR25J-E4/KU
A2R415	311-0831-00	B010100	8059999	RES. VAR. NONWA: TRMR. 100K OHM. 0.5W	73138	91-104-0
A2R415	311-1272-00	B060000	500000	RES. VAR. NONWW: TRMR. 100K OHM. 0.5W	32997	3329P-L58-104
A2R418	317-0512-00			RES. FXD. CMPSN: 5.1K 0HM. 5%. 0.125	01121	BB5125
A2R422	317-0103-00			RES, FXD, CMPSN: 10K 0HM, 5%, 0125W	01121	BB1035
A2R423	317-0132-00			RES, FXD, CMPSN: 1.3K OHM, 5%, 0.125W	01121	BB1325
A2R427	317-0132-00			RES,FXD,CMPSN:1.3K OHM,5%,0.125W	01121	BB 1325
100100	21E 0201 00			DEC EXD ETHN 200 OLM EN O 251	57660	NTR2E 1 E200E
A2R430 A2D421	315-0201-00			DES EVD EILMILK OHM 5% O 25W	57669	NTD25 1E01K0
A2R431 A2D424	215-0102-00	8010100	R040000	DES EVD ETIMAL 2K OHM 5% 0 254	57669	NTD251_E01K2
A2R434 A2D/3/	315-0122-00	B050000	00499999	DES EVD ETLM-1 5K 0HM 5% 0 25W	57668	NTP251-F01K5
Δ2241	315-0511-00	000000		RES FYD FILM 510 OHM 5% 0 254	19701	50430251080.1
A2R442	315-0153-00			RES. FXD. FILM: 15K OHM. 5%. 0. 25W	19701	5043CX15K00J
	010 0100 00					
A2R446	315-0204-00			RES, FXD, FILM: 200K OHM, 5%, 0.25W	19701	5043CX200K0J
A2R451	315- 0 513-00			RES,FXD,FILM:51K OHM,5%,0.25W	57668	NTR25J-E51K0
A2R452	315-0101-00			RES, FXD, FILM: 100 OHM, 5%, 0.25W	57668	NTR25J-E 100E
A2R453	315-0243-00			RES, FXD, FILM: 24K 0HM, 5%, 0.25W	57668	NTR25J-E24K0
A2R455	315-0432-00			RES, FXD, FILM: 4.3K OHM, 5%, 0.25W	57668	NTR25J-E04K3
A2R45/	315-04/2-00			RES,FXD,FILM:4.7K OHM,5%,0.25W	5/668	N/R25J-E04K/
A2R460	311-0950-00	B010100	B059999	RES.VAR.NONWW:TRMR.10K OHM.0.5W	73138	91B R10K
A2R460	311-1268-00	B060000		RES, VAR, NONWY: TRMR, 10K OHM, 0.5W	32997	3329P-L58-103
A2R461	315-0272-00			RES, FXD, FILM: 2.7K OHM, 5%, 0.25W	5 7668	NTR25J-E02K7
A2R462	315-0223-00			RES, FXD, FILM: 22K OHM, 5%, 0.25W	19701	5043CX22K00J92U
A2R464	315 -0 331-00			RES, FXD, FILM: 330 OHM, 5%, 0.25W	57668	NTR25J-E330E
A2R470	315-0201-00	B120000		RES,FXD,FILM:200 OHM,5%,0.25W	57668	NTR25J-E200E
A2R471	315-0124-00			RES EXD ETLM-120K OHM 5% 0 25W	19701	5043CX120K0.3
A2R472	317-0104-00			RES. FXD. CMPSN: 100K OHM. 5%-0. 125W	01121	BB1045
A2R474	317-0202-00	B010100	B099999	RES. FXD. CMPSN: 2K 0HM. 5%. 0. 125W	01121	BB2025
A2R474	317-0102-00	B100000		RES.FXD.CMPSN:1K OHM.5%.0125W	01121	BB1025
A2R475	317-0103-00	B100000		RES, FXD, CMPSN: 10K OHM, 5%, 0125W	01121	BB1035
A2R476	317-0153-00	B010100	B135354	RES, FXD, CMPSN: 15K OHM, 5%, 0.125W	01121	BB1535
A2R476	317-0103-00	B135355		RES, FXD, CMPSN: 10K OHM, 5%, 0125W	01121	BB1035
120178	315-0362-00			DES EVD ETIMIS OF OHN 5% O 254	10701	50430326001
A2R470	317-0511-00	8010100	RAQQQQQ	RES EXD (MPSN-510 0HM 5% 0 1254	01121	BB5115
A2R621	321-0632-00	0010100	0000000	RES FXD FILM 9 41K OHM 0 5% 0 125W TC=T2	19701	5033RC9K410C
A2R622	321-0601-00			RES. FXD. FILM:2 141K 0HM.0 25%.0.125₩.TC=T2	19701	5033RC2K141C
A2R624	321-0236-00			RES, FXD, FILM: 2.80K OHM, 1%, 0.125W, TC=T0	07716	CEAD28000F
A2R626	321-0315-00			RES, FXD, FILM: 18.7K OHM, 1%, 0.125W, TC=T0	19701	5043ED18K70F
A2D627	315_0190_00			DEC EVD ETIM. 18 OLIN EV O 251	10701	50/30V190001
A2D620	315-0100-00			RES, RAU, FILMIS OUTH, 3%, U.20W DES EVD ETIMIS 1K OLMIEV O 2ELI	13/01	
A2R025	315-0312-00			DES EVD ETIMANT OHM 5% O 254	57668	NTP251-F47F0
A2R636	315-0101-00			RES FXD FILM.100 0HM 5% 0 25	57668	NTR251-F 100F
A2R638	315-0101-00			RES EXD FILM:100 OHM 5% 0 25W	57668	NTR251-F 100F
A2T400	120-0650-00			XFMR, TOROID:	80009	120-0650-00
A2T410	120-0497 00			VEND TODOLD.	80000	120-0487-00
A2T430	120-0487-00			XFMR.TOROID:	80009	120-0546-00
A3	670-1090-00	B010100	B029999	CIRCUIT BD ASSY: INTERFACE	80009	670-1090-00
A3	670-1090-01	B030000	B039999	CIRCUIT BD ASSY: INTERFACE	80009	670-1090-01
A3	670-1090-02	B040000	B079999	CIRCUIT BD ASSY: INTERFACE	80009	670-1090-02
AJ	670-1090-03	B080000	R033333	CIRCUIT BD ASSY: INTERFACE	80009	670-1090-03
AJ	6/0-1090-04	B100000		CIRCUIT BU ASST:INTERFACE	80009	0/0-1090-04

.

	Tektronix	Serial/Asser	nbly No.		Mfr.	115 5 (11
<u>Camponent No.</u>	Part No.	Effective	Dscont	Name & Description	Code	Mfr. Part No.
A3C104	283-0003-00			CAP.FXD.CER DI:0.01UF.+80-20%.150V	59821	D103Z40Z5UJDCEX
A3C115	283-0072-01			CAP, FXD, CER DI:0.010F, +80-20%, 200V	59660	8300-201Z5V0103M
A3C631	290-0327-00			CAP. FXD. ELCTLT: 0.56UF. 20%. 100V	05397	T110A564M100AS
A3C632	290-0134-00			CAP. FXD. ELCTLT: 22UF. 20%. 15V	05397	T110B226M015AS
A3C634	283-0059-00			CAP, FXD, CER DI: 1UF, +80-20%, 50V	04222	SR305C105MAA
A3C639	290-0327-00			CAP, FXD, ELCTLT: 0.56UF, 20%, 100V	05397	T110A564M100AS
A3CR108	152-0141-02			SEMICOND DVC, DI:SW, SI, 30V, 150MA, 30V, DO-35	03508	DA2527 (1N4152)
A3CR113	152-0141-02			SEMICOND DVC, DI:SW, SI, 30V, 150MA, 30V, DO-35	03508	DA2527 (1N4152)
A3CR115	152-0141-02			SEMICOND DVC, DI:SW, SI, 30V, 150MA, 30V, DO-35	03508	DA2527 (1N4152)
A3CR116	152-0153-00			SEMICOND DVC, DI:SW, SI, 10V, 50MA, . DO-7	07263	FD7003
A3CR528	152-0141-02	B040000		SEMICOND DVC, DI:SW, SI, 30V, 150MA, 30V, DO-35	03508	DA2527 (1N4152)
A3J101	131-0391-00			CONN, RCPT, ELEC: SNAP-ON, MALE, BULK PACK	24931	32JR105-1
A3J114	131-0391-00			CONN, RCPT, ELEC: SNAP-ON, MALE, BULK PACK	24931	32JR105-1
A3L631	120-0382-00			CUIL, RF: 2100H, +28%-43%, 14 TURNS	80009	120-0382-00
A3L632	120-0382-00			CUIL, RF: 2100H, +28%-43%, 14 TURNS	80009	120-0382-00
A3L039	120-0382-00			CUIL, RF: 2100H, +28%-43%, 14 TURNS	80009	120-0382-00
A30108 A20112	151-0188-00			TRANSISTOR: PNP, SI, TO 02	80009	151-0100-00
ASQIIS	151-0108-00			TRANSISTOR: PNP, 51, 10-92	00009	151-0100-00
A3Q116	151-0207-00			TRANSISTOR:NPN,SI,TO-92	57 66 8	XD11BCP0207
A3R101	317-0124-00			RES, FXD, CMPSN: 120K OHM, 5%, 0.125W	01121	BB1245
A3R102	317-0244-00			RES, FXD, CMPSN: 240K OHM, 5%, 0.125W	01121	BB2445
A3R104	317-0153-00			RES, FXD, CMPSN: 15K OHM, 5%, 0.125W	01121	BB1535
A3R106	317-0153-00			RES, FXD, CMPSN: 15K OHM, 5%, 0.125W	01121	BB1535
A3R107	317-0151-00	B030000		RES, FXD, CMPSN: 150 OHM, 5%, 0.125W	01121	BB1515
A3R108	317-0302-00			RES. FXD. CMPSN: 3K OHM. 5%. 0. 125W	01121	BB3025
A3R109	317-0152-00			RES. FXD. CMPSN: 1.5K OHM. 5%. 0. 125W	01121	BB1525
A3R111	315-0203-00			RES. FXD. FILM: 20K OHM. 5%. 0.25W	57668	NTR25J-E 20K
A3R113	315-0122-00			RES, FXD, FILM: 1.2K DHM, 5%, 0.25W	57668	NTR25J-E01K2
A3R114	321- 0 206-00			RES, FXD, FILM: 1.37K OHM, 1%, 0.125W, TC=T0	07716	CEAD13700F
A3R115	317-0431-00			RES, FXD, CMPSN: 430 OHM, 5%, 0.125W	01121	BB4315
A3R116	315-0390-00			RES,FXD,FILM:39 0HM,5%,0.25W	57668	NTR25J-E39E0
A3R320	311-0585-00			RES, VAR, NONWAY: PNL, 15K OHM, 0.25W	59821	BA201061
A3R512	321-0402-00			RES, FXD, FILM: 150K OHM, 1%, 0.125W, TC=T0	19701	5033ED150K0F
A3R513	321-0402-00			RES, FXD, FILM: 150K OHM, 1%, 0. 125W, TC=T0	19701	5033ED150K0F
A3R519	321-0339-00			RES, FXD, FILM: 33.2K OHM, 1%, 0.125W, TC=T0	07716	CEAD33201F
A3R521	321-0373-00			RES,FXD,FILM:75.0K OHM,1%,0.125W,TC=T0	19701	5033ED75K00F
A3R527	321-0373-00			RES, FXD, FILM: 75.0K 0HM, 1%, 0.125W, TC=T0	19701	5033ED75K00F
A3R528	321-0304-00			RES, FXD, FILM: 14.3K OHM, 1%, 0.125W, TC=T0	19701	5033ED14K30F
A3R529	321-0402-00			RES, FXD, FILM: 150K OHM, 1%, 0.125W, TC=T0	19701	5033ED150K0F
A3R531	321-0373-00			RES, FXD, FILM: 75.0K 0HM, 1%, 0.125W, TC=T0	19701	5033ED75K00F
A3R533	321-0402-00			RES, FXD, FILM: 150K 0HM, 1%, 0.125W, TC=T0	19701	5033ED150K0F
A3R535	321-0402-00			RES, FXD, F1LM: 150K OHM, 1%, 0.125W, TC=T0	19701	5033ED150K0F
A3R537	321-0356-00			RES, FXD, FILM:49.9K OHM, 1%, 0.125W, TC=T0	19701	5033ED49K90F
A3R539	321-0344-00			RES,FXD,FILM:37.4K OHM,1%,0.125W,TC=T0	19701	5033ED 37K40F
A3R551	315-0510-00			RES, FXD, FILM:51 OHM, 5%, 0.25W	19701	5043CX51R00J
A3R561	315-0510-00			RES, FXD, FILM:51 OHM, 5%, 0.25W	19701	5043CX51R00J
A3R634	315-01 00-0 0			RES, FXD, FILM: 10 OHM, 5%, 0.25W	19701	5043CX10RR00J
A4	670-1148-00	B010100 E	3019999	CIRCUIT BD ASSY:+UP-INVERT SW	80009	670-1148-00
A4	670-1148-01	B020000		CIRCUIT BD ASSY:+UP-INVERT SW	80009	670-1148-01
				·····		
A4DS302	150-0057-01	B010100 E	8019999	LAMP, INCAND: 5V, 0.115A, WIRE LD, AGED & SEL	71744	7153 AS 15
A4DS302	150-0048-01	8020000		LAMP, INCAND: 5V, 0.06A, #683, AGED & SEL	58854	683AS15
A4S302				(NUI REPLACEABLE - SEE A4 REPL)		
A5	6 70- 11 49-0 0	B010100 E	8019999	CIRCUIT BD ASSY:NORMAL-SMOOTH SW	80009	670-1149-00
A5	670-114 9-01	B020000		CIRCUIT BD ASSY:NORMAL-SMOOTH SW	80009	670-1149-01

<u>Component No.</u>	Tektronix Part No.	Serial/Ass Effective	embly No. Dscont	Name & Description	Mfr. Code	Mfr. Part No.
A5DS116	150-0057-01	B010100	B019999	LAMP INCAND 5V 0 1154 WIRE ID AGED & SEL	71744	7153 AS 15
A5DS116	150-0048-01	B020000	0010000	AMP INCANDISV, 0.110A, WIRE ED, AUED & SEE	58854	6834515
A5DS110	150-0040-01	B010100	P010000	LAMP INCAND. SV, 0.007, 7000, AGED & SEL	71744	7152 AS 15
A505141	150-0037-01	B010100	D019999	LAMP, INCAND. SV, 0.113A, WIRE LD, AGED & SEL	/1/44 E00EA	7133 A3 13 602A015
ADUS141	100-0040-01	BU20000		LAMP, INCANDIOV, U. UOA, #000, AGEU & SEL	01101	0034313
A5R141	317-0222-00			RES, FXD, CMPSN: 2.2K UHM, 5%, U.125W	01121	BB2225
A5R142	317-0681-00			RES,FXD,CMPSN:680 OHM,5%,0.125W	01121	BB6815
A5S141				(NOT REPLACEABLE - SEE A5 REPL)		
A6	670-1165-00			CIRCUIT BD ASSY:COMMUTATOR SW MOVING (NO ELECTRICAL PARTS)	80009	670-1165-00
A7	670-1166-00			CIRCUIT BD ASSY:COMMUTATOR SW FIXED (NO ELECTRICAL PARTS)	80009	670-1166-00
C149	283-0103-00			CAP, FXD, CER DI: 180PF, 5%, 500V	59821	2DDH73L181J
CR476	152-0141-02	B010100	B099999	SEMICOND DVC, DI:SW, SI.30V.150MA.30V.DO-35	03508	DA2527 (1N4152)
J100	131-0410-00			CONN, RCPT, ELEC: COAXIAL CONTACTS, RTANG PILIG	13556	DM53741-5001
J120	131-0581-00			CONN. RCPT. ELEC. EDGECARD. 6/12 CONT. 0.156 SP	23880	MMM6D/1-2TX
J165	131-0779-00			JACK. TIP: U/W 0 08 OD TEST POINT	98291	0168010000208
J166	131-0779-00			JACK, TIP: U/W 0.08 OD TEST POINT	98291	0168010000208
J269	131-0779-00			JACK, TIP: U/W 0.08 OD TEST POINT	98291	0168010000208
J449	131-0391-00	B080000		CONN.RCPT.ELEC:SNAP-ON.MALE.BULK PACK	24931	32JR105-1
R143	311-0095-00			RES. VAR. NONWY: PNL. 500 OHM. 0. 5W	01121	WA1N048S501UZ
R145	321-0193-00			RES, FXD, FILM: 1K OHM, 1%, 0.125W, TC=T0	19701	5033ED1K00F
R145	321-0231-00			(R145R ONE) RES, FXD, FILM: 2.49K OHM, 1%, 0.125W, TC=TO	19701	5033ED2K49F
R145	321-0260-00			(R1450 ONE) RES,FXD,FILM:4.99K OHM,1%,0.125W,TC=TO	19701	5033ED4K990F
R145	321-0289-00			(R143C ONLT) RES, FXD, FILM:10.0K OHM, 1%, 0.125W, TC=TO	19701	5033ED10K0F
R145	321-0327-00			(R145D ONLT) RES, FXD, FILM:24.9K OHM, 1%, 0.125W, TC=TO	07716	CEAD24901F
R145	321-0356-00			(R145E ONLT) RES, FXD, FILM:49.9K OHM, 1%, 0.125W, TC=TO	19701	5033ED49K90F
R145	321-0385-00			(R145F UNLT) RES,FXD,FILM:100K OHM,1%,0.125W,TC=TO (R145G ONLY)	19701	5033ED100K0F
R147	321- 0450- 01			RES, FXD, FILM: 475K OHM, 0.5%, 0.125W, TC=TO MI	24546	NA55D4753D
R147	321-0760-01			(R147A DALT) RES,FXD,FILM:189.9K OHM,0.5%,0.125W,TC=TO (P147B ONLY)	01121	ORDER BY DESCR
R147	321-0759-01			(R147) RES, FXD, FILM:95K OHM, 0.5%, 0.125W, TC=TO (R147C ONLY)	01121	ORDER BY DESCR
R147	321-0354-01		•	(RES, FXD, FILM: 47.5K OHM, 0.5%, 0.125W, TC=TO (R147D ONLY)	07716	CEAD47501D
R147	321-0757-01			RES, FXD, FILM: 18.99K OHM, 0.5%, 0.125W, TC=T9 (R147E ONLY)	01121	ORDER BY DESCR
R147	321-0758-01			RES,FXD,FILM:9.5K OHM,0.5%,0.125W,TC=TO (R147F ONLY)	19701	5033RD9K500D
R147	321-0258-01			ŘES,FXD,FILM:4.75K OHM,0.5%,0.125W,TC=TO (R147G ONLY)	2 454 6	NA55D4751D
R149	321-0354-01			RES, FXD, FILM:47.5K OHM, 0.5%, 0.125W, TC=T0	07716	CEAD47501D
R151	311-0965-00	B010100	B059999	RESISTOR ASSY:VAR, (2)10K OHM, 10%, 1W	80009	311-0965-00
R151	311-1162-00	B060000	B089999	RES, VAR, NONWW: PNL, 2 X 10K OHM. 1W	12697	D381-CM 39691
R151	311-1591-00	B090000	B139999	RES, VAR, NONWW: PNL, 2 X 10K OHM. 1W	12697	381-CM40266
R151	311-2196-00	B140000		RES. VAR, W: PNL, 2X10K OHM. 5%. 1W	32997	84N2AK35J15J15
R153	315-0273-00			RES, FXD, FILM: 27K OHM, 5%, 0.25W	57668	NTR25J-E27K0
R154	315-0273-00			RES,FXD,FILM:27K OHM,5%,0.25W	57668	NTR25J-E27K0
R156 R157	315-0101-00			RES,FXD,FILM:100 OHM,5%,0.25W (PART OF R151)	57 6 68	NTR25J-E 100E

<u>Component No.</u>	Tektronix Part No.	Serial/Assem Effective	bly No. Dscont	Name & Description	Mfr. Code	Mfr. Part No.
R158	315-0821-00			RES,FXD,FILM:820 OHM,5%,0.25W	19701	5043CX820R0J
R345	311-0258-00			RES, VAR, NONWW: PNL, 100 OHM, 0.5W	01121	WA1G024S101UA
R440	311-0310-00			RES, VAR, NONWW: PNL, 5K OHM, 0.5W	01121	W7350A
R522	321-0402-00			RES, FXD, FILM: 150K OHM, 1%, 0.125W, TC=T0	19701	5033ED150K0F
R523	321-0344-00			RES, FXD, FILM: 37.4K OHM, 1%, 0.125W, TC=T0	19701	5033ED 37K40F
R524	321-0373-00			RES, FXD, FILM: 75.0K OHM, 1%, 0.125W, TC=T0	19701	5033ED75K00F
R525	321 -040 2-00			RES.FXD.FILM:150K 0HM.1%.0.125₩.TC≂T0	19701	5033ED150K0F
S146	262-0894-00			SWITCH.WIRED: VOLTS/DIV	80009	262-0894-00
S146	260-1090-00			SWITCH, ROTARY: VOLTS/DIV	76854	5-36211-415

-

.

7S11

SECTION 8 DIAGRAMS AND MECHANICAL PARTS ILLUSTRATIONS

The following special symbols are used on the diagrams:



Scans by ArtekMedia => 2010

Scans by ARTEK MEDIA =>



Scans by Artekmedia => 2010

7511 SAMPLING UNIT

+ ·

۵

.

RMG 0370 BLOCK DIAGRAM

VOLTAGE AND WAVEFORM TEST CONDITIONS

The typical voltage measurements were obtained under the following conditions unless noted otherwise on the individual diagrams:

Voltr	neter	7ST1 (right vertical compartment, calibrated Sampling Head installed)				
Туре	Multimeter	-				
Sensitivity	20,000 ohm/volt	Units/Div	200			
Ranges	0.6 and 12 volts	VARIABLE	CAL IN			
Recommended type (used	Triplett Model 630-NA	+UP	Pushed in			
for measuring the voltage shown on the diagrams)	S	DC OFFSET	Midrange, 0 volts at OFFSET OUT jack.			
, and the second s		NORMAL	Pushed in			
		Input signal	Termination or Coaxial			
750	04		cable connected. No input signal.			
Vertical Mode	Left					
Horizontal Mode	В	7T11 (right l	horizontal compartment)			
B Intensity	Optimum	Slone	+			
A Trigger Source	Right Vert	Stability	Fully clockwise (free run)			
B Trigger Source	Left Vert	Sequential	Pushed in			
		Sweep Range	5 µs			
		Time/Div	.1 µs			
7A13 (left vertica	al compartment,	Int	Pushed in			
P6010, at +Inp 10X probe used	out connector, for waveforms)	Scan	Rep			
Volts	+	7B50 (left h	orizontal compartment)			
+Input	DC	Mode	Auto			
Comparison Voltage	20	Coupling	AC			
	Center display on	Source	Int			
	graticule	Magnifier	X1			
Volts/Div	See waveforms	Time/Div	See Waveforms			

All voltages given on the diagrams are in volts. Waveforms shown are actual waveform photographs taken with a Tektronix Oscilloscope Camera System and Projected Graticule. Vertical deflection factor shown on waveform is the actual deflection factor from the input connector and does not include the 10X attenuation of the probe. The voltages and waveforms (shown in blue) on the diagrams are not absolute and may vary between instruments because of component tolerances, internal calibration, or front panel control settings. Voltage and time readouts are simulated in larger-than-normal type.

NOTE

The spring tension of the pin sockets ensures a good connection between the circuit board and pin. This spring tension may be damaged by using the pin sockets as a connecting point for spring-loaded probe tip, alligator clips, etc.

Scans by ArtekMedia => 2010

Scans by ARTEK MEDIA =>







7511 SAMPLING UNIT

REV B, FEB 1979

hq 0370 MEMORY

MEMORY

 \diamond



OUTPUT AMPLIFIER



#



+

18

17

1,3

15

13 TO 14 OTHER 15 7511

то т. ц.

Scans by Artekmedia => 2010



7511 SAMPLING UNIT

READOUT LOGIC \$







OUTPUT CONNECTIONS

+





Scans by Artekmedia => 2010

7511 SAMPLING UNIT

Ø,

POWER DISTRIBUTION & DECOUPLING

200

L 631

L 632 14T

L634 14T

L639



* DECOUPLING

hq

0370

 \Diamond

+





FRONT PANEL CONTROLS & CONNECTORS (8) 85%

REPLACEABLE **MECHANICAL PARTS**

PARTS ORDERING INFORMATION

Replacement parts are available from or through your local Tektronix, Inc. Field Office or representative.

Changes to Tektronix instruments are sometimes made to accommodate improved components as they become available, and to give you the benefit of the latest circuit improvements developed in our engineering department. It is therefore important, when ordering parts, to include the following information in your order: Part number, instrument type or number, serial number, and modification number if applicable.

If a part you have ordered has been replaced with a new or improved part, your local Tektronix. Inc. Field Office or representative will contact you concerning any change in part number

Change information, if any, is located at the rear of this manual

SPECIAL NOTES AND SYMBOLS

X000 Part first added at this serial number

00X Part removed after this serial number

FIGURE AND INDEX NUMBERS

Items in this section are referenced by figure and index numbers to the illustrations.

ELCTRN

ELCTLT

ELEC

FLEM

EOPT

EPL

FXT

FIL

FLEX

FLH

FR FSTNR

FT FXD

GSKT

HDL

HEX

HEX HD

HLCPS

HLEXT

IDENT

IMPLR

HV

IC ID

HEX SOC

FLTR

INDENTATION SYSTEM

This mechanical parts list is indented to indicate item relationships. Following is an example of the indentation system used in the description column.

1 2 3 4 5 Name & Description

Assembly and/or Component Attaching parts for Assembly and/or Component

Detail Part of Assembly and/or Component Attaching parts for Detail Part

Parts of Detail Part Attaching parts for Parts of Detail Part

Attaching Parts always appear in the same indentation as the item it mounts, while the detail parts are indented to the right. Indented items are part of, and included with, the next higher indentation. The separation symbol - - - * - - - indicates the end of attaching parts.

Attaching parts must be purchased separately, unless otherwise specified.

ITEM NAME

In the Parts List, an Item Name is separated from the description by a colon (:). Because of space limitations, an Item Name may sometimes appear as incomplete. For further Item Name identification, the U.S. Federal Cataloging Handbook H6-1 can be utilized where possible.

••	INCH
#	NUMBER SIZE
ACTR	ACTUATOR
ADPTR	ADAPTER
ALIGN	ALIGNMENT
AL	ALUMINUM
ASSEM	ASSEMBLED
ASSY	ASSEMBLY
ATTEN	ATTENUATOR
AWG	AMERICAN WIRE GAGE
B D	BOARD
BRKT	BRACKET
BRS	BRASS
BRZ	BRONZE
BSHG	BUSHING
CAB	CABINET
CAP	CAPACITOR
CER	CERAMIC
CHAS	CHASSIS
СКТ	CIRCUIT
COMP	COMPOSITION
CONN	CONNECTOR
cov	COVER
CPLG	COUPLING
CRT	CATHODE RAY TUBE
DEG	DEGREE
DWR	DRAWER

ABBREVIATIONS

IN

OD

PL

ΡN

ELECTRICAL ELECTROLYTIC FI EMENT ELECTRICAL PARTS LIST EQUIPMENT EXTERNAL FILLISTER HEAD FLEXIBLE FLAT HEAD FILTER FRAME or FRONT FASTENER FIXED GASKET HANDLE HEXAGON HEXAGONAL HEAD HEXAGONAL SOCKET HELICAL COMPRESSION HELICAL EXTENSION HIGH VOLTAGE INTEGRATED CIRCUIT INSIDE DIAMETER IDENTIFICATION IMPELLER

ELECTRON

INCH INCAND INCANDESCENT INSULATOR INSUL INTI LAMPHOLDER LPHLDR MACH MACHINE MECHANICAL MECH MOUNTING MTG NIPPLE NIP NOT WIRE WOUND NON WIRE OBD ORDER BY DESCRIPTION OUTSIDE DIAMETER OVH OVAL HEAD PHOSPHOR BRONZE PH BRZ PLAIN or PLATE PLASTIC PLSTC PART NUMBER PAN HEAD PNH POWER PWR RCPT RECEPTACLE RES RESISTOR RIGID RGD RELIEF RLF RTNR RETAINER SOCKET HEAD SCH SCOPE OSCILLOSCOPE SCR SCREW

SINGLE END SE SECT SECTION SEMICOND SEMICONDUCTOR SHIELD SHOULDERED SHLD SHLDR SKT SOCKET SL SLFLKG SLIDE SELF-LOCKING SLVG SLEEVING ŝQ SQUARE STAINLESS STEEL SST STEEL STL SW SWITCH TUBE TERMINAL TERM THREAD THD тнк THICK TENSION TNSN TPG TAPPING TRH TRUSS HEAD VOLTAGE v VAR VARIABLE WITH W/ WASHER WSHR TRANSFORMER XEMB XSTR TRANSISTOR

CROSS INDEX - MFR. CODE NUMBER TO MANUFACTURER

Mfr. Code	Manufacturer	Address	City, State, Zip Code
00779	AMP INC	2800 FULLING MILL PO BOX 3608	HARRISBURG PA 17105
04 811	PRECISION COIL SPRING CO	10107 ROSE ST PO BOX 5450	EL MONTE CA 91734
07707	USM CORP SUB OF EMHART INDUSTRIES INC USM FASTENER DIV	510 RIVER RD	SHELTON CT 06848-4517
08261	SPECTRA-STRIP AN FLTRA CO	7100 LAMPSON AVE	GARDEN GROVE CA 92642
13556	TRW CYLINDRICAL CONNECTOR DIV OF TRW INC	8821 SCIENCE CENTER DRIVE	MINNEAPOLIS MN 55428-3619
22526	DU PONT E I DE NEMOURS AND CO INC DU PONT CONNECTOR SYSTEMS DIV. MILITARY PRODUCTS GROUP	515 FISHING CREEK RD	NEW CUMBERLAND PA 17070-3007
22 59 9	AMERACE CORP	15201 BURBANK BLVD SUITE C	VAN NUYS CA 91411-3532
23880	STANFORD APPLIED ENGINEERING INC	340 MARTIN AVE	SANTA CLARA CA 95050-3112
24546	CORNING GLASS WORKS	550 HIGH ST	BRADFORD PA 16701-3737
24931	SPECIALTY CONNECTOR CO INC	2100 EARLYWOOD DR PO BOX 547	FRANKLIN IN 46131
71785	CINCH CONNECTORS	1501 MORSE AVE	ELK GROVE VILLAGE IL 60007-5723
73743	FISCHER SPECIAL MFG CO	111 INDUSTRIAL RD	COLD SPRING KY 41076-9749
74445	HOLO-KROME CO	31 BROOK ST	ELMWOOD CT 06110-2350
77900	ILLINOIS TOOL WORKS SHAKEPROOF DIV	ST CHARLES RD	ELGIN IL 60120
78189	ILLINOIS TOOL WORKS INC SHAKEPROOF DIV	ST CHARLES ROAD	ELGIN IL 60120
79136	WALDES KOHINOOR INC	47-16 AUSTEL PLACE	LONG ISLAND CITY NY 11101-4402
80009	TEKTRONIX INC	14150 SW KARL BRAUN DR PO BOX 500	BEAVERTON OR 97077-0001
83 38 5	MICRODOT MFG INC GREER-CENTRAL DIV	3221 W BIG BEAVER RD	TROY MI 48098
83486	ELCO INDUSTRIES INC	1101 SAMUELSON RD	ROCKFORD IL 61101
84830	LEE SPRING CO INC	1462 62ND ST	BROOKLYN NY 11219-5413
87308	FARLEY METALS INC	BARKLEY RD	STATESVILLE NC 28677-9774
	SOUTHERN SCREW DIV	P 0 BOX 1360	
90484	SURPRENANT WIRE AND CABLE DIV OF FL INDUSTRIES INC	172 STERLING ST	CLINTON MA 01510
91260	CONNOR SPRING AND MFG CO A SLOSS AND BRITTAN INC CO	1729 JUNCTION AVE	SAN JOSE CA 95112
92101	SCHULZE MFG	50 INGOLD RD	BURLINGAME CA 94010-2206
93907	TEXTRON INC	600 18TH AVE	ROCKFORD IL 61108-5181
98291	SEALECTRO CORP BICC FLECTRONICS	40 LINDEMAN DR	TURNBULL CT 06611-4739
TK0392	NORTHWEST FASTENER SALES INC.	7923 SW CIRRUS DRIVE	BEAVERTON OR 97005-6448
TK0433	PORTLAND SCREW CO	6520 N BASIN	PORTLAND OR 97217-3920
TK0435	I FWIS SCREW CO	4300 S RACINE AVE	CHICAGO IL 60609-3320
TK0588	UNIVERSAL PRECISION PRODUCTS	1775 NW 216TH	HILLSBORD OR 97123
TK1326	NORTHWEST FOURSLIDE INC	18224 SW 100TH CT	TUALATIN OR 97062

Fia.	8
	~

Index	Tektronix	Serial/Ass	embly No.	•		Mfr.	ME. Daugh Nu
NO.	Part No.	Lifective	Discont	Qty	12345 Name & Description	Code	MTr. Part No.
1-1	366-0392-02			1	KNOB:GY.0.125 ID X 0.375 H X 0.812 H	80009	366-0392-02
-2				ī	RESISTOR, VAR: (SEE R440 REPL)		
	213-0020-00			1	(ATTACING FACIS) SETSCREW:6-32 X 0.125,STL	TK0433	ORDER BY DESCR
2	266 1100 00			1	$(END A A \cup A \cup$	0000	266-1180-00
-3	212-0152-00			1	NUD: 01, 0.12/ 10 X 0.5 00 X 0.551	00003 TK0303	ODDED BY DESCD
	213-0155-00			1	SEISUKEW: 3-40 A U.123, SIL	180392	URDER DI DESCR
-4				1	(ATTACHING PARTS)		
-5	361-0143-00			1	SPACER.RING:0.125 L X 0.281 ID.AL	80009	361-0143-00
-6	210-0583-00			1	NUT, PLAIN, HEX: 0.25-32 X 0.312, BRS CD PL	73743	2X-203 19-402
-7	366-1064-00	B010100	8050000	1	KNOB-GY 0.096 TD Y 0.392 OD Y 0.466	80008	366-1064-00
,	366-1084-00	B060000	00333333	1	KNOB-GY 0 08 TD X 0 392 0D X 0 400	80009	366-1084-00
	213-0239-00	2000000		1	SETSCREW-3-48 X 0 062 STI	80009	213-0239-00
-8	366-1148-00	B010100	B029999	1	KNOB GY 0 16 TD X 0 706 0D X 0 6 H	80009	366-1148-00
Ũ	366-1148-01	B030000	B059999	1	KNOB-GY 0 16 ID X 0 706 0D X 0 6 H	80009	366-1148-01
	366-1101-00	B060000	000000	1	KNOB GY 0 127 ID X 0 706 0D X 0 6 H	80009	366-1101-00
	213-0153-00	0000000		2	SETSCREW-5-40 X 0 125 STI	TK0392	ORDER BY DESCR
-Q				1	RESISTOR VAR-(SEE DISI DIST REPL)	110002	ONDER DI DECOR
U				-	(ATTACHING PARTS)		
-10	210-0583-00			1	NUT, PLAIN, HEX:0.25-32 X 0.312, BRS CD PL	73743	2X-20319-402
11	200 1100 00			1	(ENU ALTALATING PARTS)	00000	266 1169 00
-11	300-1100-00			1	NUD:RED, U. 004 10 X U. 392 UD X U.4 H	00009	000-1100-00
10	213-0153-00			1	.SEISUKEW: 3-40 & 0.123, SIL	100392	DRUER DI DESCR
-12	300-105/-00			1	KNUB:GT,U.252 ID X U./96 UD X U./9 H	80009	300-103/-00
10	213-0153-00			1	SEISCREW: 5-40 X 0.125, STL	1K0392	ORDER BT DESCR
-13				1	SWITCH, WIRED: VOLIS/DIV(SEE SI46 REPL)		
	~~~~~~				(ATTACHING PARTS)	707.00	
-14	210-0590-00			1	NUI, PLAIN, HEX: 0.375-32 X 0.438 BRS CD PL	/3/43	28269-402
					(END ATTACHING PARTS)		
-15	214-1205-00			1	ADAPTER, SW ACTR: VARIABLE (CAL IN)	80009	214-1205-00
	213-0075-00			1	.SETSCREW: 4-40 X 0.094, STL	74445	ORDER BY DESCR
-16	214-1190-00			1	CPLG, SHAFT, RGD: 0.125 OD TO 0.125 OD, AL	80009	214-1190-00
	213-0075-00			1	.SETSCREW:4-40 X 0.094,STL	74445	ORDER BY DESCR
	213-0140-00			1	.SETSCREW:2-56 X 0.094,STL	TK0433	ORDER BY DESCR
-17				1	RESISTOR, VAR: (SEE R345 REPL)		
					(ATTACHING PARTS)		
-18	220-0510-00			1	NUT, PLAIN, HEX: 0.25 X 0.312 HEX, AL	80009	220-0510-00
-19	210-0046-00			1	WASHER, LOCK: 0.261 ID, INTL, 0.018 THK, STL	77900	1214-05-00-0541C
-20	358-0409-00			1	BSHG, MACH THD: 0.25-32 X 0.159 ID, BRS	80009	358-0409-00
					(END ATTACHING PARTS)		
-21				1	CKT BOARD ASSY:+UP/INVERT(SEE A4 REPL)		
	380-0148-00			1	.HOUSING, LIGHT: STAINLESS STEEL	80009	380-0148-00
					.(ATTACHING PARTS)		
	213-0181-00			1	.SCREW, TPG, TF: 2-32 X 0.375, TYPE B, PNH, STL	83385	ORDER BY DESCR
					.(END ATTACHING PARTS)		
-22	131-0589-00			6	.TERMINAL,PIN:0.46 L X 0.025 SQ PH BRZ	22526	48283-029
-23	131 <b>-0590-0</b> 0			2	.TERMINAL,PIN:0.71 L X 0.025 SQ PH BRZ	22526	47331
					(ATTACHING PARTS FOR CKT BOARD)		
-24	211-0156-00			1	SCREW, MACHINE: 1-72 X 0.250, FLH, 82 DEG, STL	93907	ORDER BY DESCR
					(END ATTACHING PARTS)		
-25				1	CKT BOARD ASSY:NORMAL/SMOOTH-INT TRIG		
					(SEE A5 REPL)		
	380-0154-00			1	.HOUSING, LIGHT: STAINLESS STEEL	80009	380-0154-00
					.(ATTACHING PARTS)		
	213-0181-00			1	.SCREW, TPG, TF:2-32 X 0.375, TYPE B, PNH, STL	83385	ORDER BY DESCR
					.(END_ATTACHING_PARTS)		
-26	131-0589-00			9	.TERMINAL,PIN:0.46 L X 0.025 SQ PH BRZ	22526	48283-029
-27	131-0590-00			2	.TERMINAL, PIN: 0.71 L X 0.025 SQ PH BRZ	22526	47331
					.(ATTACHING PARTS FOR CKT BOARD)		
-28	2 <b>11-0156-00</b>			1	SCREW, MACHINE: 1-72 X 0.250, FLH, 82 DEG, STL	93907	ORDER BY DESCR
					(END ATTACHING PARTS)		
-29	131 <b>-0779-00</b>			3	JACK, TIP: U/W 0.08 OD TEST POINT	98291	0168010000208
-30	352-0181-00			1	HOLDER, TIP JACK: 1.308 X 0.3 X 0.25, DELRIN	80009	352-0181-00
					(ATTACHING PARTS)		
-31	213-0012-00			2	SCREW, TPG, TC: 4-40 X 0.375, FLH 100 DEG, STL	83385	ORDER BY DESCR
					(END ATTACHING PARTS)		

. .

Fig.& Index No.	Tektronix Part No.	Serial/As Effectiv	ssendbly No. ve Dscont	Qty	12345	Name & Description	Mfr. Code	Mfr. Part No.
1-32 -33	358-0301-02 366-1058-09			1	BUSHIN KNOB:G	G,SLEEVE:0.16 ID X 0.205 OD RAY,7S11	80009 80009	358-0301-02 366-1058-09
-34	214-1095-00			1	(ATTAC PIN,SP (END A	HING PARTS) RING:0.187 L X 0.094 OD,STL,CD PL TTACHING PARTS)	22599	52-022-094-0187
-35	105-0076-02	B010100 B125325	B125324	1	RELEAS	E BAR, LCH: PLUG-IN UNIT F BAR, LCH: PLUG-IN UNIT	80009 80009	105-0076-02 105-0076-04
-36	214-1280-00	DILOGLO		ī	SPRING	HLCPS:0.14 OD X 1.126 L, TWIST LOOP	91260	ORDER BY DESCR
-37	348-0235-00			1	Shld G	SKT,ELEK:FINGER TYPE,4.734 L	92101	ORDER BY DESCR
-38	214-1054-00			1	SPRING	FLAT:0.825 X 0.322,SST	TK1326	5 ORDER BY DESCR
-39	105~00/5-00			1	BOLT, D	AICH: E ELEC: GROUNDING CH RE	80009	105-00/5-00
-40	333-1218-00			1	PANEL	FRONT ·	80009	333-1218-00
-42	386-1447-20			1	SUBPAN	EL, FRONT:	80009	386-1447-20
-43	213-0192-00 213-0793-00	8010100 B124525	B124524	4 4	SCREW,	IPG, TF:6-32 X 0.5, SPCL TYPE, FILH, STL IPG, TF:6-32 X 0.4375, TAPTITE, FILH	87308 83486	ORDER BY DESCR 239 <b>-006</b> -406043
-44	200-0895-00			1	COVER, I	WR SPLY:FRONT IING PARTS)	80009	2 <b>00-08</b> 95-00
-45	343-0153-00			4	CLAMP, F	RIM CLENC:0.375 X 0.358, BRS	80009	343-0153-00
-46	210-0457-00			4	NUT, PL, (END AT	ASSEM WA:6-32 X 0.312,STL CD PL TACHING PARTS)	78189	511-061800-00
-47	351-0132-00			1	GUIDE-C	LIP: SAMPLING HEAD, ACETAL	80009	351-0132-00
-48	131-0581-00			1	CONN, RC	CPT, ELEC: EDGECARD, 6/12 CONT, 0.156 SP	23880	MMM6D/1-2TX
-49	213-0082-00			2	SCREW, T	PG,TC:4-40 X 0.5,TYPE T,PNH,STL TACHING PARTS)	TK0435	7933-302
-50	255-0249-00 407-0628-00			AR 1	PLASTIC BRACKET	CHANNEL:0.205 X 0.155 X 0.035, VINYL , CMPNT:SAMPLING HD CONN, ALUMINUM ING PARTS)	80009 80009	255-0249-00 407-0628-00
-51	211-0101-00			4	SCREW.M	ACHINE:4-40 X 0.25.FLH.100 DEG.STL	93907	ORDER BY DESCR
-52	210-0586-00			2	NUT, PL, (END AT	ASSEM WA:4-40 X 0.25,STL CD PL TACHING PARTS)	78189	211-041800-00
-53	220-0547-01			6	NUT BLC	CK:4-40 X 0.282,NI SIL NP ING PARTS)	80009	220-0547-01
-54	211-0105-00			6	SCREW,M (END AT	ACHINE:4-40 X 0.188,FLH,100 DEG TACHING PARTS)	TK0435	ORDER BY DESCR
-55	426-0499-06			1	FR SECT	, PLUG-IN: BOTTOM	80009	426-0499-06
-56	426-0505-06			1	FR SECT	, PLUG-IN: TOP	80009	426-0505-06
-5/	131-0410-00			1	CONN, RC (ATTACH	PT,ELEC:COAXIAL CONTACTS,RTANG PLUG ING PARTS)	13556	DM53741-5001
-58 -59	354-0331-00 343-0190-00			1 1	RING, RI RTNR, EL	NG:EXT BOWED E,U/O 0.219 DIA SFI EC CONN:ALUMINUM TACUINC DADIS)	79136 80009	5131-X-21MD 343-0190-00
~60				1	CKT BOA	RD ASSY:COMMUTATOR SW MOVING REPL)		
-61	131-0839-00			6	.CONTAC	T, ELEC: TRIG COMMUTATOR, NI BE GOLD PL	80009	131-0839-00
-62	210-0702-00			18	.EYELET	,METALLIC:0.047 00 X 0.125 L	07707	S-6127-
-63	131-0842-00			4	. TERMIN	AL,LUG:0.76 ID X 0.225 L,BRS CD PL	80009	131-0842-00
-65	131-0512-00			1	CONNEC	TOR TERM 28-22 AVE RE CULCOLD R	00779	6150/-1 61615-1
-66	131-0375-00			2	CONN P	IUR, IERM:20-32 AWG, DE CU GULD PL	24931	32P-111-1
-67	175-0826-00			AR	CABLE.	SP FLEC:3.26 AWG.STRD PVC JKT RBN	80009	175-0826-00
-68	131-0621-00			3	.CONN.T	ERM: 22-26 AWG. BRS. CU BE GLD PL	22526	46231-000
-69	352-0199-00			1	.HLDR,T	ERM CONN:3 WIRE, BLACK HING PARTS FOR CKT BOARD)	80009	352-0199-00
-70	211-0038-00			3	SCREW, M	ACHINE: 4-40 X 0.312, FLH, 100 DEG, STL	93907	ORDER BY DESCR
-71	204-0411-00			1	BODY, HA	LF CONN:MOVING	80009	204-0411-00
-72	214-1035-00			3	SPRING,	HLCPS:0.3 OD X 0.265 L,OPEN ENDS,MUW	84830	LC-026D-4 SS
-/3	386-1679-00			3	BLOCK, SI	JPPORT: COMMUTATOR HALF	80009	386-1679-00
-74	213-0230-00			చ 2	NUT DIA	LVE:4-40 INTE HU,U.531 L,FEH,BKS	80009	213-0230-00
-76	211-0101-00			3	SCREW, M	ACHINE:4-40 X 0.25, FLH, 100 DEG, STL FACHING PARTS)	93907	ORDER BY DESCR
-77				1	CKT BD /	ASSY: COMMUTATOR SW FIXED		
-78	131-0842-00			2	TERMIN	AL,LUG:0.76 ID X 0.225 L,BRS CD PL	80009	131-0842-00

-

Fig.	&
------	---

Index	Tektronix	Serial/Ass	sembly No.			Mfr.	
<u>No.</u>	Part No.	Effective	e Dscont	Qty	12345 Name & Description	<u>Code</u>	<u>Mfr. Part No.</u>
1-79	175-0826-00	1		AR	.CABLE.SP.ELEC:3.26 AWG.STRD.PVC JKT.RBN	80009	175-0826-00
-80	131-0621-00	1		3	.CONN.TERM: 22-26 AWG.BRS.CU BE GLD PL	22526	46231-000
-81	352-0199-00	1		1	HLDR. TERM CONN: 3 WIRE BLACK	80009	352-0199-00
-82	131-0512-00			1	.CONTACT.ELEC:CONNECTOR.CU BE GOLD PL	00779	61507-1
-83	131-0755-00	1		ī	.CONNECTOR.TERM: 28-32 AWG.BE CU GOLD PL	00779	61615-1
				-	(ATTACHING PARTS FOR CKT BOARD)		
-84	211-0038-00			3	SCREW.MACHINE: 4-40 X 0.312.FLH.100 DEG.STL	93 <b>9</b> 07	ORDER BY DESCR
	210-0001-00	i i		3	WASHER.LOCK: #2 INTL.0.013 THK.STL	77900	1202-00-00-0541C
-85	210-0405-00			3	NUT.PLAIN.HEX:2-56 X 0.188.BRS CD PL	73743	12157-50
					(END ATTACHING PARTS)		
-86	204-0410-00			1	BODY HALF, CONN: STATIONARY	80009	204-0410-00
					(ATTACHING PARTS)		
	211-0038-00			3	SCREW.MACHINE: 4-40 X 0.312.FLH.100 DEG.STL	939 <b>07</b>	ORDER BY DESCR
-87	210-0586-00			3	NUT, PL, ASSEM WA: 4-40 X 0.25, STL CD PL	78189	211-041800-00
					(END ATTACHING PARTS)		
-88				1	ČKT BOARD ASSY:VERTIČAL(SEE A1 REPL)		
-89	136-0220-00			24	.SKT, PL-IN ELEK: TRANSISTOR 3 CONTACT	71785	133-23-11-034
-90	136-0235-00			2	.SKT, PL-IN ELEK: TRANSISTOR, 6 CONTACT	71785	133-96-12-062
-91	136-0263-03	B010100	B102089	39	.SOCKET, PIN TERM: U/W 0.025 SQ PINS	00779	85864-2
	136-0263-04	B102090		39	.SOCKET, PIN TERM: U/W 0.025 SQ PIN	22526	75377-001
-92	214-0579-00			10	.TERM, TEST POINT: BRS CD PL	80009	214-0579-00
-93	361-0238-00			4	.SPACER, POST: 0.433 L, 0.25 OD	80009	361-0238-00
-94	211-0155-00			4	.SCREW, EXT RLV:4-40 X 0.375, PNH, SST, POZ	80009	211-0155-00
-95				1	CKT BOARD ASSY: INTER-CHANNEL CONT		
					(SEE A2 REPL)		
-96	131-0391-00	B010100	B079999	1	.CONN, RCPT, ELEC: SNAP-ON, MALE, BULK PACK	24931	32JR105-1
	131-0391-00	B080000		2	.CONN, RCPT, ELEC: SNAP-ON, MALE, BULK PACK	24931	32JR105-1
-97	136-0183-00			1	.SKT, PL-IN ELEK: TRANSISTOR, 3 CONTACT	80009	136-0183-00
-98	136-0220-00			10	.SKT, PL-IN ELEK: TRANSISTOR 3 CONTACT	71785	133-23-11-034
-99	136-0235-00			1	.SKT, PL-IN ELEK: TRANSISTOR, 6 CONTACT	71785	133-96-12-062
-100	136-0263-03	B010100	B102089	19	.SOCKET, PIN TERM: U/W 0.025 SQ PINS	00779	85864-2
	136-0263-04	B102090		16	.SOCKET, PIN TERM: U/W 0.025 SQ PIN	22526	75377-001
-101	426-0121-00			1	. MOUNT, COMPONENT :	80009	426-0121-00
-102	361-0007-00			1	.SPACER, SLEEVE: 0.188 L X 0.111 ID, POLTHN	80009	361-0007-00
-103	361-0238-00			3	.SPACER, POST: 0.433 L, 0.25 OD	80009	361-0238-00
-104	211-0155-00			3	.SCREW, EXT RLV:4-40 X 0.375, PNH, SST, POZ	80009	211-0155-00
-105				1	CKT BOARD ASSY: INTERFACE (SEE A3 REPL)		
-106	131-0391-00			2	.CONN,RCPT,ELEC:SNAP-ON,MALE,BULK PACK	24931	32JR105-1
-107	131-0566-00			2	.BUS,CONDUCTOR:DUMMY RES,0.094 OD X 0.225 L	24546	OMA 07
-108	131-0589-00			40	.TERMINAL,PIN:0.46 L X 0.025 SQ PH BRZ	22526	48283-029
	131-0590-00	B010100	B079999	48	.TERMINAL,PIN:0.71 L X 0.025 SQ PH BRZ	22526	47331
	131-0590-00	B080000		46	.TERMINAL,PIN:0.71 L X 0.025 SQ PH BRZ	22526	47331
	131-0593-00			4	.TERMINAL,PIN:1.15 L X 0.025 SQ BRS TIN PL	22526	47334
	131-0665-00			1	.TERMINAL,PIN:0.88 L X 0.025 SQ,BRS TIN PL	22526	47338
	131-0827-00			1	.TERMINAL,PIN:0.55 L X 0.025 SQ PH BRZ	22526	48283-028
-109	131-0593-00			4	.TERMINAL,PIN:1.15 L X 0.025 SQ BRS TIN PL	22526	47334
-110	136-0183-00			1	.SKT, PL-IN ELEK: TRANSISTOR, 3 CONTACT	80009	136-0183-00
-111	136-0220-00			2	.SKT, PL-IN ELEK: TRANSISTOR 3 CONTACT	71785	133-23-11-034
-112	351-0155-00			5	.INSULATOR, STDF: CONNECTOR, DELRIN	80009	351-0155-00
-113	351-0188-00			7	.POST,CKT BD MTG:0.65 INCH LONG	80009	351-0188-00
-114	351-0185-00			1	.POST,CKT BD MTG:0.65 L X 0.25 DD BRS	80009	351-0185-00
-115	214-1140-00			8	.SPRING, HLCPS: 0.251 OD 0.375 L, CLE ENDS, SST	04811	ORDER BY DESCR
-115	214-1136-00			1	ACTUATOR, SL SW: VARIABLE CAL	80009	214-1136-00
-11/	351-0180-00			1	.GUIDE, SLIDE SW: SWITCH ACTUATOR	80009	351-0180-00
-118	407-0553-00			1	.BRACKET, CMPNT: BRASS ALBALOY PL	80009	407-0553-00
-119				1	.RESISTUR, VAR: (SEE R320 REPL)	70740	av 00010 400
-120	210-0583-00			1	.NUT, PLAIN, HEX: 0.25-32 X 0.312, BKS CD PL	/3/43	22-20319-402
101	011 0110 00	D010100	D104140	~	. (ALLACHING PARIS FOR CKI BUARD)	77000	OPDED DY DECCD
-121	211-0116-00	B010100	B124149	b	SUR, ASSEM WSHR: 4-40 X U.312, PNH, BRS, NP, PUZ	7/900	URDER BT DESCR
	211-0292-00	D124150		ь	SUK, ASSEM WSHK: 4-40 X U.29, PNH, BKS NI PL	19199	51-040445-01
100	200 1400 00	D010100	D1 4001 F		(END ATTACHING PARIS)	00000	200 1402 00
-122	386-1402-00	B010100	B149015	1	PANEL, KEAK:	80009	300-1402-00
	386-5466-00	6149016		1	PANEL, KEAK:	80009	300-5400-00
100	010 0100 00	D010100	D104504		(ATTACHING PARIS)	07000	ADDED DV DECOD
-123	213-0192-00	BUTUTUU B124E05	D124524	4	SUKEW, ING, IT: 0-32 X U.S. SPUL IYPE, FILH, SIL	0/308	UKUEK DI DESCK
	213-0/93-00	D124323		4	JUKEW, IFG, IF: 0-32 A U.43/5, IAPIIIE, FILM (END ATTACHING DADIS)	00400	233-000-400043
_124	327-1220 00	P010100	PAEAAAA	1		90000	227-1228-00
-154	331-1230-00	0010100	00099999	T	SHIELD, ELEC: LEFT SIDE	00009	33/-1230-00

- -

Fig.& Index No.	Tektronix Part No.	Serial/A	ssennbly No. ve Dscont	Qty	12345	Name & Description	Mfr. Code	Mfr. Part No.
1-	337-1238-01	B060000		1	SHIELD	.ELEC:LEFT SIDE	80009	337-1238-01
-125	337-1247-00	B010100	B059999	ī	SHIELD	ELEC:RIGHT SIDE	80009	337-1247-00
	337-1247-01	B060000		1	SHIELD	ELEC:RIGHT SIDE	80009	337-1247-01
-126	131-0375-00	B010100	B079999	ī	.CONN.	PLUG.ELEC: SNAP-ON FEMALE	24931	32P-111-1
	131-0375-00	B080000		2	.CONN .	PLUG, ELEC: SNAP-ON FEMALE	24931	32P-111-1
-127	175-0825-00			AR	CABLE	SP.ELEC:2.26 AWG.STRD.PVC JKT.RBN	80009	175-0825-00
~128	175-0828-00			AR	CABLE	SP. FLEC: 5.26 AWG. STRD. PVC JKT. RBN	08261	111-2699-955
-129	175-0831-00			AR	CABLE	SP.ELEC:8.26 AWG.STRD.PVC INSUL.RBN	08261	111-2699-971
-130	175-0832-00			AR	CABLE	SP.ELEC:9.26 AWG.STRD.PVC JKT.RBN	08261	111-2699-956
-131	352-0162-00			1	HLDR	FERM CONN: 4 WIRE, BLACK	80009	352-0162-00
-132	352-0163-00			1	.HLDR.	TERM CONN:5 WIRE, BLACK	80009	352-0163-00
-133	352-0169-00			ī	.HLDR.	TERM CONN:2 WIRE, BLACK	80009	352-0169-00
	352-0169-02			2	HLDR.	FERM CONN:2 WIRE.RED	80009	352-0169-02
-134	352-0176-00			ī	.HLDR.	FERM CONN: 4 WIRE, DBL ROW BLACK	80009	352-0176-00
-135	352-0198-00			ī	.HLDR.	FERM CONN:2 WIRE, BLACK	80009	352-0198-00
-136	352-0201-00			3	.HLDR.	FERM CONN:5 WIRE, BLACK	80009	352-0201-00
-137	352-0204-00			1	.HLDR.	ERM CONN:8 WIRE.BLACK	80009	352-0204-00
-138	352-0205-00			ī	.HLDR.	ERM CONN:9 WIRE, BLACK	80009	352-0205-00
-139	131-0707-00			1	CONTAC	CT.ELEC:22-26 AWG.BRS.CU BE GLD PL	22526	47439-000
	131-0708-00			1	.CONTAG	T.ELEC: 28-32 AWG.BRS.CU BE GLD PL	22526	47437-000
-140	131-0621-00	B010100	B020369	1	.CONN.	ERM: 22-26 AWG. BRS. CU BE GLD PL	22526	46231-000
	131-0792-00	B020370		3	CONNEC	TOR, TERM: 18-20 AWG, CU BE GOLD PL	22526	46221
	131-0622-00			1	.CONTAC	T.ELEC:28-32 AWG.BRS & CU BE GLD PL	22526	46241-000
-141	384-0664-00			1	.SHAFT	STRAIGHT:1.05 L X 0.1247 0D.SST	80009	384-0664-00
-142	384-0679-00			1	.EXTENS	ION SHAFT: 5.29 L X 0.125 STEP OD. STL	TK0588	ORDER BY DESCR
-143	376-0051-00			1	.CPLG.S	HAFT.FLEX:0.127 ID X 0.375 OD.DELRIN	80009	376-0051-00
	213-0048-00			4	.SETSCF	EW:4-40 X 0.125.STL	TK0392	ORDER BY DESCR
-144	175-1020-00	B010100	B102088	1	CABLE.F	F:50 OHM COAX, WHT POLYTHN JKT	90484	DAB70J AAA WHITE
	175-1769-00	B102089		1	CABLE A	SSY,RF:50 OHM COAX,4.75L	80009	175-1769-00
					STANDAR	D ACCESSORIES		
	070-0985-00			1	MANUAL,	TECH: INSTRUCTION	80009	070-0985-00

REV FEB 1989

•

-



				,			
No.	Part No.	Eff	Dscont	Qtv 12345	Name & Description	Code	Mfr Part Number
Index	Tektronix	Serial/M	lodel No.			Mfr	
Fig. &							

070-0985-00

1 MANUAL, TECH: INSTRUCTION '

80009 070-0985-00

### MANUAL CHANGE INFORMATION

At Tektronix, we continually strive to keep up with latest electronic developments by adding circuit and component improvements to our instruments as soon as they are developed and tested.

Sometimes, due to printing and shipping requirements, we can't get these changes immediately into printed manuals. Hence, your manual may contain new change information on following pages.

A single change may affect several sections. Since the change information sheets are carried in the manual until all changes are permanently entered, some duplication may occur. If no such change pages appear following this page, your manual is correct as printed.